

INDEX

INDEX FOR TOOL NUMBER

A.....	2
B.....	2
C.....	3
D.....	5
E.....	6
F.....	7
G.....	7
H.....	8
I.....	8
J.....	9
K.....	9
L.....	9
M.....	9
N.....	11
O.....	13
P.....	13
Q.....	14
R.....	14
S.....	14
T.....	16
U.....	18
V.....	18
W.....	19
X.....	20
Z.....	20
NUMBER / OTHERS	20



INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
A		
A50UMWLNRO8	M type boring bar	E039
ABS000-ES-M	Parts for ABS head	N024
ABS000-ES-M0	Parts for ABS head	N024, N025
ABS00-F0	Screw (For ABS adapter)	N023
ABS000-FS-W	Parts for ABS adapter	N023
ABS000M	Parts for ABS head	N024
ABS000W	Parts for ABS adapter	N023
AD-BM10	Banjo adapter	F112
A000-DCLNR/L12	DOUBLE CLAMP DIMPLE BAR	E013
A000-DDUNR/L15	DOUBLE CLAMP DIMPLE BAR	E013
AD-G1/8	Adapter	F113
A000-DSKNR/L12	DOUBLE CLAMP DIMPLE BAR	E014
A000-DTFNR/L16	DOUBLE CLAMP DIMPLE BAR	E014
A000-DVUNR/L16	DOUBLE CLAMP DIMPLE BAR	E015
A000-DWLNRL00	DOUBLE CLAMP DIMPLE BAR	E015
AEMW000000ER	Insert (For BAE type cutter)	L024
AF5000 type	Spare parts (For AF5000 type face mill)	Q028
AHX440S-0000A00AR	AHX440S type face mill	M038, M039
AHX440SR000000A	AHX440S type face mill	M038
AHX475S-000A00AR	AHX475S type face mill	M043
AHX475SR000000A	AHX475S type face mill	M043
AHX640S-00000000R	AHX640S type face mill	M046, M047
AHX640SR00000000	AHX640S type face mill	M046
AHX640W-0000000R/L	AHX640W type face mill	M055
AHX640WR/L0000000	AHX640W type face mill	M054
AJS0000T00	Clamp screw	C030, M165, Q003
AJX00-00000000	AJX type face mill	M162
AJX00R0000000	AJX type face mill	M162
AJX00R0000AM0000	AJX type end mill	M166
AJX00R0000SA00S/SS/L/EL	AJX type end mill	M164, M165
AMS0	Clamp bridge	C030, M165, Q014
AOGT123600PEFR-GM	Insert (For APX3000 type cutter)	L024, M099, M204
AOMT123600PEER-0	Insert (For APX3000 type end mill)	L024, M099, M204
AOMT184800PEER-0	Insert (For APX4000 type end mill)	L024, M105, M208
AOX445-0000000R	AOX445 type face mill	M060
AOX445R00000000	AOX445 type face mill	M060
AOX445R0000S32	AOX445 type end mill	M060
A000MWLN type	Spare parts (For M type boring bar)	Q026
A000PCLNR/L00	P type boring bar	E036, Q026
A000PDQNR/L00	P type boring bar	E037
A000PDUNR/L00	P type boring bar	E036
A000PDZNR/L00	P type boring bar	E038
APGT1135PDFR-G2	Insert (For BAP300 type cutter)	L025, M087, M210
APGT1604PDFR-G2	Insert (For BAP400 type cutter)	L025
APMT1135PDER-00	Insert (For BAP300/SRM2 type cutter)	L025, M087, M210, M239, M245
APMT1604PDER-00	Insert (For BAP400/SRM2 type cutter)	L025, M239, M245
A000PSKNR/L00	P type boring bar	E035, Q026
A000PTFNR/L00	P type boring bar	E035

ORDER NUMBER	PRODUCT NAME	PAGE
A000PWLNR/L00	P type boring bar	E037
APX3K-000A000RA	APX3000 type end mill (Long cutting edge)	M203
APX3KR0000S0000000A	APX3000 type end mill (Long cutting edge)	M202
APX4K-000A000RA	APX4000 type end mill (Long cutting edge)	M207
APX4KR06316CA056A	APX4000 type end mill (Long cutting edge)	M207
APX4KR0000SA42S056A	APX4000 type end mill (Long cutting edge)	M206
APX4KR0000WA5080000A	APX4000 type end mill (Long cutting edge)	M206
APX3000-000A000RA	APX3000 type face mill	M097
APX3000R0000000A	APX3000 type face mill	M097
APX3000R000M00A00	APX3000 type end mill	M098
APX3000R000SA000A	APX3000 type end mill	M096
APX4000-000A000RA	APX4000 type face mill	M103
APX4000R0000000A	APX4000 type face mill	M103
APX4000R000M00A00	APX4000 type end mill	M104
APX4000R000SA000A	APX4000 type end mill	M102
AQXR000M00A00	AQX type end mill	M156
AQXR000SA/N00S/L	AQX type end mill	M154, M155
ARP6PR000000A	ARP type face mill	M186
ARP0P-0000000AR	ARP type face mill	M187
ARP0PR0000AM0000	ARP type end mill	M189
ARP0PR0000SA0000	ARP type end mill	M188
ARX00R000M00A00	ARX type end mill	M193
ARX00R000SA00S/LW	ARX type end mill	M192, M193
ASS0	Spring (For SXZC/AJX/PMC/BRE/CV type cutter)	C030, M162, M254, Q035, Q036
ASX400	ASX400 side cutter	M095
ASX400-0000000R	ASX400 type face mill	M080, M081
ASX400R00000000	ASX400 type face mill	M080
ASX400R0000AM1600	ASX400 type end mill	M083
ASX400R0000S00	ASX400 type end mill	M082
ASX445-0000000R	ASX445 type face mill	M030, M031
ASX445R00000000	ASX445 type face mill	M030
ASX445R0000S00	ASX445 type end mill	M032
AXD4000-000A000RA/B	AXD4000 type face mill	M135
AXD4000R0000000A/B	AXD4000 type face mill	M135
AXD4000R0000SA0000	AXD4000 type end mill	M134
AXD7000-000A000RA/B	AXD7000 type face mill	M142, M143
AXD7000R0000000A/B	AXD7000 type face mill	M142
AXD7000R0000000A-H63A	AXD7000 type end mill (For HSK-T)	M143
AXD7000R0000SA00SA/B	AXD7000 type end mill	M142
B		
B10000	Arbor (For D type boring head)	E042, F138, G039
BAE type	Spare parts (For BAE type end mill)	Q034
BAP300 type	Spare parts (For BAP300 type face mill)	Q028
BAP300 type	Spare parts (For BAP300 type end mill)	Q034

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
BAP300R ^{○○○○○} ES ^{○○}	BAP300 type end mill (Long cutting edge)	M210	BTBT ^{○○○○○○○} R/L-SMB	Insert for external back turning	D013
BAP300R ^{○○○○○} LS ^{○○}	BAP300 type end mill (Long shank type)	M086	BTVHR ^{○○○○○} ○○	Small tools holder (External back turning) ...	D014
BAP300R ^{○○○○○} S ^{○○}	BAP300 type end mill	M086	BTVT ^{○○○○○○○} R-B	Insert for external back turning	D014
BAP3500 type	Spare parts (For BAP3500 type end mill)	Q034	BXD4000- ^{○○○○○○○} RA/B	BXD4000 type face mill	M150, M151
BAP400 type	Spare parts (For BAP400 type face mill)	Q028	BXD4000R ^{○○○○○○○} A/B	BXD4000 type face mill	M150
BAP400 type	Spare parts (For BAP400 type end mill)	Q034	BXD4000R ^{○○○○○} SA ^{○○○○○} A/B	BXD4000 type end mill	M152
BAP400R type	Spare parts (For BAP400 type end mill)	Q034	BXD7000 type	Spare parts (For BXD7000 type end mill)	Q035
BB-G1/8	Banjo bolt	F112	BXD7000 type	Spare parts (For BXD7000 type face mill)	Q029
BC [○]	Clamp set (For BC type cartridge)	N009	BZC400 type	Spare parts (For BZC400 type end mill)	Q035
BC ^{○○}	Clamp set (For BC type cartridge)	N009	BZC400 type	Spare parts (For BZC400 type face mill)	Q029
BCP ^{○○○○}	Shim pin	H013, N009, Q013	C		
BF407R type	Spare parts (For BF407 type face mill)	Q028	C [○]	Clamp set	E026, Q024, Q025
BF-CCGT ^{○○○○○○○} TA2	Insert (Class G tolerance)	B051	C ^{○○○○○} -BLS	MICRO-MINI boring bar (Solid carbide) ...	F119
BF-CCGT ^{○○○○○○○} TS2	Insert (Class G tolerance)	B051	C2JS	Carbide end mill	J099
BF-CNGG ^{○○○○○○○} TA4	Insert (Class G tolerance)	B028	C2LA	Carbide end mill	J106
BF-CNGM ^{○○○○○○○} TA2	Insert (Class G tolerance)	B030	C2LS	Carbide end mill	J100
BF-CNGM ^{○○○○○○○} TS2	Insert (Class G tolerance)	B030	C2MA	Carbide end mill	J104
BF-DCGT ^{○○○○○○○} TA2	Insert (Class G tolerance)	B055	C2MB	Carbide end mill	J252
BF-DCGT ^{○○○○○○○} TS2	Insert (Class G tolerance)	B055	C2MHA	Carbide end mill	J108
BF-DNGG ^{○○○○○○○} TA4	Insert (Class G tolerance)	B033	C2MS	Carbide end mill	J095
BF-DNGM ^{○○○○○○○} TA2	Insert (Class G tolerance)	B035	C2SA	Carbide end mill	J102
BF-DNGM ^{○○○○○○○} TS2	Insert (Class G tolerance)	B035	C2SS	Carbide end mill	J094
BM-CCGT ^{○○○○○○○} TA2	Insert (Class G tolerance)	B051	C3SA	Carbide end mill	J128
BM-CNGM ^{○○○○○○○} TA2	Insert (Class G tolerance)	B030	C3SARB	Carbide end mill	J282
BM-DCGT ^{○○○○○○○} TA2	Insert (Class G tolerance)	B055	C4JC	Carbide end mill	J182
BM-DNGM ^{○○○○○○○} TA2	Insert (Class G tolerance)	B035	C4LATB	Carbide end mill (For impellers)	J356
BMR	BMR bore boring cutter	M260	C4LC	Carbide end mill	J183
BM-TNGM ^{○○○○○○○} TA3	Insert (Class G tolerance)	B040	C4MC	Carbide end mill	J181
BN425 type	Spare parts (For BN425 type face mill) ...	Q028	CA ^{○○○}	Clamp bridge	Q014
BOE type	Spare parts (For BOE type end mill)	Q035	CAS51T	Set screw	Q003
BOE type	Spare parts (For BOE type face mill)	Q028	CBJ/MPR ^{○○○○○} S ^{○○}	CBJP/CBMP type end mill	M250
BOES ^{○○○}	Set bolt	Q009	CBN2XLB	CBN end mill	J236
BPT322	Shim	Q010	CBN2XLRB	CBN end mill	J280
BRE type	Spare parts (For BRE type end mill)	Q035	CB ^{○○○} RS	MICRO-MINI TWIN	E019
BRPOP ^{○○○} A ^{○○○} R	BRP type face mill	M198	CB ^{○○○} RS- ^{○○}	MICRO-MINI TWIN	E019
BRPOP ^{○○○○○○○}	BRP type face mill	M198	CB ^{○○○} RS-B	MICRO-MINI TWIN	E019
BRP ^{○○○} R ^{○○○○○} S ^{○○}	BRP type end mill	M196, M197	CB ^{○○○} RS- ^{○○○} B	MICRO-MINI TWIN	E019
BRS ^{○○○}	Wedge screw	Q003	CBS ^{○○}	Breaker piece	Q016
BSP type	Spare parts (For BSP type end mill)	Q035	CBT ^{○○}	Breaker piece	Q016
BSX type	Spare parts (For BSX type end mill)	Q035	CBT ^{○○○○○}	Breaker piece	Q016
BSX400 type	Spare parts (For BSX400 type face mill) ..	Q029	CCET ^{○○○○○○○} R/L-SN	Insert (Class E tolerance)	A146
BSX500 type	Spare parts (For BSX500 type face mill) ..	Q029	CCET ^{○○○○○○○} R/L-SR	Insert (Class E tolerance)	A145
BTAHR/L ^{○○○○○} -50	Small tools holder (External back turning) ...	D012	CCET ^{○○○○○○○} R/LW-SN	Insert (Class E tolerance)	A146
BTAT605000RX	Insert for external back turning	D012	CCGH ^{○○○○○○○} R/L-F	Insert (Class G tolerance)	A141
BTAT ^{○○○○○○○} MR-B	Insert for external back turning	D012	CCGH ^{○○○○○○○} MR/L-F	Insert (Class G tolerance)	A141
BTAT ^{○○○○○○○} R/L-B	Insert for external back turning	D012	CCGT ^{○○○○○○○} AZ	Insert (Class G tolerance)	A141
BTAT ^{○○○○○○○} SMB	Insert for external back turning	D012	CCGT ^{○○○○○○○} FJ	Insert (Class G tolerance)	A140
BTBT ^{○○○○○○○} MR-SMB	Insert for external back turning	D013	CCGT ^{○○○○○○○} L-F	Insert (Class G tolerance)	A141
BTBT ^{○○○○○○○} R/L	Insert for external back turning	D013	CCGT ^{○○○○○○○} M-FS	Insert (Class G tolerance)	A140
BTBT ^{○○○○○○○} R/L-B	Insert for external back turning	D013	CCGT ^{○○○○○○○} M-FS-P	Insert (Class G tolerance)	A140
			CCGT ^{○○○○○○○} M-LS	Insert (Class G tolerance)	A142

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
CCGT○○○○○○○M-LS-PInsert (Class G tolerance).....	A142	CNMG○○○○○○○GJInsert (Class M tolerance)	A105
CCGT○○○○○○○M-SMGInsert (Class G tolerance).....	A146	CNMG○○○○○○○GKInsert (Class M tolerance)	A103
CCGT○○○○○○○MR/L-FInsert (Class G tolerance).....	A141	CNMG○○○○○○○GMInsert (Class M tolerance)	A103
CCGT○○○○○○○MR/L-SNInsert (Class G tolerance).....	A145	CNMG○○○○○○○LKInsert (Class M tolerance)	A101
CCGT○○○○○○○MR/L-SSInsert (Class G tolerance).....	A143	CNMG○○○○○○○LMInsert (Class M tolerance)	A101
CCGT○○○○○○○R/L-SNInsert (Class G tolerance).....	A145	CNMG○○○○○○○LPInsert (Class M tolerance)	A100
CCGT○○○○○○○R/L-SSInsert (Class G tolerance).....	A143	CNMG○○○○○○○LSInsert (Class M tolerance)	A101
CCGW○○○○○○○Insert (Class G tolerance).....	A147	CNMG○○○○○○○MAInsert (Class M tolerance)	A103
CCGW○○○○○○○FSInsert (Class G tolerance).....	B052	CNMG○○○○○○○MHInsert (Class M tolerance)	A103
CCK○○Clamp bridge	Q014	CNMG○○○○○○○MJInsert (Class M tolerance)	A101
CCMH○○○○○○○MVInsert (Class M tolerance)	A144	CNMG○○○○○○○MKInsert (Class M tolerance)	A102
CCMH○○○○○○○SVInsert (Class M tolerance)	A142	CNMG○○○○○○○MMInsert (Class M tolerance)	A102
CCMT○○○○○○○Insert (Class M tolerance)	A144	CNMG○○○○○○○MPInsert (Class M tolerance)	A102
CCMT○○○○○○○FMInsert (Class M tolerance)	A140	CNMG○○○○○○○MSInsert (Class M tolerance)	A102, A103
CCMT○○○○○○○FPInsert (Class M tolerance)	A140	CNMG○○○○○○○MWInsert (Class M tolerance)	A104
CCMT○○○○○○○FVInsert (Class M tolerance)	A140	CNMG○○○○○○○RKInsert (Class M tolerance)	A105
CCMT○○○○○○○LMInsert (Class M tolerance)	A142	CNMG○○○○○○○RMInsert (Class M tolerance)	A104
CCMT○○○○○○○LPInsert (Class M tolerance)	A141	CNMG○○○○○○○RPInsert (Class M tolerance)	A104
CCMT○○○○○○○LSInsert (Class M tolerance)	A142	CNMG○○○○○○○RSInsert (Class M tolerance)	A105
CCMT○○○○○○○MKInsert (Class M tolerance)	A143	CNMG○○○○○○○SAInsert (Class M tolerance)	A101
CCMT○○○○○○○MMInsert (Class M tolerance)	A143	CNMG○○○○○○○SHInsert (Class M tolerance)	A101
CCMT○○○○○○○MPInsert (Class M tolerance)	A143	CNMG○○○○○○○SWInsert (Class M tolerance)	A101
CCMT○○○○○○○MSInsert (Class M tolerance)	A144	CNMG○○○○○○○SYInsert (Class M tolerance)	A101
CCMT○○○○○○○MWInsert (Class M tolerance)	A144	CNMM○○○○○○○HLInsert (Class M tolerance)	A105
CCMT○○○○○○○SWInsert (Class M tolerance)	A142	CNMM○○○○○○○HMInsert (Class M tolerance)	A106
CCMW○○○○○○○Insert (Class M tolerance)	A147, B052, B072	CNMM○○○○○○○HRInsert (Class M tolerance)	A106
CCMX○○○○○○○EN-○Insert (For DCCC type end mill)	L025, L026, M213	CNMM○○○○○○○HVInsert (Class M tolerance)	A106
CCP○○Shim pin.....	Q013	CNMM○○○○○○○HXInsert (Class M tolerance)	A105
CCTC1Clamp bridge	Q014	CNMM○○○○○○○HZInsert (Class M tolerance)	A106
CE4SRBCeramic radius end mill.....	J338	CNMN○○○○○○○Insert (Class M tolerance)	A137
CE6SRBCeramic radius end mill.....	J338	CPGT○○○○○○○Insert (Class G tolerance).....	A148, B072
CESPR○○○○○S○○CESP type end mill.....	M246	CPGT○○○○○○○R/L-FInsert (Class G tolerance).....	A148
CFM○○○○○○○Shim screw	Q018	CPMH○○○○○○○FVInsert (Class M tolerance)	A148
CFSPR○○○○○S○○CFSP type end mill.....	M246	CPMH○○○○○○○MVInsert (Class M tolerance)	A148
CG○○○○○RS-○○○MICRO-MINI TWIN.....	F132	CPMH○○○○○○○R/L-FInsert (Class M tolerance)	A148
CG○○○○○RS-○○○MICRO-MINI TWIN.....	F132	CPMH○○○○○○○SVInsert (Class M tolerance)	A148
CGSPR○○○○○S○○CGSP type end mill	M246	CPMT○○○○○ZPEN-M○Insert (For PMR type end mill).....	L026, M259
CK○○○Clamp bridge	Q014, Q018	CPMX○○○○○○○Insert (Class M tolerance)	A148
CKW6Clamp bridge	Q015	CPT○○○Side lock plate (For WP holder/M type boring bar) ...	C017, E039, Q022
CMRACarbide end mill.....	J374	CR○Stop ring	G021, G030, H016, Q021, Q025, Q038
CNGA○○○○○○○Insert (Class G tolerance).....	B031	○○○○R-BLSMICRO-MINI boring bar (Solid carbide)	E022, F131
CNGG○○○○○○○FJInsert (Class G tolerance).....	A100	CRN2MBCRN end mill	J230
CNGG○○○○○○○MJInsert (Class G tolerance).....	A102	CRN2MRBCRN end mill	J277
CNGG○○○○○○○PKInsert (Class G tolerance).....	A100	CRN2MSCRN end mill	J084
CNGN○○○○○○○Insert (Class G tolerance).....	B045	CRN2XLCRN end mill	J086
CNMA○○○○○○○Insert (Class M tolerance)	A106, B031, B068	CRN2XLBCRN end mill	J232
CNMG○○○○○○○Insert (Class M tolerance)	A104	CRN2XLRBCRN end mill	J278
CNMG○○○○○○○FHInsert (Class M tolerance)	A100	CRN4JCCRN end mill	J174
CNMG○○○○○○○CInsert (Class M tolerance)	A101	CR○○RS-01MICRO-MINI TWIN.....	E020
CNMG○○○○○○○FPInsert (Class M tolerance)	A100	CR○○RS-01BMICRO-MINI TWIN.....	E020
CNMG○○○○○○○FSInsert (Class M tolerance)	A100	CS○Clamp screw.....	Q003
CNMG○○○○○○○FYInsert (Class M tolerance)	A100	CS○○Shim	Q010
CNMG○○○○○○○GHInsert (Class M tolerance)	A105	CS-1/8-○○○○○Coolant hose kit.....	F112

ORDER NUMBER	PRODUCT NAME	PAGE
CS300590T	Plug	F111
CSAF	Stop screw	Q030
CSBP type	Spare parts (For MC type holder)	Q019
C SCLCR	S type boring bar/MICRO-MINI (Carbide shank)	E016, E030, Q026
C SCZC type	Spare parts (For S type boring bar)	Q026
C SDQCR	S type boring bar (Carbide shank)	E031
C SDUCR/L	S type boring bar (Carbide shank)	E029, Q026
C SDZC type	Spare parts (For S type boring bar)	Q026
CSF401260T	Clamp screw	Q003
CSKPR CA	BC type cartridge	N008
CSKP type	Spare parts (For MC type holder)	Q019
CSRA	Carbide end mill	J372
CSRARB	Carbide end mill	J370
C SSKCR/L type	Spare parts (For S type boring bar)	Q026
CSSN type	Spare parts (For MC type holder)	Q019
CSSPR CA	BC type cartridge	N008
CSSP type	Spare parts (For MC type holder)	Q019
CS	Clamp screw	Q003
C STFCR	S type boring bar (Carbide shank)	E028
CSTN type	Spare parts (For MC type holder)	Q019
C STUCR06	MICRO-DEX boring bar (Carbide shank)	E017
CSVHR/L	Small tools holder (For cam tool posts)	D027
C SVQCR	S type boring bar (Carbide shank)	E032
CSVTB R-B	Insert for external back turning	D028
CSVTB R/L	Insert for external back turning	D028
CSVTBXL	Insert for external back turning	D028
CSVTC R-B	Insert for external cutting off	D028
CSVTC R/L	Insert for external cutting off	D028
CSVTF R/L	Insert for external front turning	D027
CSVTF R/L-B	Insert for external front turning	D027
CSVTFXL	Insert for external front turning, Copying	D027
CSVTG R/L	Insert for grooving	D029
CSVTT RRR/L	Insert for threading	D029
C SVUC type	Spare parts (For S type boring bar (Carbide shank))	Q026
C SWUBR	MICRO-DEX boring bar (Carbide shank)	E016
CT	Shim	Q010
CTAHR1010-120S	Small tools holder (For external cutting off)	D018
CTAHR/L-120	Small tools holder (For external cutting off)	D018
CTAN type	Spare parts (For MC type holder)	Q019
CTAP type	Spare parts (For MC type holder)	Q019
CTAT R-B	Insert for cutting off	D019
CTAT R-B	Insert for cutting off	D019
CTAT RRR/LL	Insert for cutting off	D019
CTBHR/L	Small tools holder (For external cutting off)	D013, D020
CTBT R-B	Insert for cutting off	D020
CTCHR/L	Small tools holder (For external cutting off)	D021
CTCP type	Spare parts (For MC type holder)	Q019
CTCT R-B	Insert for cutting off	D021

ORDER NUMBER	PRODUCT NAME	PAGE
CTDHR/L	Small tools holder (For external cutting off)	D022
CTDT25350V5R-BS	Insert for cutting off	D022
CTDT R-N/R-B	Insert for cutting off	D022
CTEHR/L	Small tools holder (For external cutting off)	D023
CTE	Shim (For MMTE holder)	G019
CTET30350V5R-BS	Insert for cutting off	D023
CTET R-B	Insert for cutting off	D023
CTGN type	Spare parts (For MC type holder)	Q019
CTI	Shim (For MMTI holder)	G028
CTORS-M	MICRO-MINI TWIN	G033
CT	Shim	Q011
CV type	Spare parts (For CV type end mill)	Q036
CV20 type	Spare parts (For CV20 type end mill)	Q036
CWAF10N	Adjusting screw (For NF/NR10000/QF10000 type end mill)	Q030, Q031
CWAF10R	Wedge	M073, Q030, Q031
CWAHX640WN	Wedge	M056
CWAOX445N	Wedge	M061
CWCV20	Wedge	Q036
CWFSTE	Wedge	Q036
CWMSE445R	Wedge	Q030, Q037
CWNSE300TR	Wedge-T	Q031
CWS	Wedge	M265, Q030
CWS42SER/L	Wedge	M267
CWS42SPR/L	Wedge	M263
CWS43SNN	Wedge	Q028
CWSE SN	Wedge-S	M062
CWSE RTR/L	Wedge-T	M062, Q031, Q032
CWSF RTR	Wedge-T	Q028, Q031, Q032
CWSG20SN	Wedge-S	M065
CWSG20TR	Wedge-T	M065
CWSP415TR	Wedge-T	Q029
CWS R/L	Wedge	Q029, Q031
CWTSE300TR	Wedge-T	Q031, Q037

D

DC2SB	Diamond coating end mill	J238
DC2XLB	Diamond coating end mill	J240
DCBSS	Diamond coated drill, For hard brittle materials	P138
DCCCR S	DCCC type end mill	M212
DCET R/L-SN	Insert (Class E tolerance)	A153, A154
DCET R/L-SR	Insert (Class E tolerance)	A152, A153
DCET R/LW-SN	Insert (Class E tolerance)	A154
DCGT AZ	Insert (Class G tolerance)	A149
DCGT M-FS	Insert (Class G tolerance)	A149
DCGT M-FS-P	Insert (Class G tolerance)	A149
DCGT M-LS	Insert (Class G tolerance)	A150
DCGT M-LS-P	Insert (Class G tolerance)	A150
DCGT M-SMG	Insert (Class G tolerance)	A154
DCGT MR/L-SN	Insert (Class G tolerance)	A153
DCGT MR/L-SS	Insert (Class G tolerance)	A151
DCGT R/L-F	Insert (Class G tolerance)	A150

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
DCGT○○○○○○○R/L-SNInsert (Class G tolerance).....	A153
DCGT○○○○○○○R/L-SSInsert (Class G tolerance).....	A151
DCGW○○○○○○○Insert (Class G tolerance).....	A154
DCGW○○○○○○○FSInsert (Class G tolerance).....	B056
DCK○○○○○Clamp bridge C008, C010, C016, C018-C021, E013-E015, H006-H011, Q015	
DCLNR/L○○○○○○○DOUBLE CLAMP holder C008	
DCMT○○○○○○○Insert (Class M tolerance).....	A152
DCMT○○○○○○○-FMInsert (Class M tolerance).....	A149
DCMT○○○○○○○-FPInsert (Class M tolerance).....	A149
DCMT○○○○○○○-FVInsert (Class M tolerance).....	A149
DCMT○○○○○○○-LMInsert (Class M tolerance).....	A150
DCMT○○○○○○○-LPInsert (Class M tolerance).....	A150
DCMT○○○○○○○-LSInsert (Class M tolerance).....	A150
DCMT○○○○○○○-MKInsert (Class M tolerance).....	A151
DCMT○○○○○○○-MMInsert (Class M tolerance).....	A151
DCMT○○○○○○○-MPInsert (Class M tolerance).....	A151
DCMT○○○○○○○-MSInsert (Class M tolerance).....	A152
DCMT○○○○○○○-MVInsert (Class M tolerance).....	A152
DCMT○○○○○○○-SVInsert (Class M tolerance).....	A151
DCMW○○○○○○○Insert (Class M tolerance).....	A154, B056, B073
DCS○Spring C008, C010, C016, C018-C021, E013-E015, H006-H011	
DCSD typeSpare parts (For DCSD type end mill).....	Q036
DCSN typeSpare parts (For DCSN type end mill).....	Q036
DCSSMDiamond coated drill, Medium, For non-ferrous material ...	P136
DCSSSDiamond coated drill, Short, For non-ferrous material ...	P136
DCSVN32Shim Q010	
DC○○○○○TClamp screw H006-H011, Q003	
DCTU typeD type boring head Q024	
DDJNR/L○○○○○○○DOUBLE CLAMP holder C010	
DEGX○○○○○○○R/LInsert (For AL holder).....	A155
DEGX○○○○○○○R/L-FInsert (For AL holder).....	A155, B079
DF2MBDiamond coated end mill J244	
DF2XLBDiamond coated end mill J246	
DF2XLBFDiamond coated end mill J250	
DF3XBDiamond coated end mill J266	
DF4JCDiamond coated end mill J176	
DF4XLDiamond coated end mill J177	
DFC4JCDFC type end mill J180	
DFCJRTDFC type end mill J195	
DFPSRBDiamond coated end mill J335	
DGHR/L typeSpare parts (For DG type holder).....	Q023
DGHN○○○Wrench (For UG type holder) Q023	
DGK3R/LClamp bridge Q023	
DGS51Clamp screw (For HSK-T-DG).....	Q023
DKS○Clamp screw Q003	
DLC2MADLC coated end mill J089	
DLC2MBDLC coated end mill J242	
DLE○○○○S○○○P○○○Leading drills P012	
DNGA○○○○○○○Insert (Class G tolerance).....	A113, B036, B068
DNGG○○○○○○○-FJInsert (Class G tolerance).....	A107

ORDER NUMBER	PRODUCT NAME	PAGE
DNGG○○○○○○○-PKInsert (Class G tolerance).....	A107
DNGG○○○○○○○-R/LInsert (Class G tolerance).....	A111
DNGM○○○○○○○-MJInsert (Class G tolerance).....	A109
DNGN○○○○○○○Insert (Class G tolerance).....	B045
DNMA○○○○○○○Insert (Class M tolerance).....	A113
DNMG○○○○○○○Insert (Class M tolerance).....	A111
DNMG○○○○○○○-CInsert (Class M tolerance).....	A109
DNMG○○○○○○○-FHInsert (Class M tolerance).....	A107
DNMG○○○○○○○-FPInsert (Class M tolerance).....	A107
DNMG○○○○○○○-FSInsert (Class M tolerance).....	A107
DNMG○○○○○○○-FYInsert (Class M tolerance).....	A107
DNMG○○○○○○○-GHInsert (Class M tolerance).....	A112
DNMG○○○○○○○-GJInsert (Class M tolerance).....	A112
DNMG○○○○○○○-GKInsert (Class M tolerance).....	A110
DNMG○○○○○○○-GMInsert (Class M tolerance).....	A111
DNMG○○○○○○○-LKInsert (Class M tolerance).....	A108
DNMG○○○○○○○-LMInsert (Class M tolerance).....	A108
DNMG○○○○○○○-LPInsert (Class M tolerance).....	A108
DNMG○○○○○○○-LSInsert (Class M tolerance).....	A108
DNMG○○○○○○○-MAInsert (Class M tolerance).....	A111
DNMG○○○○○○○-MHInsert (Class M tolerance).....	A111
DNMG○○○○○○○-MJInsert (Class M tolerance).....	A109
DNMG○○○○○○○-MKInsert (Class M tolerance).....	A110
DNMG○○○○○○○-MMInsert (Class M tolerance).....	A110
DNMG○○○○○○○-MPInsert (Class M tolerance).....	A109
DNMG○○○○○○○-MSInsert (Class M tolerance).....	A110
DNMG○○○○○○○-RKInsert (Class M tolerance).....	A112
DNMG○○○○○○○-RMInsert (Class M tolerance).....	A112
DNMG○○○○○○○-RPInsert (Class M tolerance).....	A112
DNMG○○○○○○○-RSInsert (Class M tolerance).....	A112
DNMG○○○○○○○-SAInsert (Class M tolerance).....	A109
DNMG○○○○○○○-SHInsert (Class M tolerance).....	A108
DNMG○○○○○○○-SYInsert (Class M tolerance).....	A109
DNMM○○○○○○○-HLInsert (Class M tolerance).....	A113
DNMM○○○○○○○-HZInsert (Class M tolerance).....	A113
DNMX○○○○○○○-MWInsert (Class M tolerance).....	A111
DNMX○○○○○○○-SWInsert (Class M tolerance).....	A109
DPCL○○○RD type boring head E041, Q024	
DPDH○○○RD type boring head E041, Q024	
DPDU○○○RD type boring head E040, Q024	
DPDZ typeSpare parts (For D type boring head).....	Q024
DPSK typeSpare parts (For D type boring head).....	Q024
DPT2○○○RD type boring head G038, Q024	
DPT4○○○RD type boring head F126, Q024	
DPTF○○○RD type boring head E040, Q024	
DPT○○○RD type boring head F126	
DPVP○○○RD type boring head E042, Q024	
DTGNR/L○○○○○○○DOUBLE CLAMP holder C016	
DVJNR/L○○○○○○○DOUBLE CLAMP holder C018	
DVPNR/L○○○○○○○DOUBLE CLAMP holder C020	
DVVNN○○○○○○○DOUBLE CLAMP holder C019	
DWLNRL○○○○○○○DOUBLE CLAMP holder C021	
E		
E○○Stop ring C018-C020, E042, F126, G038	
E404 typeSpare parts (For E404 type face mill).....	Q029

ORDER NUMBER	PRODUCT NAME	PAGE
ECMP type	Spare parts (For ECMP type end mill).....	Q036
EGHR type	Spare parts (For EG holder).....	Q018
EGS	Clamp screw.....	Q004, Q018
EPSS	Straight shank drill, Plate pal.....	P192
ESBN type	Spare parts (For ML holder).....	Q020
E	Spare parts (For COBRA carbide shank boring bar).....	Q024
ESDN type	Spare parts (For ML holder).....	Q020
ESEN type	Spare parts (For ML holder).....	Q020
ESKN type	Spare parts (For ML holder).....	Q020
ESS42	Shim.....	Q010
EST	Shim.....	Q010
E	Spare parts (For COBRA boring bar).....	Q024
ETAN type	Spare parts (For ML holder).....	Q020
ETENN type	Spare parts (For ML holder).....	Q020
ETFN type	Spare parts (For ML holder).....	Q020
ETHR type	Spare parts (For ET holder).....	Q018
ETJN type	Spare parts (For SL holder).....	Q021
ETNN type	Spare parts (For SL holder).....	Q021
ETQN type	Spare parts (For SL holder).....	Q021
ETXN type	Spare parts (For ML holder).....	Q020

F

FA	Boring unit (Angular type).....	N012
FA-FAPN	Boring unit (Angular type).....	N012
FA-FASC	Boring unit (Angular type).....	N012
FA-FASP	Boring unit (Angular type).....	N012
FAPN	Cartridge (For boring unit).....	N012
FASC	Cartridge (For boring unit).....	N012
FASP	Cartridge (For boring unit).....	N012
FBE2 type	Spare parts (For FBE2 type end mill).....	Q039
FBP415 type	Spare parts (For FBP415 type face mill).....	Q029
FC400890T	Clamp screw.....	Q004
FCDG4 type	Spare parts (For FCDG4 type boring bar).....	Q025
FCL5 type	Spare parts (For FCL5 type boring bar).....	Q025
FCSK type	Spare parts (For FCSK type boring bar).....	Q025
FCTU	FCTU type boring bar.....	E026, Q025
FE404R/L	FE404 type face mill.....	M266
FF3000 type	Spare parts (For FF3000 type end mill).....	Q036
FF3000R	FF3000 type face mill.....	M074
FFAWR	Adjusting wedge (For FF3000 type face mill).....	M074
FFCSR	Cartridge (For FF3000 type face mill).....	M074
FFL	Lever (For FF3000 type face mill).....	M074
FFLB	Lever screw (For FF3000 type face mill).....	M074
FFP	Lock pin (For FF3000 type face mill).....	M074, Q036
FFRP	Radial spring (For FF3000 type face mill).....	M074
FFSS	Shim (For FF3000 type face mill).....	M074, Q036
FFW	Washer (For FF3000 type face mill).....	M074
FMAX	FMAX type face mill.....	M066
FMAX	FMAX type face mill.....	M068
FMAXR	FMAX type face mill.....	M067
FN548 type	Spare parts (For FN548 type face mill).....	Q030

ORDER NUMBER	PRODUCT NAME	PAGE
FP490R/L	FP490 type face mill.....	M262
FP590R/L	FP590 type face mill.....	M264
FSCLC	DIMPLE BAR (Carbide shank).....	E006
FSCLC	DIMPLE BAR (Carbide shank).....	E006
FSCLC	DIMPLE BAR.....	E006
FSCLP	DIMPLE BAR (Carbide shank).....	E006
FSCLP	DIMPLE BAR (Carbide shank).....	E006
FSCLP	DIMPLE BAR.....	E006
FSDQC	DIMPLE BAR (Carbide shank).....	E009
FSDQC	DIMPLE BAR.....	E009
FSDUC	DIMPLE BAR (Carbide shank).....	E008
FSDUC	DIMPLE BAR.....	E008
FSL5	FSL5 type boring bar.....	F124, G036
FSTE type	Spare parts (For FSTE type end mill).....	Q036
FSTUP	DIMPLE BAR (Carbide shank).....	E007
FSTUP	DIMPLE BAR (Carbide shank).....	E007
FSTUP	DIMPLE BAR.....	E007
FSTU	FSTU type boring bar.....	E025
FSVJB	DIMPLE BAR.....	E012
FSVJC	DIMPLE BAR.....	E012
FSVPB	DIMPLE BAR.....	E011
FSVPC	DIMPLE BAR.....	E011
FSVUB	DIMPLE BAR.....	E011
FSVUC	DIMPLE BAR.....	E011
FSWL	FSWL type boring bar.....	E027
FSWUB	DIMPLE BAR (Carbide shank).....	E010
FSWUB	DIMPLE BAR (Carbide shank).....	E010
FSWUB	DIMPLE BAR.....	E010
FSWUP	DIMPLE BAR (Carbide shank).....	E010
FSWUP	DIMPLE BAR (Carbide shank).....	E010
FSWUP	DIMPLE BAR.....	E010
FV	Boring unit (Vertical type).....	N012
FV-FVFN	Boring unit (Vertical type).....	N012
FV-FVSC	Boring unit (Vertical type).....	N012
FV-FVSP	Boring unit (Vertical type).....	N012
FVFN	Cartridge (For boring unit).....	N012
FVSC	Cartridge (For boring unit).....	N012
FVSP	Cartridge (For boring unit).....	N012

G

GBE	GBE type end mill.....	J376
GCMT	Insert (For TAF type drill).....	L056, P246
GDCN2004PDFR3	Insert (For NF10000/QF10000 type cutter).....	L052, M073
GDCN2004PDR	Insert (For AF10000 type cutter).....	L052
GDCN2004ZDTR1	Insert (For NR10000 type cutter).....	L052
GOER1408PXFR2-8	Insert (For FMAX type cutter).....	L052, M069
GOER	Insert (For FMAX type cutter).....	L052, M069
GOER	Insert (For FMAX type cutter).....	L052, M069
GPMT	Insert (For TAF type drill).....	L056, P246
GSD	Straight shank drill, TiN.....	P174
GTD	Taper shank drill, TiN.....	P193
GT	Small tools holder (External grooving).....	D016
GTTD	Taper shank drill, TiN, For steel frame.....	P205
GT	Insert (Blank).....	D017
GT	Insert (For small tools holder).....	D017

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
GT0T00000000R/L-UInsert (For small tools holder).....	D016
GT0T00000000R-VTInsert (For small tools holder).....	D017
GW1M00000000N-00Inserts for GW blade (For grooving and cutting off) ...	F112
GW1M00000000R/L05-GMInserts for GW blade (For cutting off)	F112
GW04005FPlug screw	F110
GWB00NA2-000GW blade.....	F110
GWCW0Wedge	F111
GWSLStraight shank drill, TiN, Extra long	P186
GWSSStraight shank drill, TiN, Convolute flute... ..	P184
GWTBN0000-B00Tool block (For GW blade).....	F111
GWTBN0000-B00-CTool block (For GW blade).....	F111
GWTSTaper shank drill, TiN, Convolute flute.....	P204
GWW000000Washer	F110
GWY39LWrench	F110
GY1B00000000NInsert (For GY holder).....	F012
GY1G00000000N-GFGSInsert (For GY holder).....	B066, F011
GY1M00000000N-GMInsert (For GY holder).....	F010
GY1M00000000R/L05-GMInsert (For GY holder).....	F010
GY2B00000000NInsert (For GY holder).....	F012
GY2G00000000N-MFInsert (For GY holder).....	F011
GY2M00000000N-BMInsert (For GY holder).....	F012
GY2M00000000N-GMInsert (For GY holder).....	F010
GY2M00000000N-GSInsert (For GY holder).....	F010
GY2M00000000N-GUInsert (For GY holder).....	F010
GY2M00000000N-MMInsert (For GY holder).....	F012
GY2M00000000N-MSInsert (For GY holder).....	F012
GY2M00000000R/L05-GMInsert (For GY holder).....	F011
GY05016SClamp screw	F081-F087, Q004
GY06013MClamp screw	F017-F087, Q004
GYAR/L000090-000GY holder	F080-F087
GYDR000090-M00R/LGY holder	F080-F087
GYHR/L000000-M00R/LGY holder	F016-F027, F038-F069
GYHR/L00000050-M00R/LGY holder	F026-F037
GYHR/L00000090-M00R/LGY holder	F030-F035, F070-F079
GYM00R/L0-000Modular blade.....	F016-F035, F080-F087
GYM00R/L0-000-000Modular blade.....	F038-F079
GYM00R/LC-0005Modular blade.....	F036
GYPR/L00000000-K25GY holder	F028-F029
GYQR/L00000000-000GY holder	F016-F027
GYSR/L000000JX00-000GY holder	F014-F015

H

H63TH-A000DCLNR/L12HSK DCLN type holder.....	H008
H63TH-B000-00HSK boring bar holder.....	H021
H63TH-DCLNL-L12-3HSK DCLN type holder.....	H008
H63TH-DCLNR/L-DX12HSK DCLN type holder.....	H006
H63TH-DCMNN-012HSK DCMN type holder.....	H007
H63TH-DDJNL-L15-3HSK DDJN type holder.....	H011
H63TH-DDJNR/L-DX15HSK DDJN type holder.....	H009
H63TH-DDNNN-015HSK DDNN type holder.....	H010
H63TH-DGHR/L typeSpare parts (For HSK-DG)	Q023
H63TH-EN2525R/L-115HSK boring bar holder	H020
H63TH-EV2020R/L-105-3HSK boring bar holder	H021
H63TH-EV2525R/L-112HSK boring bar holder	H019
H63TH-MGHR/L-DX4300HSK MG type holder.....	H014

ORDER NUMBER	PRODUCT NAME	PAGE
H63TH-MMTENR-016HSK MMTE type holder.....	H016
H63TH-MMTER-DX16HSK MMTE type holder.....	H016
H63TH-MTHR/L-DX43HSK MTH type holder.....	H017
H63TH-PCLNR/L-DX12HSK PCLN type holder.....	H006
H63TH-PCMNN-012HSK PCMN type holder.....	H007
H63TH-PDJNR/L-DX15HSK PDJN type holder.....	H009
H63TH-PDNNN-015HSK PDNN type holder	H010
H63TH-PRDCN-012HSK PRDC type holder	H012
H63TH-PRGCR/L-DX12HSK PRGC type holder	H012
H63TH-SVPBR/L-DX16HSK SVPB type holder.....	H013
H63TH-SVBN-016HSK SVVB type holder.....	H013
H100TH-B000-000HSK boring bar holder.....	H022
H100TH-EN3232R/L-130HSK boring bar holder.....	H020
H100TH-EV3232R/L-180HSK boring bar holder.....	H019
HBH08000Set bolt	N007, N009, N011
HDS000000Clamp screw.....	Q009
HFC000000Shim pin.....	G019, G028, H016
HFF06015Clamp screw.....	Q004
HFF08043HClamp screw.....	Q009
HGJ-PT1/8Plug	F111
HGM-PT00Plug	E035-E039, H007-H012
HKY000Wrench	Q002
HLS0Lever spring.....	M252, N007, N013
HNMX1206E000-RInsert (For BMR type boring cutter).....	L026, M261
HOSE-1/8-000Coolant hose	F112
HP0Spring	M074
HP00Clamp pin	E035-E038
HR00Spanner	N013
HS00Clamp screw.....	Q004
HSC000000Clamp screw.....	Q002, Q009
HSC05016HWReamer adjustment screw.....	N002
HSC08025HSet bolt (For AHX440S type cutter)	M039
HSC000000HSet bolt	Q009
HSCX000000HSet bolt (For FMAX type cutter).....	M067, Q009
HSD04004H00Coolant nozzle (For VFX5/6 type cutter).....	M221, M225
HSD05004SPlug (For GW type blade).....	F123
HSK-00000MHSK type taper tool number	N027
HSP05008CLock screw.....	Q004
HSP08014Lock screw.....	F138, G038
HSS000000GBalance adjustment screw (For FMAX type cutter)...	M066-M068
HSS040000Clamp screw.....	E018, F122, G035
HSS03005Screw (For P type boring bar)	E035-E038
HSS05005Balance adjustment screw (For V10000 type cutter) ...	M070
HSS000000Clamp screw.....	H020-H022, Q002
HVF06-HSK63A000A0Valve finisher	N002
HY0Unit screw	N013, Q004
HY-A1Unit screw	N013, Q004
HY-V1Unit screw	N013, Q004

I

iMX-B2SIndexable head end mill.....	K022
iMX-B3FVIndexable head end mill.....	K024

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
iMX-B4HVIndexable head end mill.....	K026	KSOSClamp screw.....	Q004
iMX-B4HV-EIndexable head end mill.....	K027	KSS2Large adjustment screw.....	M066-M068
iMX-B4SIndexable head end mill.....	K023	KTDTaper shank drill, Cobalt HSS.....	P198
iMX-B6HVIndexable head end mill.....	K030	KYOSpanner.....	Q020
iMX-C3AIndexable head end mill.....	K046	L		
iMX-C4FD-CIndexable head end mill.....	K042	LDCN190412R/LInsert (For AF5000 type face mill).....	L052
iMX-C4FVIndexable head end mill.....	K044	LK1Clamp bridge.....	Q015
iMX-C4HVIndexable head end mill.....	K032	LLCLOOClamp lever.....	Q013
iMX-C4HV-SIndexable head end mill.....	K034	LLCSOOClamp screw.....	Q005
iMX-C6HVIndexable head end mill.....	K040	LLCSOOSClamp screw.....	Q005
iMX-C8T-CIndexable head end mill.....	K049	LLPOShim pin.....	Q013
iMX-C10HVIndexable head end mill.....	K040	LLRRadial screw.....	N007, Q004
iMX-C10T-CIndexable head end mill.....	K049	LLSCNOShim.....	Q010
iMX-C12HVIndexable head end mill.....	K040	LLSCPOShim.....	Q010
iMX-C12T-CIndexable head end mill.....	K049	LLSDNOShim.....	Q010
iMX-C15T-CIndexable head end mill.....	K049	LLSDPOShim.....	Q010
iMX-CH3LIndexable head end mill.....	K050	LLSRNOShim.....	Q010
iMX-CH6VIndexable head end mill.....	K052	LLSSNOShim.....	Q010
iMXOOOOOOOOOOOCLOOOCIndexable head end mill.....	K054	LLSSP42Shim.....	Q010
iMXOOOOOOOOOOOCLOOSIndexable head end mill.....	K055	LLSTE32Shim.....	Q011
iMX-R4FIndexable head end mill.....	K020	LLSTNOShim.....	Q011
iMX-S3AIndexable head end mill.....	K017	LLSTPOShim.....	Q011
iMX-S3HVIndexable head end mill.....	K006	LLSWNOShim.....	Q011
iMX-S4HVIndexable head end mill.....	K010	LLSWPOShim.....	Q011
iMX-S4HV-SIndexable head end mill.....	K011	LNGU1308OPNEOInsert (For VAS400 type side cutter).....	L028, M091
iMXOO-WRWrench (For indexable head end mill).....	Q002	LNGU1710OPNEORInsert (For VAS500 type side cutter).....	L029, M093
J					
JDMTOOOOOOZZDER-JLInsert (For AJX/PMC type cutter)....	L026, M167	LOGUOOOOOOPNORInsert (For VPX200/300 type cutter).....	L030, M113, M125
JDMTOOOOOOZZSR-STInsert (For AJX type cutter).....	L026, M167, M255	LRBOOInsert for brazed tool holder (MITSUBISHI standard) ...	I004
JFSOOOOOJUST FIT SLEEVE (JFS).....	P248	LSOClamp screw.....	Q005
JOMTOOOOOOZZER-JLInsert (For AJX type cutter).....	L026, M167	LSOOClamp screw.....	Q005
JOMTOOOOOOZZSR-JMInsert (For AJX/PMC type cutter).....	L026, M167, M255	LS10TSClamp screw.....	Q005
JOMU140715ZZER-MInsert (For WJX type cutter).....	L027, M175	LS24HClamp screw.....	Q005
JOMWOOOOOZZSR-FTInsert (For AJX/PMC type cutter).....	L026, M167, M255	LSDStraight shank drill, Extra long.....	P189
JPMTOOOOOOOInsert (For TAB/CBJP type end mill).....	L027, M251	LSE445 typeSpare parts (For LSE445 type face mill).....	Q030
JPMXOOOOOOOInsert (For SPX type end mill).....	L027, M217	LSOOOOTClamp screw.....	Q005
JSSOShim screw.....	Q004	LSOOTClamp screw.....	Q005
K			M		
KGBNOOOTool block (For UG holder).....	F115, Q023	MAEOOOOMBMAE type drill (External coolant).....	P087
KGC1Clamp bridge.....	F115, Q015	MASOOOOLB/MBMAS type drill (Internal coolant).....	P083
KGTONInsert (For UG holder).....	F115	MBAOOOOHClamp screw.....	Q009
KGTOR/LInsert (For UG holder).....	F115	MCAHOOOOXOOSOODrill for CFRP+Al.....	P095
KKCR/L typeSpare parts (For MH holder).....	Q020	MCAOOOXOOSOODrill for CFRP+Al.....	P091
KSAxial screw.....	M070, N007, N009, N011, Q004	MCCHOOOOXOOSOODrill for CFRP.....	P094
KSPre-set screw.....	N015, Q004	MCCOOOXOOSOODrill for CFRP.....	P090
KSDStraight shank drill, Cobalt HSS, For stainless steel... P182		MCLNRDOUBLE CLAMP holder (For heavy cutting)....	C009
KSMGRKSMG type end mill.....	M252	MCTOOOXOOSOODrill for CFRP+Ti.....	P092
KSN2Micro adjustment nut.....	M066-M068	MCWOOOXOOSOODrill for CFRP and stack material.....	P093

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
MES	Spring C017, E039, F116, G024, H014, H017, Q019-Q020, Q022-Q023, Q026		MPMHVRB	MS Plus end mill.....	J284
MFE	Solid carbide flat bottom drill P015		MPMT	Insert (For CBMP/ECMP/TAB type end mill).....	L031, M251
MG2R/L type	Spare parts (For MG2 type holder).....	Q019	MPMW	Insert (For TSMP type end mill).....	L031, M249
MG200 type	Spare parts (For MG200 type end mill)....	Q037	MPMX120412	Insert (For SPX type end mill).....	L032, M217
MG245 type	Spare parts (For MG245 type end mill)....	Q037	MPXLRB	MS Plus end mill.....	J288
MG300 type	Spare parts (For MG300 type end mill)....	Q037	MQS	MQS type drill (Internal coolant).....	P050
MG300 type	Spare parts (For MG300 type face mill) ...	Q030	MR	HSS end mill.....	J408
MG345 type	Spare parts (For MG345 type end mill)....	Q037	MS2ES	MSTAR end mill.....	J066
MG345 type	Spare parts (For MG345 type face mill) ...	Q030	MS2JS	MSTAR end mill.....	J054
MG400 type	Spare parts (For MG400 type face mill) ...	Q030	MS2LS	MSTAR end mill.....	J056
MG445 type	Spare parts (For MG445 type face mill) ...	Q030	MS2MD	MSTAR end mill.....	J052
MGD	Driver.....	P131	MS2MRB	MSTAR end mill.....	J274
MGEW	Insert (For MG245/345/445 type cutter).....	L031	MS2MS	MSTAR end mill.....	J049
MGEW	Insert (For MG200/300/400 type cutter).....	L031	MS2SS	MSTAR end mill.....	J048
MGHR/L	MG holder.....	F116, Q019	MS2XL	MSTAR end mill.....	J058
MGP445 type	Spare parts (For MGP445 type face mill).....	Q030	MS2XL6	MSTAR end mill.....	J062
MGS6	Clamp screw.....	Q005	MS3ES	MSTAR end mill.....	J114
MGS	Solid gun drill.....	P130	MS4EC	MSTAR end mill.....	J152
MGTL	Insert (For D type boring head/KSMG type end mill) ...	F127, M253	MS4JC	MSTAR end mill.....	J146
MGTR	CBN Insert (For grooving).....	B067	MS4MC	MSTAR end mill.....	J144
MGTR/L	Insert (For MG holder).....	F117, H015	MS4MRB	MSTAR end mill.....	J294
MHK5NR/L	Clamp bridge.....	Q015	MS4SC	MSTAR end mill.....	J142
MHS	MHS type drill (Internal coolant).....	P064	MS4XL	MSTAR end mill.....	J148
MHS	Shim.....	Q011	MSBNR	DOUBLE CLAMP holder (For heavy cutting)	C012
MHT1	Clamp screw.....	Q005	MSCN63	Shim.....	C009, Q011
MK1K	Anti-seize lubricant.....	Q017	MSD445 type	Spare parts (For MSD445 type face mill).....	Q030
MK1KS	Anti-seize lubricant.....	Q017	MSE445 type	Spare parts (For MSE445 type end mill).....	Q037
MLCP42	Shim.....	Q011	MSE445 type	Spare parts (For MSE445 type face mill).....	Q030
MLDP42	Shim.....	Q011	MSE	MSE type drill.....	P097
MLG	Insert (For FSL5 type boring bar).....	F125, G037	MSJHD	MSTAR end mill.....	J140
MLSP42	Shim.....	Q011	MSMHD	MSTAR end mill.....	J137
MLT	Insert (For FSL5 type boring bar).....	F125, G037	MSMHZD	MSTAR end mill.....	J112
MLTP32	Shim.....	Q011	MSP0300SB	MSP type starting drill.....	P096
MMS	MMS type drill (Internal coolant).....	P057	MSSHD	MSTAR end mill.....	J136
MMT	Insert (For MMTE holder).....	G020, G021, G022, G023	MSSN63	Shim.....	C012, C014, Q011
MMTER	MMTE holder.....	G019	MSSNR	DOUBLE CLAMP holder (For heavy cutting)	C014
MMT	Insert (For MMTI boring bar).....	G029, G030, G031, G032	MT1R/L	MT1 type holder.....	G024
MMTIR	MMTI boring bar.....	G028	MT2R/L type	Spare parts (For MT2 type holder).....	Q020
MNS	MNS type drill (Internal coolant).....	P076	MTENN type	Spare parts (For WP holder).....	Q022
MNS	MNS type drill (Internal coolant).....	P076	MTHR/L	MT holder.....	G024
MP2MB	MS Plus end mill.....	J198	MTJNR/L	WP holder.....	C017, Q022
MP2SB	MS Plus end mill.....	J197	MTK	Clamp bridge ... F116, G024, H014, H017, Q015	
MP2SDB	MS Plus end mill.....	J200	MTNN type	Spare parts (For WP holder).....	Q022
MP2SSB	MS Plus end mill.....	J196	MTQN type	Spare parts (For WP holder).....	Q022
MP2XLB	MS Plus end mill.....	J202	MTTR/L	Insert (For MT holder/D type boring head).....	G025, G039, H018
MP3XB	MS Plus end mill.....	J254	MVE	MVE type drill (External coolant).....	P042
MP6	Shim.....	C014, Q013	MVS	MVS type drill (Internal coolant).....	P020, P022, P024
MPJHV	MS Plus end mill.....	J134	MVS	MVS type drill (Internal coolant).....	P020
MPMHV	MS Plus end mill.....	J130			

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
MVX0000X0F00.....	MVX type drill (Internal coolant)	P230	NP-CNGA00000000FS4.....	Insert (Class G tolerance).....	B028
MWLN type.....	Spare parts (For WP holder)	Q022	NP-CNGA00000000FSWS2.....	Insert (Class G tolerance).....	B030
MWS0000LB/MB/SB/XB.....	MWS type drill (Internal coolant)	P100	NP-CNGA00000000FSWS4.....	Insert (Class G tolerance).....	B028
MWS0000X8DB.....	MWS type drill (Internal coolant)	P104	NP-CNGA00000000G2.....	Insert (Class G tolerance).....	B029
MWS0000X00DB.....	MWS type drill (Internal coolant)	P102	NP-CNGA00000000GA2.....	Insert (Class G tolerance).....	B029
MZE0000MA/SA/SB.....	MZE type drill (External coolant)	P122	NP-CNGA00000000GA4.....	Insert (Class G tolerance).....	B028
N			NP-CNGA00000000GAWS2.....	Insert (Class G tolerance).....	B030
NA0 type.....	Spare parts (For angular type boring unit).....	Q027	NP-CNGA00000000GAWS4.....	Insert (Class G tolerance).....	B028
NAPN00 type.....	Spare parts (For cartridge (Boring unit)).....	Q027	NP-CNGA00000000GBWL2.....	Insert (Class G tolerance).....	B030
NASP00 type.....	Spare parts (For cartridge)	Q027	NP-CNGA00000000GH2.....	Insert (Class G tolerance).....	B029
NF10000R000000.....	NF10000 type face mill.....	M072	NP-CNGA00000000GH4.....	Insert (Class G tolerance).....	B028
NFT type.....	Spare parts (For F type boring bar).....	Q025	NP-CNGA00000000GN2.....	Insert (Class G tolerance).....	B029
NKY15S.....	Wrench.....		NP-CNGA00000000GN4.....	Insert (Class G tolerance).....	B028
	D012-D014, D016, D018, D024, D030		NP-CNGA00000000GS2.....	Insert (Class G tolerance).....	B029
NNMU200600ZE000.....	Insert (For AHX640S/640W type cutter).....	L033, M056	NP-CNGA00000000GS4.....	Insert (Class G tolerance).....	B028
NNMU200700ZE000.....	Insert (For AHX640S type cutter)	L032, M048	NP-CNGA00000000GSWS2.....	Insert (Class G tolerance).....	B030
NNMU130508ZE000.....	Insert (For AHX440S type cutter)	L032, M040	NP-CNGA00000000GSWS4.....	Insert (Class G tolerance).....	B028
NNMU130532ZEN00.....	Insert (For AHX440S/475S type cutter).....	L032, M040, M044	NP-CNGA00000000SE2.....	Insert (Class G tolerance).....	B029
NNMU200608ZEN00.....	Insert (For AHX640W type cutter)	L033, M048, M056	NP-CNGA00000000SF2.....	Insert (Class G tolerance).....	B029
NP-CCGB000000GA2.....	Insert (Class G tolerance).....	B049	NP-CNGA00000000T2.....	Insert (Class G tolerance).....	B029
NP-CCGW000000F.....	Insert (Class G tolerance).....	B051	NP-CNGA00000000TA2.....	Insert (Class G tolerance).....	B029
NP-CCGW000000FA.....	Insert (Class G tolerance).....	B051	NP-CNGA00000000TA4.....	Insert (Class G tolerance).....	B028
NP-CCGW000000FA2.....	Insert (Class G tolerance).....	B050	NP-CNGA00000000TH2.....	Insert (Class G tolerance).....	B029
NP-CCGW000000FBWL2.....	Insert (Class G tolerance).....	B050	NP-CNGA00000000TH4.....	Insert (Class G tolerance).....	B028
NP-CCGW000000FS.....	Insert (Class G tolerance).....	B051	NP-CNGA00000000TS2.....	Insert (Class G tolerance).....	B029
NP-CCGW000000FS2.....	Insert (Class G tolerance).....	B049	NP-CNGA00000000TS4.....	Insert (Class G tolerance).....	B028
NP-CCGW000000FSWS2.....	Insert (Class G tolerance).....	B050	NP-CNMA000000F.....	Insert (Class M tolerance)	B031
NP-CCGW000000G.....	Insert (Class G tolerance).....	B051, B052	NP-CNMA000000G.....	Insert (Class M tolerance)	B031
NP-CCGW000000G2.....	Insert (Class G tolerance).....	B050	NP-CNMA000000GS.....	Insert (Class M tolerance)	B031
NP-CCGW000000GA2.....	Insert (Class G tolerance).....	B049	NP-CNMA000000T.....	Insert (Class M tolerance)	B031
NP-CCGW000000GAWS2.....	Insert (Class G tolerance).....	B050	NP-CNMM000000R/L-F.....	Insert (Class M tolerance)	B068
NP-CCGW000000GBWL2.....	Insert (Class G tolerance).....	B050	NP-CPGB000000FS2.....	Insert (Class G tolerance).....	B053
NP-CCGW000000GH2.....	Insert (Class G tolerance).....	B049	NP-CPGB000000GA2.....	Insert (Class G tolerance).....	B053
NP-CCGW000000GN2.....	Insert (Class G tolerance).....	B050	NP-CPGB000000GS2.....	Insert (Class G tolerance).....	B053
NP-CCGW000000GN2.....	Insert (Class G tolerance).....	B050	NP-CPGB000000SE2.....	Insert (Class G tolerance).....	B053
NP-CCGW000000GS.....	Insert (Class G tolerance).....	B051	NP-CPGB000000TA2.....	Insert (Class G tolerance).....	B053
NP-CCGW000000GS2.....	Insert (Class G tolerance).....	B049	NP-CPMB000000G.....	Insert (Class M tolerance)	B053
NP-CCGW000000GSWS2.....	Insert (Class G tolerance).....	B050	NP-CPMH000000.....	Insert (Class M tolerance)	B072
NP-CCGW000000SE2.....	Insert (Class G tolerance).....	B050	NP-DCGW000000F.....	Insert (Class G tolerance).....	B056
NP-CCGW000000SF2.....	Insert (Class G tolerance).....	B050	NP-DCGW000000FA2.....	Insert (Class G tolerance).....	B054
NP-CCGW000000T.....	Insert (Class G tolerance).....	B052	NP-DCGW000000FS2.....	Insert (Class G tolerance).....	B054
NP-CCGW000000TA2.....	Insert (Class G tolerance).....	B049	NP-DCGW000000G.....	Insert (Class G tolerance).....	B056
NP-CCGW000000TH2.....	Insert (Class G tolerance).....	B049	NP-DCGW000000G2.....	Insert (Class G tolerance).....	B054
NP-CCGW000000TS2.....	Insert (Class G tolerance).....	B049	NP-DCGW000000GA2.....	Insert (Class G tolerance).....	B054
NP-CCMB000000G.....	Insert (Class M tolerance)	B051	NP-DCGW000000GH2.....	Insert (Class G tolerance).....	B054
NP-CCMH000000.....	Insert (Class M tolerance)	B072	NP-DCGW000000GN2.....	Insert (Class G tolerance).....	B054
NP-CCMW000000.....	Insert (Class M tolerance)	B072	NP-DCGW000000GS.....	Insert (Class G tolerance).....	B056
NP-CCMW000000F.....	Insert (Class M tolerance)	B052	NP-DCGW000000GS2.....	Insert (Class G tolerance).....	B054
NP-CNGA000000FBWL2.....	Insert (Class G tolerance).....	B030	NP-DCGW000000R/L-F.....	Insert (Class M tolerance)	B073
NP-CNGA000000FS2.....	Insert (Class G tolerance).....	B029	NP-DCMT000000R/L-F.....	Insert (Class M tolerance)	B073
			NP-DCMW000000G.....	Insert (Class M tolerance)	B056

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
NP-DNGA	FS2	B033
NP-DNGA	FS4	B032
NP-DNGA	G2	B034
NP-DNGA	GA2	B033
NP-DNGA	GA4	B032
NP-DNGA	GAWS2JR/L	B035
NP-DNGA	GH2	B033
NP-DNGA	GH4	B032
NP-DNGA	GN2	B034
NP-DNGA	GN4	B033
NP-DNGA	GS2	B033
NP-DNGA	GS4	B032
NP-DNGA	GSWS2JR/L	B035
NP-DNGA	SE2	B034
NP-DNGA	SF2	B034
NP-DNGA	T2	B034
NP-DNGA	TA2	B034
NP-DNGA	TA4	B032
NP-DNGA	TH2	B034
NP-DNGA	TH4	B032, B033
NP-DNGA	TS2	B034
NP-DNGA	TS4	B032
NP-DNMA	F	B036
NP-DNMA	G	B036
NP-DNMA	GS	B036
NP-DNMA	T	B036
NP-DNMM	R/L-F	B068
NP-GDCN2004PDSR3	Insert (For NF10000 type face mill)	L053, M073
NP-GDCW1240PDFR2	Insert (For V10000 type face mill)	L053, M071
NP-SNGA	FS2	B037
NP-SNGA	G2	B037
NP-SNGA	GA2	B037
NP-SNGA	GA4	B037
NP-SNGA	GS2	B037
NP-SNGA	SE2	B037
NP-SNGA	SF2	B037
NP-SNGA	T2	B037
NP-SNGA	TS2	B037
NP-SNMA	F	B038
NP-SNMA	G	B038
NP-SNMA	GS	B038
NP-SNMA	T	B038
NP-SNMM	R/L-F	B069
NP-TCGW	FA3	B057
NP-TCGW	FS3	B057
NP-TCGW	GA3	B057
NP-TCGW	GS3	B057
NP-TCGW	SE3	B057
NP-TCGW	SF3	B057
NP-TCGW	TS3	B057
NP-TNGA	FS3	B039
NP-TNGA	FS6	B039
NP-TNGA	G3	B040
NP-TNGA	GA3	B039

ORDER NUMBER	PRODUCT NAME	PAGE
NP-TNGA	GA6	B039
NP-TNGA	GH3	B039
NP-TNGA	GH6	B039
NP-TNGA	GN3	B040
NP-TNGA	GN6	B039
NP-TNGA	GS3	B039
NP-TNGA	GS6	B039
NP-TNGA	SE3	B040
NP-TNGA	SF3	B040
NP-TNGA	T3	B040
NP-TNGA	TA3	B040
NP-TNGA	TA6	B039
NP-TNGA	TH3	B040
NP-TNGA	TH6	B039
NP-TNGA	TS3	B039
NP-TNGA	TS6	B039
NP-TNMA	F	B040
NP-TNMA	G	B041
NP-TNMA	GS	B040
NP-TNMA	T	B041
NP-TNMM	R/L-F	B069
NP-TPGB	FS3	B058
NP-TPGB	GA3	B058
NP-TPGB	GH3	B058
NP-TPGB	GS3	B058
NP-TPGB	SE3	B059
NP-TPGB	SF3	B058
NP-TPGB	TA3	B058
NP-TPGB	TH3	B058
NP-TPGX	F	B059
NP-TPGX	G	B059
NP-TPGX	GA3	B059
NP-TPGX	GS3	B059
NP-TPGX	T	B059
NP-TPMB	G	B059
NP-TPMH	R/L-F	B075
NP-TPMX	R/L-F	B075
NP-VBGT	R-F	B077
NP-VBGW	FS2	B061
NP-VBGW	G	B062
NP-VBGW	GA2	B061
NP-VBGW	GH2	B061
NP-VBGW	GS2	B061
NP-VBGW	SE2	B061
NP-VBGW	SF2	B061
NP-VBGW	TA2	B061
NP-VBGW	TH2	B061
NP-VBGW	TS2	B061
NP-VCGT	R-F	B077
NP-VCGW	FS2	B062
NP-VCGW	GA2	B062
NP-VCGW	GH2	B062
NP-VCGW	GS2	B062
NP-VCGW	TA2	B062
NP-VCGW	TH2	B062
NP-VCGW	TS2	B062

ORDER NUMBER	PRODUCT NAME	PAGE
NP-VNGA○○○○○○G2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○FS2	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○FS4	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○G2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○GA2	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○GA4	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○GH2	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○GH4	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○GN2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○GS2	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○GS4	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○SE2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○SF2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○T2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○TA2	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○TA4	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○TH2	Insert (Class G tolerance)	B043
NP-VNGA○○○○○○TH4	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○TS2	Insert (Class G tolerance)	B042
NP-VNGA○○○○○○TS4	Insert (Class G tolerance)	B042
NP-VNMA○○○○○○F	Insert (Class M tolerance)	B043
NP-VNMA○○○○○○G	Insert (Class M tolerance)	B043
NP-VNMA○○○○○○GS	Insert (Class M tolerance)	B043
NP-VNMA○○○○○○T	Insert (Class M tolerance)	B043
NP-VNMM○○○○○○R/L-F	Insert (Class M tolerance)	B070
NP-WCMW○○○○○○FA	Insert (Class M tolerance)	B063
NP-WFC42ZFER2	Insert (For BF407•QBF407 type face mill)	L055
NP-WNGA○○○○○○FS3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○FS6	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GA3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GA6	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GAWS3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GH3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GS3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GS6	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○GSWS3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○SE3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○SF3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○TA3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○TH3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○TS3	Insert (Class G tolerance)	B044
NP-WNGA○○○○○○TS6	Insert (Class G tolerance)	B044
NPX type	Spare parts (For NPX type drill)	Q043
NR10000 type	Spare parts (For NR10000 type face mill)	Q030
NS○○○	Clamp screw	Q006
NS○○○W	Clamp screw	Q006
NSE300 type	Spare parts (For NSE300 type end mill)	Q037
NSE300 type	Spare parts (For NSE300 type face mill)	Q031
NSE400 type	Spare parts (For NSE400 type end mill)	Q037
NSE400 type	Spare parts (For NSE400 type face mill)	Q031

ORDER NUMBER	PRODUCT NAME	PAGE
NTF type	NT holder	Q025
NV○ type	Boring unit (Vertical type)	Q027
NVPN type	Cartridge (For boring unit)	Q027
NVSP type	Cartridge (For boring unit)	Q027
O		
OCTACUT○○○○○○○	OCTACUT type face mill	M181, M182
OCTACUT○○○○S32○○	OCTACUT type end mill	M180
OEMX○○○○○E○R1	Insert (For OCTACUT type cutter)	L033, L053, M183
OEMX○○○○○E○R1-JS	Insert (For OCTACUT type cutter)	L033, M183
ORGW○○○N9	O ring	F111
P		
P425 type	Spare parts (For P425 type face mill)	Q031
P525 type	Spare parts (For P525 type face mill)	Q031
P○○○AM	Pin	E035-E038
PCBNR/L○○○○○○○	LL holder	C009, Q018
PCFN type	Spare parts (For LL holder)	Q018
PCLNR/L○○○○○○○	LL holder	C008, Q018
PCLNR/L○○CA○○	LL type cartridge	N006
PDHNR/L○○○○○○○	LL holder	C011
PDJNR/L○○○○○○○	LL holder	C010
PMC○○R○○○AM○○○○	PMC type end mill	M254
PMF○○○○○A○○R	PMF type end mill	M256
PMFA○○R	Cartridge (For PMF type end mill)	M256
PMR○○○○○○A○○R	PMR type end mill	M258
PMR○○○○○○R	PMR type end mill	M258
PRDCN○○○○○○○	LL holder	C024, Q018
PRGCR/L○○○○○○○	LL holder	C024, Q018
P○○S	Lock pin	C020, G038, F126, Q014
PS○○	Shim	Q010
PSBNR/L○○○○○○○	LL holder	C012, Q018
PSDNN○○○○○○○	LL holder	C014
PSKNR/L○○○○○○○	LL holder	C015, Q018
PSKNR/L○○CA○○	LL type cartridge	N006
PSSNR/L○○○○○○○	LL holder	C013, Q018
PSSNR/L○○CA○○	LL type cartridge	N006
PSTNR/L○○○○○○○	LL holder	C013
PSYNR○○CA○○	LL type cartridge	N006
PT○○	Shim	Q010
PTAN type	Spare parts (For LL holder)	Q018
PTBN type	Spare parts (For LL holder)	Q018
PTFE type	Spare parts (For AL holder)	Q022
PTFNR/L○○○○○○○	LL holder	C017, Q018
PTFNR/L○○CA○○	LL type cartridge	N006
PTGE type	Spare parts (For AL holder)	Q022
PTGNR/L○○○○○○○	LL holder	C016, Q018
PTGNR/L○○CA○○	LL type cartridge	N006
PTTNR○○CA○○	LL type cartridge	N006
PTTN type	Spare parts (For LL holder)	Q018
PT○○○R	Shim	Q011
P○○○US	Lock pin	Q014
PV○○○	Shim	Q012
PVJNR/L○○○○○○○	MP holder	C018

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
PVPNR/L	MP holder	C020, Q020
PVVNN	MP holder	C019, Q020
P	Lock pin	Q014
PWLNR/L	LL holder	C021
P	Lock pin	Q014

Q

QB	Q type quick change	N021
QBF407R type	Spare parts (For Qing cutter)	Q031
QBP415 type	Spare parts (For Qing cutter)	Q031
QF10000 type	Spare parts (For Qing cutter)	Q031
QFA	T type quick change	N019
QFA	Q type quick change	N018
QFA	Q type quick change	N018
QFB	Q type quick change	N019
QING	Qing cutter	M271
QOGT	Insert (For AQX type end mill)	L034, M157
QOMT	Insert (For AQX type end mill)	L034, M157
QPAR1	Guide plate	Q031, Q032
QPCR1	Guide plate	Q031
QSE415 type	Spare parts (For Qing cutter)	Q032
QWGR1	Wedge-T	Q031

R

RBH	Arbor (For MICRO-DEX/MICRO-MINI type boring bar)	E018, E023, F122, G035
RCGT	Insert (Class G tolerance)	A156
RCMT	Insert (Class M tolerance)	A156
RCMX	Insert (Class M tolerance)	A156
RCMX	Insert (Class M tolerance)	A156
RDMW	Insert (For ARX type end mill)	L034, M192
REM1705SN	Insert (For OCTACUT type cutter)	L034, M183
REM	Insert (For OCTACUT type cutter)	L034, M183
RGEN2004M	Insert (For SG20 type cutter)	L035, M065
RKY25S	Wrench	M066-M068
RNGN	Insert (Class G tolerance)	B046
RNMG	Insert (Class M tolerance)	A114
RN-S	Clamp screw	Q006
RPH/MT	Insert (For ARP type cutter)	L034, M189
RPMT	Insert (For BRP type cutter)	L035, M199
RPMW	Insert (For BRP type cutter)	L035, M199
RS	Clamp screw	Q006
RTG	Insert (For TL holder)	A179, B063, C035

S

S	Clamp screw	Q006
S2SDA	HSS end mill	J392
SBA	Parts for ABS head	N025
SBA	Parts for ABS head	N025
SBAHR	Boring holder	D030
SBAT	Insert (For SBAHR type holder)	D030
SBAT	Insert (For SBAHR type holder)	D030
SBH	Square type holder	(For MICRO-DEX/MICRO-MINI type boring bar)...
		E024, F123, G034
SBR	MI holder	N015

ORDER NUMBER	PRODUCT NAME	PAGE
SCACR/L	Small tools holder (External front turning)	D008
SCD43	Shim	Q029
SCLCR/L	SP holder	C022
SCLCR/L	Small tools holder (External front turning)	D008
SC	Arbors for screw-in tools	M270
SC	Arbors for screw-in tools	M270
SC	Arbors for screw-in tools	M269
SC	Arbors for screw-in tools	M269
SCMT	Insert (Class M tolerance)	A158
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A158
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A157
SCMT	Insert (Class M tolerance)	A158
SCMT	Insert (Class M tolerance)	A158
SCMW	Insert (Class M tolerance)	A158
SCP	Shim	Q031
SD	Straight shank drill	P176, P178
SD	Set bolt	E042, Q006
SDEN1203AEN	Insert (For FMSSD type cutter)	L035
SDFC type	Spare parts (For SP holder)	Q021
SDJCR/L	SP holder	C023, Q021
SDJCR/L	Small tools holder (External front turning)	D009
SDJER/L	AL holder	C032
SDKN1203AEN	Insert (For FMSSD type cutter)	L035
SDKN	Insert (For FMSSD type cutter)	L035
SDLS	Straight shank drill	P179
SDNCN	SP holder	C023
SDNCR/L	Small tools holder (External front turning)	D009
SDNEN	AL holder	C032
SDXC type	Spare parts (For SP holder)	Q021
SE300 type	Spare parts (For SE300 type end mill)	Q037
SE300 type	Spare parts (For SE300 type face mill)	Q032
SE400 type	Spare parts (For SE400 type face mill)	Q032
SE415 type	Spare parts (For SE415 type face mill)	Q032
SE445 type	Spare parts (For SE445 type face mill)	Q032
SE545 type	Spare parts (For SE545 type face mill)	Q032
SE515R	SE515 type face mill	M062
SEA42C10GR/L	Insert (For E404/FE404 type cutter)	L035, M267
SECN1203AFFR1	Insert (For SE445 type cutter)	L053
SECN	Insert (For SE445 type cutter)	L035
SECN	Insert (For SE415/SE515 type cutter)	L036, L053, M063
SED2KMG	Key way slotting end mill	J091
SED2KPG	Key way slotting end mill	J092
SEE2L	Carbide end mill	J110
SEE4L	Carbide end mill	J186
SEEN	Insert (For SE445/545 type cutter)	L035, L036

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
SEEN○○○○EFOR1	Insert (For SE415/515 type cutter)	L036, M063	SNMG○○○○○○-FS	Insert (Class M tolerance)	A115
SEER1203EFER-JS	Insert (For SE415 type cutter)	L036	SNMG○○○○○○-GH	Insert (Class M tolerance)	A119
SEER○○○○AFEN-JS	Insert (For SE445/545 type cutter)	L036	SNMG○○○○○○-GK	Insert (Class M tolerance)	A117
SEET13T3AGEN-JL	Insert (For ASX445 type cutter)	L037, M033	SNMG○○○○○○-GM	Insert (Class M tolerance)	A117
SEFO○○○	Setting fixture	M268	SNMG○○○○○○-LK	Insert (Class M tolerance)	A115
SEG4SA	Carbide end mill	J185	SNMG○○○○○○-LM	Insert (Class M tolerance)	A115
SEGT13T3AGFN-JP	Insert (For ASX445 type cutter)	L037, M033	SNMG○○○○○○-LP	Insert (Class M tolerance)	A115
SEKN1203AGTN	Insert (For corner angle 45° type cutter)	L037	SNMG○○○○○○-MA	Insert (Class M tolerance)	A117
SEKN○○○○AFON1	Insert (For SE445/545 type cutter)	L035, L036	SNMG○○○○○○-MH	Insert (Class M tolerance)	A117
SEKN○○○○AFTN	Insert (For SE445 type cutter)	L035	SNMG○○○○○○-MK	Insert (Class M tolerance)	A117
SEKN○○○○EFOR	Insert (For SE415 type cutter)	L036	SNMG○○○○○○-MM	Insert (Class M tolerance)	A116
SEKN○○○○EFOR1	Insert (For SE415/515 type cutter)	L036, M063	SNMG○○○○○○-MP	Insert (Class M tolerance)	A116
SEMT13T3AGSN-○○	Insert (For ASX445 type cutter)	L037, M033	SNMG○○○○○○-MS	Insert (Class M tolerance)	A117
SEPDM	HSS milling shank drill	P142	SNMG○○○○○○-RK	Insert (Class M tolerance)	A119
SEPDS	HSS milling shank drill	P140	SNMG○○○○○○-R/L-1G	Insert (Class M tolerance)	A116
SETHR type	Spare parts (For SET holder)	Q021	SNMG○○○○○○-RM	Insert (Class M tolerance)	A118
SETK○○	Clamp bridge	G019, G038, H016, Q015	SNMG○○○○○○-RP	Insert (Class M tolerance)	A118
SETS○○	Clamp screw	G019, G038, H016, Q006	SNMG○○○○○○-RS	Insert (Class M tolerance)	A119
SFAN1203ZFFR/L2	Insert (For BF407/QBF407 type cutter)	L037	SNMG○○○○○○-SA	Insert (Class M tolerance)	A116
SFCN1203ZFFR/L2	Insert (For BF407/QBF407 type cutter)	L037, L053	SNMG○○○○○○-SH	Insert (Class M tolerance)	A115
SG20R○○○○○	SG20 type face mill	M064	SNMG○○○○○○-SY	Insert (Class M tolerance)	A116
SH○○○-FSDUCL○○	Small tools holders (For opposite tool posts)	D026	SNMM○○○○○○-HL	Insert (Class M tolerance)	A119
SHP400 type	Spare parts (For SHP400 type end mill)	Q037	SNMM○○○○○○-HM	Insert (Class M tolerance)	A120
SHP400 type	Spare parts (For SHP400 type face mill)	Q033	SNMM○○○○○○-HR	Insert (Class M tolerance)	A119
SL32○○-90	Sleeve (For H100THB32-135)	H022	SNMM○○○○○○-HV	Insert (Class M tolerance)	A119
SLCS○○○	Clamp screw	Q006	SNMM○○○○○○-HX	Insert (Class M tolerance)	A119
SLCW○○	Clamp wedge	Q021	SNMM○○○○○○-HZ	Insert (Class M tolerance)	A120
SLN○○	Nut	Q021	SNMN○○○○○○	Insert (Class M tolerance)	A138, L038
SL-ONEN120404ASN	Insert (For AOX445 type cutter)	L053, M061	SNMU○○○○○○AN○○○	Insert (For WSX445 type cutter)	L038, M023
SLP○○	Lock pin	Q021	SNTF type	Spare parts (For SNT holder)	Q025
SLSTN○○	Shim	Q021	SOET12T308PEER-JL	Insert (For ASX400 type cutter)	L038, M084
SMGHR○○○○○○○	SMG holder	F118, G026	SOGT12T308PEFR-JP	Insert (For ASX400 type cutter)	L038, M084
SMGTR○○○○○○○	Insert (For SMG holder)	F118	SOGX○○○○○○○○	Insert (For MVX type drill)	L057, P237
SMGTR○○○○○○○	Insert (For SMG holder)	G027	SOMT12T3○○PEER/L-○○	Insert (For ASX400 type cutter)	L039, M084, M095
SMTTR○○○○○○○	Insert (For SMG holder)	F118, G027	SOMX○○○○○○○○	Insert (For MVX type drill)	L056, L057, P237
SNC43B2○	Insert (For DN/BN425 type face mill)	L038	SONX1206PER/L	Insert (For VOX400/VOS400 type cutter)	L039, M078, M094
SNF43B2○	Insert (For DN/BN425 type face mill)	L038	SPC○○53Z	Insert (For FF3000 type cutter)	L039, M075
SNGA○○○○○○	Insert (Class G tolerance)	A120, B038, B069	SPEN1203EEER/L1	Insert (For FBP415/QBP415 type cutter)	L040
SNGG○○○○○○R/L	Insert (Class G tolerance)	A118	SPEN1203EETR1	Insert (For FBP415/QBP415 type cutter)	L053
SNGN○○○○○○	Insert (Class G tolerance)	A138, B047, B071	SPEN○○○A	Insert (For FP490/590/690 type cutter)	L039, M263, M265
SNGU○○○○○○ANOR/L-○	Insert (For WSX445 type face mill)	L038, M023	SPEN○○○EDR	Insert (For corner angle 15° type cutter)	L040
SNK43B2○	Insert (For DN/BN425 type face mill)	L038	SPER1203EEER-JS	Insert (For FBP415/QBP415 type cutter)	L040
SNMA○○○○○○	Insert (Class M tolerance)	A120	SPGN○○○○○○	Insert (Class G tolerance)	A180, B064, B081, L040
SNMG○○○○○○	Insert (Class M tolerance)	A118	SPGR○○○○○○R	Insert (Class G tolerance)	A180
SNMG○○○○○○-C	Insert (Class M tolerance)	A116	SPGX○○○○○○	Insert (Class G tolerance)	A159, B073
SNMG○○○○○○-FH	Insert (Class M tolerance)	A115	SPKN○○○○EDR	Insert (For corner angle 15° type cutter)	L040
SNMG○○○○○○-FP	Insert (Class M tolerance)	A115	SPMB1204APT	Insert (For BSP type end mill)	L040
			SPMN○○○○○○	Insert (Class M tolerance)	A180, L040
			SPMN○○○○○○T	Insert (Class M tolerance)	A180, L040
			SPMR○○○○○○	Insert (Class M tolerance)	A180

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
SPMT	Insert (Class M tolerance)	A159
SPMT120408-A	Insert (For TBE1 type end mill)	L041
SPMW	Insert (Class M tolerance)	A159, L041, M247
SPMX120408	Insert (For SPX type end mill)	L041, M217
SPNN1203EEER/L1	Insert (For FBP415 type cutter)	L040
SPS1	Locator screw	Q006
SPSE	Locator (For SE445/515/545 type cutter)	M062, Q032
SPSEW	Locator (For SE300/400 type cutter)	Q032
SPSG20R	Locator (For SG20 type cutter)	M065
SPSHP400R/L	Locator (For SHP400 type cutter)	Q037
SPSVN32	Shim	Q012
SPTSE300R	Locator (For SE300 type cutter)	Q031
SPTSE400R	Locator (For SE400 type cutter)	Q031
SPX4	SPX type end mill (Shell type)	M216
SPX4R	SPX type end mill (Shell type)	M216
SPX4R	SPX type end mill	M215
SPX4R	SPX type end mill	M215
SPX4R	SPX type end mill	M215
SPX4R	SPX type end mill	M215
SRBT	Insert (For SRF type end mill)	L041, M230
SRDCN	SP holder	C025, Q021
SRE type	Spare parts (For SRE type end mill)	Q038
SRFH	SRF/SUF type end mill	M229, M233
SRFH	SRF/SUF type end mill	M228, M232
SRFH	SRF/SUF type end mill (Carbide shank)	M229, M233
SRFT	Insert (For SRF type end mill)	L041, M230
SRG	Insert (For SRM2 type end mill)	L042, M239, M245
SRGCR/L	SP holder	C025, Q021
SRK1R	Clamp bridge	Q015
SRM2	SRM2 type end mill	M238
SRM2	SRM2 type end mill	M244
SRM2	SRM2 type end mill	M236, M237
SRM	Insert (For SRM2 type end mill)	L042, M239
SRM	Insert (For SRM2 type end mill)	L042, M239
SRS5	Clamp screw	Q006
SRSGN type	Spare parts (For SR holder)	Q021
SRSGR/L type	Spare parts (For SR holder)	Q021
SRXCR/L type	Spare parts (For SP holder)	Q021
SSBCR/L type	Spare parts (For SP holder)	Q021
S	S type boring bar (Steel shank)	E030
S	Spare parts (For COBRA boring bar)	Q024
S	S type boring bar (Steel shank)	E034, Q026
S	S type boring bar (Steel shank)	E031, Q026
S	S type boring bar (Steel shank)	E029
S	Spare parts (For S type boring bar)	Q026
SSE41R/L	Locator (For E404 type face mill)	Q029
SSKPR	SS type cartridge	N010
SSP	Locator	Q031
SSSCR/L	SP holder	C026
S	S type boring bar (Steel shank)	E033, Q026
SSSPR	SS type cartridge	N010
S	S type boring bar (Steel shank)	E028
S	AL type boring bar (Steel shank)	E043

ORDER NUMBER	PRODUCT NAME	PAGE
S	Spare parts (For COBRA boring bar carbide shank)	Q024
S	S type boring bar (Steel shank)	E032
S	S type boring bar (Steel shank)	E033
S	Spare parts (For COBRA boring bar)	Q024
SSYPR	SS type cartridge	N010
STASX	Shim	M032, M080, M082, Q012
STAWK	Insert (For STAW type drill)	L064, L065, P210, P215
STAW	STAW type drill (General use)	P210
STAWN	Insert (For STAW type drill)	L063, P214
STAWN	Insert (For STAW type drill)	L062, L063, P210, P213
STAW	STAW type drill (General use)	P210
STBE445NF	Shim	Q030
STBS500N	Shim	Q012
STFER/L	AL holder	C033
STFPR/L	SS type cartridge	N010
STGCR/L	SP holder	C027
STGER/L	AL holder	C033
STGPR	SS type cartridge	N010
STLG type	Spare parts (For STLG type end mill)	Q038
STPMR	Shim	M258
STS1	Clamp screw	Q006
STSE	Shim	M062, Q032
STSP415R	Shim	Q029, Q031
STTPR	SS type cartridge	N010
SUFT	Insert (For SUF type end mill)	L043, M234
SVJBR/L	Small tools holder (External front turning)	D010
SVJCR/L	SP holder	C028, Q021
SVJCR/L	Small tools holder (External front turning)	D011
SVJDR/L	AL holder	C034
SVLPR/L	Small tools holder (External front turning)	D010
SVPCR/L	SP holder	C029, Q021
SVPD type	Spare parts (For AL type holder)	Q022
SVPPR/L	Small tools holder (External front turning)	D011
SVVBR/L	Small tools holder (External front turning)	D011
SVVCN	SP holder	C028, Q021
SVVDN type	Spare parts (For AL type holder)	Q022
SXZCR/L	Profile holder	C030

T

TAB type	Spare parts (For TAB type drill)	Q043
TAFL/M/S	TAF type drill	P242
TAGS/M type	Spare parts (For TAGS/TAGM type drill)	Q042
TASS type	Spare parts (For TSSS type drill)	Q041
TAWBH	TAW type drill (For bridge construction)	L059, P229
TAW	TAW type drill (For bridge construction)	P229

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
TAWC12T301-45GM	Insert (For TAW type drill chamfering module)...	L061	TNMG -GH	Insert (Class M tolerance).....	A126
TAWKH OTG	Insert (For TAW type drill).....	L060, P226	TNMG -GK	Insert (Class M tolerance).....	A124
TAWNH OT	Insert (For TAW type drill).....	L058, P224	TNMG -GM	Insert (Class M tolerance).....	A124
TAW N S O	TAW type drill (General use).....	P219	TNMG -LK	Insert (Class M tolerance).....	A122
TBE1 type	Spare parts (For TBE1 type end mill).....	Q039	TNMG -LM	Insert (Class M tolerance).....	A122
TBE2 type	Spare parts (For TBE2 type end mill).....	Q039	TNMG -LP	Insert (Class M tolerance).....	A122
TBGN	Insert (Class G tolerance).....	B065	TNMG -LS	Insert (Class M tolerance).....	A122
TCGN	Insert (Class G tolerance).....	A181	TNMG -MA	Insert (Class M tolerance).....	A124
TCGT -AZ	Insert (Class G tolerance).....	A160	TNMG -MH	Insert (Class M tolerance).....	A124
TCGT MR/L-F	Insert (Class G tolerance).....	A160	TNMG -MJ	Insert (Class M tolerance).....	A123
TCGT OR/L-F	Insert (Class G tolerance).....	A160	TNMG -MK	Insert (Class M tolerance).....	A123
TCGW	Insert (Class G tolerance).....	A162, B074	TNMG -MM	Insert (Class M tolerance).....	A123
TCGW FS	Insert (Class G tolerance).....	B057	TNMG -MP	Insert (Class M tolerance).....	A123
TCMT	Insert (Class M tolerance).....	A162	TNMG -MS	Insert (Class M tolerance).....	A124
TCMT -FM	Insert (Class M tolerance).....	A160	TNMG -RK	Insert (Class M tolerance).....	A126
TCMT -FP	Insert (Class M tolerance).....	A160	TNMG -R/L-1G	Insert (Class M tolerance).....	A123
TCMT -FV	Insert (Class M tolerance).....	A160	TNMG -R/L-2G	Insert (Class M tolerance).....	A125
TCMT -LM	Insert (Class M tolerance).....	A161	TNMG -R/L-ES	Insert (Class M tolerance).....	A125
TCMT -LP	Insert (Class M tolerance).....	A161	TNMG -RM	Insert (Class M tolerance).....	A126
TCMT -LS	Insert (Class M tolerance).....	A161	TNMG -RP	Insert (Class M tolerance).....	A126
TCMT -MK	Insert (Class M tolerance).....	A161	TNMG -RS	Insert (Class M tolerance).....	A126
TCMT -MM	Insert (Class M tolerance).....	A161	TNMG -SA	Insert (Class M tolerance).....	A122
TCMT -MP	Insert (Class M tolerance).....	A161	TNMG -SH	Insert (Class M tolerance).....	A122
TCMT -MS	Insert (Class M tolerance).....	A161	TNMG -SY	Insert (Class M tolerance).....	A123
TCMW	Insert (Class M tolerance).....	A162, B057, B074	TNMM -HL	Insert (Class M tolerance).....	A127
TD	Taper shank drill.....	P194	TNMM -HZ	Insert (Class M tolerance).....	A127
TECN1603PEOR1W	Insert (For NSE300/SE300 type cutter).....	L044	TNMN	Insert (Class M tolerance).....	A139
TECN PEOR1	Insert (For NSE300/NSE400 type cutter).....	L044, L054	TNMX -MW	Insert (Class M tolerance).....	A125
TEEN PEOR1	Insert (For NSE300/NSE400 type cutter).....	L043	TNMX -SW	Insert (Class M tolerance).....	A123
TEER PEER-JS	Insert (For NSE300/400/SE300 type cutter).....	L044	TNP-CCGW G2	Insert (Class G tolerance).....	B050
TEGX	Insert (For AL holder).....	B079	TNP-CNGA G2	Insert (Class G tolerance).....	B030
TEGX OR/L	Insert (For AL holder).....	A163, B079	TNP-CNGA T2	Insert (Class G tolerance).....	B030
TEKN PEOR	Insert (For NSE400 type cutter).....	L044	TNP-DCGW G2	Insert (Class G tolerance).....	B055
TEKN PEOR1	Insert (For NSE400 type cutter).....	L044	TNP-DNGA G2	Insert (Class G tolerance).....	B035
TFS	Filler screw (For MMTI boring bar).....	G028	TNP-DNGA T2	Insert (Class G tolerance).....	B035
TIP	Wrench.....	Q002	TNP-SNGA G2	Insert (Class G tolerance).....	B037
TKY	Wrench.....	Q002	TNP-SNGA T2	Insert (Class G tolerance).....	B037
TLHR	TL holder.....	C035	TNP-TNGA G3	Insert (Class G tolerance).....	B040
TNGA	Insert (Class G tolerance).....	A127, B041, B069	TNP-TNGA T3	Insert (Class G tolerance).....	B040
TNGG -PK	Insert (Class G tolerance).....	A121	TNP-VNGA G2	Insert (Class G tolerance).....	B043
TNGG OR/L	Insert (Class G tolerance).....	A125, A126	TNP-VNGA T2	Insert (Class G tolerance).....	B043
TNGG R/L-F	Insert (Class G tolerance).....	A122	TPEN POR	Insert (For corner angle 0° type cutter).....	L044
TNGG R/L-FS	Insert (Class G tolerance).....	A121	TPEW ZPOR2	Insert (For PMF type end mill).....	L044, L054, M256
TNGG R/L-K	Insert (Class G tolerance).....	A123	TPGH OR/L-FS	Insert (Class G tolerance).....	A164
TNGN	Insert (Class G tolerance).....	A139, B048	TPGN	Insert (Class G tolerance).....	A182, B065, B081
TNMA	Insert (Class M tolerance).....	A127	TPGR OR/L	Insert (Class G tolerance).....	A182
TNMG	Insert (Class M tolerance).....	A125	TPGT OR/L-F	Insert (Class G tolerance).....	B075
TNMG -C	Insert (Class M tolerance).....	A123	TPGV OR/L-F	Insert (Class G tolerance).....	B076
TNMG -FH	Insert (Class M tolerance).....	A121	TPGX	Insert (Class G tolerance).....	A166, B060, B076
TNMG -FP	Insert (Class M tolerance).....	A121	TPGX OR/L	Insert (Class G tolerance).....	A165
TNMG -FS	Insert (Class M tolerance).....	A121	TPKN POR	Insert (For corner angle 0° type cutter).....	L044
TNMG -FY	Insert (Class M tolerance).....	A121	TPMH -FV	Insert (Class M tolerance).....	A164
			TPMH -MV	Insert (Class M tolerance).....	A165

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
TPMH○○○○○○○-SV	Insert (Class M tolerance)	A165	VBGT○○○○○○○R/L-F	Insert (Class G tolerance)	A167
TPMN○○○○○○○	Insert (Class M tolerance)	A182, L045	VBMT○○○○○○○	Insert (Class M tolerance)	A168
TPMR○○○○○○○	Insert (Class M tolerance)	A182	VBMT○○○○○○○-FM	Insert (Class M tolerance)	A167
TPMX○○○○○○○	Insert (Class M tolerance)	A165	VBMT○○○○○○○-FP	Insert (Class M tolerance)	A167
TPMX○○○○○○○L	Insert (Class M tolerance)	A165	VBMT○○○○○○○-FV	Insert (Class M tolerance)	A167
TPNX1605N	Insert (For VIPER type end mill)	L045	VBMT○○○○○○○-LM	Insert (Class M tolerance)	A167
TPS○○	Clamp screw	Q008	VBMT○○○○○○○-LP	Insert (Class M tolerance)	A167
TPS○○○	Clamp screw	Q008	VBMT○○○○○○○-LS	Insert (Class M tolerance)	A168
TPS○○○	Clamp screw	Q008	VBMT○○○○○○○-MK	Insert (Class M tolerance)	A168
TPS351B	Clamp screw	Q008	VBMT○○○○○○○-MM	Insert (Class M tolerance)	A168
TRM2 type	Spare parts (For TRM2 type end mill)	Q040	VBMT○○○○○○○-MP	Insert (Class M tolerance)	A168
TRM4 type	Spare parts (For TRM4 type end mill)	Q040	VBMT○○○○○○○-MS	Insert (Class M tolerance)	A168
TS○	Clamp screw	Q007	VBMT○○○○○○○-MV	Insert (Class M tolerance)	A169
TS○○	Clamp screw	Q007	VBMT○○○○○○○-SV	Insert (Class M tolerance)	A168
TS○○○	Clamp screw	Q007	VBMW○○○○○○○	Insert (Class M tolerance)	A169
TS3SB	Clamp screw	M134, M135, Q007	VC2C	MIRACLE end mill	J082
TS3SBS	Clamp screw	M134, Q007	VC2JS	MIRACLE end mill	J080
TS4SBL	Clamp screw	F027, M142, M143, Q007	VC2MS	MIRACLE end mill	J077
TSMPR○○○○S○○	TSMP type end mill	M248	VC2SS	MIRACLE end mill	J075
TSR○○○○○S	Clamp screw	Q008	VC3MB	MIRACLE end mill	J268
TSS○○○○○	Radial screw	M256, N009, N011, Q008	VC4JC	MIRACLE end mill	J170
TSS04505S	Clamp screw	M066-M068	VC4JRB	MIRACLE end mill	J326
TTAHR/L○○○○○	Small tools holder (External threading)	D024	VC4MC	MIRACLE end mill	J168
TTAT○○○○○○○R/L○-B	Insert (For small tools holder)	D024	VC4SRB	MIRACLE end mill	J324
TTD	Taper shank drill, For steel frame	P206	VC4STB	MIRACLE end mill	J352
U			VCGT○○○○○○○-AZ	Insert (Class G tolerance)	A170
UCR	Clamp bridge	Q015	VCGT○○○○○○○M-LS	Insert (Class G tolerance)	A171
UGHN○○○	UG holder	F114	VCGT○○○○○○○M-LS-P	Insert (Class G tolerance)	A171
UGHR/L○○○○○	UG holder	F114	VCGT○○○○○○○R/L-F	Insert (Class G tolerance)	A170
UGS1	Wrench	F114	VCHFRB	MIRACLE end mill	J328, J329
V			VCHSM	MIRACLE drill, Medium, For hardened material...	P135
V10000-063A04R	V10000 type face mill	M070	VCLD	MIRACLE end mill	J193
V10000R○○○○○	V10000 type face mill	M070	VCMDSC	MIRACLE end mill	J172
VA2MS	VIOLET end mill	J382	VCMH	MIRACLE end mill	J126
VA2SS	VIOLET end mill	J380	VCMHDRB	MIRACLE end mill	J332
VA4MC	VIOLET end mill	J396	VCMT○○○○○○○	Insert (Class M tolerance)	A172
VAMFPR	VIOLET end mill	J404	VCMT○○○○○○○-FM	Insert (Class M tolerance)	A170
VAMH	VIOLET end mill	J393	VCMT○○○○○○○-FP	Insert (Class M tolerance)	A170
VAMR	VIOLET end mill	J406	VCMT○○○○○○○-FV	Insert (Class M tolerance)	A170
VAPDJ	Violet coated high precision drill	P153	VCMT○○○○○○○-LM	Insert (Class M tolerance)	A170
VAPDM	VIOLET drill, Medium, High precision	P149	VCMT○○○○○○○-LP	Insert (Class M tolerance)	A170
VAPDMSUS	VIOLET drill, Medium, High precision, For stainless steel ...	P161	VCMT○○○○○○○-LS	Insert (Class M tolerance)	A171
VAPDS	VIOLET drill, Short, High precision	P144	VCMT○○○○○○○-MK	Insert (Class M tolerance)	A171
VAPDSCB	VIOLET drill, Short flute length, High precision, For counter boring ...	P168	VCMT○○○○○○○-MM	Insert (Class M tolerance)	A171
VAPDSSUS	VIOLET drill, Short, High precision, For stainless steel...	P155	VCMT○○○○○○○-MP	Insert (Class M tolerance)	A171
VAS400	VAS400 type side cutter	M090	VCMT○○○○○○○-MS	Insert (Class M tolerance)	A171
VAS500	VAS500 type side cutter	M092	VCMT○○○○○○○-MV	Insert (Class M tolerance)	A172
VASFPR	VIOLET end mill	J402	VCMT○○○○○○○-SV	Insert (Class M tolerance)	A171
VBET○○○○○○○R/L-SN	Insert (Class E tolerance)	A169	VCMW○○○○○○○	Insert (Class M tolerance)	A172
VBET○○○○○○○R/L-SR	Insert (Class E tolerance)	A169	VCPSRB	MIRACLE end mill	J318, J322
VBET○○○○○○○R/LW-SN	Insert (Class E tolerance)	A169	VCSSS	MIRACLE drill, Short, For steel (3mm shank series)...	P134
			VCT13R	Cartridge (For V10000 type cutter)	M070
			VCXB	MIRACLE end mill	J228
			VDGX○○○○○○○R/L	Insert (Class G tolerance)	A173

ORDER NUMBER	PRODUCT NAME	PAGE
V D G X ○○○○○○○○R/L-F	Insert (Class G tolerance)	B080
V F 2 M D	IMPACT MIRACLE end mill	J068
V F 2 M V	IMPACT MIRACLE end mill	J070
V F 2 S DB	IMPACT MIRACLE end mill	J216
V F 2 S DBL	IMPACT MIRACLE end mill	J217
V F 2 W B	IMPACT MIRACLE end mill	J219
V F 2 X L	IMPACT MIRACLE end mill	J072
V F 2 X LB	IMPACT MIRACLE end mill	J222
V F 2 X LBS	IMPACT MIRACLE end mill	J220
V F 3 X B	IMPACT MIRACLE end mill	J260
V F 4 M B	IMPACT MIRACLE end mill	J272
V F 4 M D	IMPACT MIRACLE end mill	J164
V F 4 M V	IMPACT MIRACLE end mill	J166
V F 6 M HV	IMPACT MIRACLE end mill	J189
V F 6 M HVRB	IMPACT MIRACLE end mill	J344
V F 6 S VRCH	IMPACT MIRACLE end mill	J369
V F 8 M HVCH	IMPACT MIRACLE end mill	J194
V F 8 M HVRBCH	IMPACT MIRACLE end mill	J350
V F FD R B	IMPACT MIRACLE end mill	J316
V F H V R B	IMPACT MIRACLE end mill	J306, J312
V F MD	IMPACT MIRACLE end mill	J191
V F MD R B	IMPACT MIRACLE end mill	J348
V F MF P R	IMPACT MIRACLE end mill	J368
V F M H V C H	IMPACT MIRACLE end mill	J167
V F M H V R B C H	IMPACT MIRACLE end mill	J304
V F R2 S B	IMPACT MIRACLE REVOLUTION end mill	J212
V F R2 S BF	IMPACT MIRACLE REVOLUTION end mill	J214
V F R2 S SB	IMPACT MIRACLE REVOLUTION end mill	J210
V F SD	IMPACT MIRACLE end mill	J190
V F SD R B	IMPACT MIRACLE end mill	J346
V F S F P R	IMPACT MIRACLE end mill	J365
V F S F P R CH	IMPACT MIRACLE end mill	J367
V F X5-○○○○○○○○A○○○R	VFX5 type end mill	M220
V F X6-○○○○○○○○A○○○R	VFX6 type end mill	M224
V I P400 type	Spare parts (VIP400 type face mill)	Q033
V I P445 type	Spare parts (VIP445 type face mill)	Q033
V I P E R type	Spare parts (VIPER type end mill)	Q038
V N GA○○○○○○○	Insert (Class G tolerance)	A131, B043, B070
V N GG○○○○○○○-F J	Insert (Class G tolerance)	A128
V N GG○○○○○○○R/L	Insert (Class G tolerance)	A131
V N GG○○○○○○○-R/L-F	Insert (Class G tolerance)	A128
V N GM○○○○○○○-M J	Insert (Class G tolerance)	A129
V N MA○○○○○○○	Insert (Class M tolerance)	A131
V N MG○○○○○○○	Insert (Class M tolerance)	A130
V N MG○○○○○○○-F H	Insert (Class M tolerance)	A128
V N MG○○○○○○○-F P	Insert (Class M tolerance)	A128
V N MG○○○○○○○-F S	Insert (Class M tolerance)	A128
V N MG○○○○○○○-G K	Insert (Class M tolerance)	A130
V N MG○○○○○○○-G M	Insert (Class M tolerance)	A130
V N MG○○○○○○○-L K	Insert (Class M tolerance)	A129
V N MG○○○○○○○-L M	Insert (Class M tolerance)	A128
V N MG○○○○○○○-L P	Insert (Class M tolerance)	A128
V N MG○○○○○○○-L S	Insert (Class M tolerance)	A129

ORDER NUMBER	PRODUCT NAME	PAGE
V N MG○○○○○○○-M A	Insert (Class M tolerance)	A130
V N MG○○○○○○○-M H	Insert (Class M tolerance)	A130
V N MG○○○○○○○-M J	Insert (Class M tolerance)	A129
V N MG○○○○○○○-M K	Insert (Class M tolerance)	A129
V N MG○○○○○○○-M M	Insert (Class M tolerance)	A129
V N MG○○○○○○○-M P	Insert (Class M tolerance)	A129
V N MG○○○○○○○-M S	Insert (Class M tolerance)	A130
V N MG○○○○○○○-S A	Insert (Class M tolerance)	A129
V N MG○○○○○○○-S H	Insert (Class M tolerance)	A129
V O S400	VOS400 type side cutter	M094
V O X400-○○○○○○○R	VOX400 type face mill	M076, M077
V O X400R○○○○○○○	VOX400 type face mill	M076
V P ET○○○○○○○R/L-S R F	Insert (Class E tolerance)	A174
V P GT○○○○○○○M-S M G	Insert (Class G tolerance)	A174
V P X200-○○○○○○○A○○○AR	VPX200 type face mill	M112
V P X200R○○○○○○○AM○○○○○	VPX200 type screw-in end mill	M111
V P X200R○○○○○○○S A ○○○S/L	VPX200 type end mill	M110
V P X300-○○○○○○○A○○○AR	VPX300 type face mill	M124
V P X300R○○○○○○○AM○○○○○	VPX300 type screw-in end mill	M123
V P X300R○○○○○○○C A	VPX300 type face mill	M124
V P X300R○○○○○○○S A ○○○S/L	VPX300 type end mill	M122
V Q 4 S VB	SMART MIRACLE end mill	J270
V Q 6 M HV C H	SMART MIRACLE end mill with coolant hole	J188
V Q 6 M HVRB C H	SMART MIRACLE end mill	J342
V Q J H V	SMART MIRACLE end mill	J158
V Q M H V	SMART MIRACLE end mill	J154
V Q M H VR B	SMART MIRACLE end mill	J297
V Q M H VRB F	SMART MIRACLE end mill	J302
V Q M H Z V	SMART MIRACLE end mill	J116
V Q M H Z V O H	SMART MIRACLE end mill	J122
V Q S V R	SMART MIRACLE end mill	J362
V Q T5 M VR B	SMART MIRACLE end mill	J340
V Q T6 U R	SMART MIRACLE BARREL end mill	J359
V Q X L	SMART MIRACLE end mill	J160
V S D	VIOLET drill, Straight shank	P170
V T D S	VIOLET drill, Short, Taper shank	P172

W

W A -M10	Washer	F112
W B GT○○○○○○○R/L-F	Insert (Class G tolerance)	A175
W B MT○○○○○○○R/L-M V	Insert (Class M tolerance)	A175
W C GT○○○○○○○R/L	Insert (Class G tolerance)	A176
W C MT○○○○○○○	Insert (Class M tolerance)	A176
W C M W ○○○○○○○	Insert (Class M tolerance)	B078
W C S○○○○○○○H	Shim screw	M032, Q008
W E C○○○A F ○R5C	Wiper insert (For SE445/545 type cutter)	L050
W E C○○○E F ○R5C	Wiper insert (For SE415/515 type cutter)	L050, M063
W E E W 13T3A G ○R○C	Wiper insert (For ASX445 type cutter)	L050, L055, M034
W F C42Z F E R 2	Wiper insert (For BF407/QBF407 type cutter)	L055
W J X14-○○○○○○○A○○○AR	WJX type face mill	M172, M173
W J X14R○○○○○○○A	WJX type face mill	M172, M173

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE
WJX14R	WJX type end mill	M175
WNEU1305ZEN4C-M	Wiper insert (For AHX440S type cutter)	L050, M040
WNEU2006ZEN7C-WK	Wiper insert (For AHX640S/640W type cutter)	L051, M048, M056
WNEU2007ZEN7C	Wiper insert (For AHX640S type cutter)	L051, M048
WNGU1406ANEN8C-M	Wiper insert (For WSX445 type cutter)	L051, M023
WNMA	Insert (Class M tolerance)	A136
WNMG	Insert (Class M tolerance)	A135
WNMG-C	Insert (Class M tolerance)	A133
WNMG-FH	Insert (Class M tolerance)	A132
WNMG-FP	Insert (Class M tolerance)	A132
WNMG-FS	Insert (Class M tolerance)	A132
WNMG-FY	Insert (Class M tolerance)	A132
WNMG-GH	Insert (Class M tolerance)	A136
WNMG-GJ	Insert (Class M tolerance)	A136
WNMG-GK	Insert (Class M tolerance)	A135
WNMG-GM	Insert (Class M tolerance)	A135
WNMG-LK	Insert (Class M tolerance)	A133
WNMG-LM	Insert (Class M tolerance)	A132
WNMG-LP	Insert (Class M tolerance)	A132
WNMG-LS	Insert (Class M tolerance)	A133
WNMG-MA	Insert (Class M tolerance)	A135
WNMG-MH	Insert (Class M tolerance)	A135
WNMG-MJ	Insert (Class M tolerance)	A133
WNMG-MK	Insert (Class M tolerance)	A134
WNMG-MM	Insert (Class M tolerance)	A134
WNMG-MP	Insert (Class M tolerance)	A134
WNMG-MS	Insert (Class M tolerance)	A134
WNMG-MW	Insert (Class M tolerance)	A135
WNMG-RK	Insert (Class M tolerance)	A136
WNMG-RM	Insert (Class M tolerance)	A135
WNMG-RP	Insert (Class M tolerance)	A135
WNMG-RS	Insert (Class M tolerance)	A136
WNMG-SA	Insert (Class M tolerance)	A133
WNMG-SH	Insert (Class M tolerance)	A133
WNMG-SW	Insert (Class M tolerance)	A133
WNMG-SY	Insert (Class M tolerance)	A133
WOEW12T308PE	Wiper insert (For ASX400 type cutter)	L051, M084
WOEX1206PER5C	Wiper insert (For VOX400 type cutter)	L051, M078
WPC42EER/L10C	Wiper insert (For FBP415/QBP415 type cutter)	L051
WPGT	Insert (Class G tolerance)	B078
WPGT-R/L-FS	Insert (Class G tolerance)	A177
WPMT	Insert (Class M tolerance)	A177
WPS	Lock screw	Q022
WPSTN	Shim	Q012
WPSWC43	Shim	Q012
WPSWN43	Shim	Q012
WPT4405	Plate (For TAW type drill)	P219-P223, P229
W-S1	Seal washer	M221, M225

ORDER NUMBER	PRODUCT NAME	PAGE
W-S1	Seal washer	M221
WS1	Wedge screw	Q008
WS-LH	Stopper	P218
WS-T	Clamp screw	Q008
WS-TPS	Clamp screw	P218, Q008
WS-TPS-LH	Spare parts set	P218
WSX445-L	WSX445 type face mill	M021
WSX445L	WSX445 type face mill	M019
WSX445-R	WSX445 type face mill	M018, M020
WSX445R	WSX445 type face mill	M018
WSX445R-SA32M	WSX445 type end mill	M022

X

XCMT	Insert (Class M tolerance)	A178
XDGT1550PD-R-G	Insert (For BXD4000 type cutter)	L045, M153
XDGX1750-PD-R	Insert (For AXD4000 type cutter)	L046, M136
XDGX2270-PDER-GLA	Insert (For AXD7000 type cutter)	L047, M144
XDGX2270-PDFR	Insert (For AXD7000 type cutter)	L047, M144
XNMU16-R-S	Insert (For VFX5 type cutter)	L048, M222
XNMU19-R-S	Insert (For VFX6 type cutter)	L048, M226
XPGT-PD-R-G	Insert (For BAP3500 type cutter)	L049
XPMT-PDER-M	Insert (For BAP3500 type end mill)	L049

Z

ZCMX-R	Insert (For DCCC type end mill)	L049, M213
ZR type	Spare parts (For ZR type end mill)	Q038

NUMBER / OTHERS

01	Insert (For brazed tools holder)	I002
1LA	HSS end mill	J379
1MA	HSS end mill	J378
02	Insert (For brazed tools holder)	I002
2LS	HSS end mill	J388
2MK	HSS end mill	J391
2MS	HSS end mill	J386
2SS	HSS end mill	J384
03	Insert (For brazed tools holder)	I002
3KD	Triangular shank drill, (Type 6.5)(Type 10)(Type 13) ...	P207
04	Insert (For brazed tools holder)	I002
4LC	HSS end mill	J400
4MC	HSS end mill	J398
05	Insert (For brazed tools holder)	I002
06	Insert (For brazed tools holder)	I002
07	Insert (For brazed tools holder)	I003
08	Insert (For brazed tools holder)	I003
09E1	Insert (For brazed tools holder)	I003
31	31 type brazed tools holder	I005
32	32 type brazed tools holder	I005
33	33 type brazed tools holder	I005
34	34 type brazed tools holder	I005
35	35 type brazed tools holder	I005
36	36 type brazed tools holder	I005
37	37 type brazed tools holder	I006
38	38 type brazed tools holder	I006
39	39 type brazed tools holder	I006
40	40 type brazed tools holder	I006

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
41-○41 type brazed tools holder	I006			
42-○42 type brazed tools holder	I006			
43-○43 type brazed tools holder	I006			
47-○47 type brazed tools holder	I007			
49-○49 type brazed tools holder	I007			
51-○51 type brazed tools holder	I007			
95-○95 type brazed tools holder	I007			
GUN REAMER	P252			
Arbors for screw-in tools	M269			
Setting fixture	M268			
GUN REAMER with diamond compound	P253			

SAFETY OF CUTTING TOOL PRODUCTS

1. Use of Cutting Tool Products

Packages of Mitsubishi products carry a safety warning label. However, tools are not labeled with detailed warning indications. Please read the "Safety of Cutting Tool Products" in this catalogue before handling cutting tool products and cemented carbide materials. Moreover, as a part of your workers' safety education, please notify the contents of the "Safety of Cutting Tool Products" to all workers.

2. Basic Characteristics of Hard Tool Materials

In Terms of "Safety of Cutting Tool Products"

Hard Tool Materials : General term for tool materials like cemented carbide alloy, cermet, ceramics, sintered CBN, sintered diamond, high speed steel and alloy steel, etc.

Physical Characteristics

Appearance : Varies depending on the type of material. Eg. grey, black, gold, etc.

Smell : None

Hardness, Specific Gravity :

Hard Tool Materials	Hardness (HV)	Specific Gravity	Hard Tool Materials	Hardness (HV)	Specific Gravity
High Speed Steel (HSS)	200—1200kg/mm ²	7—9	Sintered CBN	2000—5000kg/mm ²	3—5
Cemented Carbide	500—3000kg/mm ²	9—16	Sintered Diamond	8000—12000kg/mm ²	3—5
Cermet	500—3000kg/mm ²	5—9	Alloy Steel	200—1200kg/mm ²	7—9
Ceramics	1000—4000kg/mm ²	2—7	Diamond Electroforming Product	8000—12000kg/mm ²	3—5

Constituents

Carbide, nitride, carbon nitride, oxide, such as W, Ti, Al, Si, Ta, B, V and metals such as Fe, Co, Ni, Cr, Mo.

3. Safety of Cutting Tool Products

- Hard tool materials have a large specific gravity. Thus, they require special attention as heavy materials when the size or quantity is large.
- Cutting tool products generate dust and mist during grinding operations or heating. This dust and mist can be harmful when coming in contact with the eyes or skin, or if substantial quantities are swallowed. When grinding and machining, it is recommended to use local exhaust ventilation and respirators, a dust protective mask, glasses, gloves etc. If dust makes contact with the hands, thoroughly wash the affected area with soap and water. Don't eat in the exposed area, and wash hands thoroughly before eating. Remove dust from the clothing by a cleaning or washing, but don't shake off.
- Cobalt and nickel contained in carbide or other cutting tool materials are reported as possibly carcinogenic to humans. It is also reported that cobalt and nickel dust and mist can affect the skin, respiratory organs and heart through repeated or prolonged contact.
- For further information, please refer to Safety Data Sheet.

Home page: <http://www.carbide.mht.co.th/download/safety>

4. Handling Cutting Tool Products

- Surface conditions affect toughness of cutting tools. Therefore, use a diamond grinding wheel for finishing.
- Hard tool materials are extremely hard and brittle at the same time. Thus, they may be broken by shocks and tightening with excess force.
- Hard tool materials and ferrous materials have different thermal expansion ratios. Shrinkage or swell fit products may suffer from cracks when applied temperature is higher or lower than the appropriate temperature for the tool.
- Pay special attention on storing hard tool materials. Toughness of hard tool materials is lowered when they corrode due to coolant and other liquid.
- When brazing hard tool materials, if the temperature is too high or too low from the melting point of the brazing material, loosening and breakage may occur.
- After regrinding cutting tools, make sure that there are no cracks.
- Machining hard tool materials on EDM may cause cracks on the surface due to electrons remaining after the EDM operation, resulting in lowering of the toughness. Eliminate these cracks by grinding, etc.

SUGGESTIONS ON HOW TO USE CUTTING TOOLS

Products	Hazard	Countermeasure
All Cutting Tools	⊙Cutting tools have sharp cutting edges. Handling them with bare hands may cause injuries.	*Take precautions such as wearing gloves especially when handling tools and during installation.
	⊙Improper use of tools and application of inappropriate cutting conditions may cause the tool to break and be expelled from the machine providing risk of injury.	*Ensure safety guards and goggles are used. *Refer to handling explanatory notes and catalogues. Use tools under recommended cutting conditions.
	⊙Impact load and rapid increase of cutting resistance due to excessive wear may cause the tool to break and be expelled from the machine providing risk of injury.	*Ensure safety guards and goggles are used. *Exchange tools before excessive wear occurs.
	⊙Cutting tools and workpieces become extremely hot during cutting. Touching them with bare hands may cause burns.	*Take precautions such as wearing gloves.
	⊙Expelled hot chips produced in cutting produces risk of injuries and burns.	*Ensure safety guards and goggles are used. *During swarf removal and machine cleaning ensure the machine is stopped and wear gloves. Please use tools, such as cutting nippers and cutting clippers.
	⊙In cutting, sparks, hot chips and heat generation caused by tool breakage provides a risk of igniting a fire.	*Avoid using cutting tools in places where there is a possibility of igniting a fire. *In case of using non-water soluble oil, make sure to have a fire prevention countermeasure.
	⊙Using machines, chucks, and tools with poor balance at high revolutions may cause tools to break providing risk of injuries.	*Ensure safety guards and goggles are used. *Check the machine for vibration, chattering, and abnormal noise.
	⊙Handling machined parts with burrs using bare hands may cause injuries.	*Wear gloves.
Indexable Inserts Type Tools	⊙If inserts and spare parts are not held securely, they may become loose and be expelled producing risk of injuries.	*Clean insert locating seat and spare parts before setting inserts. *Use the tool provided for setting inserts, and ensure the inserts and spare parts are clamped securely. Do not use the tool provided for things other than prescribed inserts and spare parts.
	⊙Clamping inserts and spare parts too tightly by using tools such as extension pipes may cause them to break and be expelled.	*Do not use extra tools for more leverage. Only use the tool provided.
	⊙When applying high cutting speed, spare parts and inserts may be expelled due to centrifugal force. Pay special attention on each safety guideline.	*Refer to the handling explanatory notes and catalogues. Use tools under recommended cutting conditions.
Cutters and Other Rotating Tools	⊙Milling cutters have sharp edges. Handling them with bare hands may cause injuries.	*Take precautions such as wearing gloves.
	⊙Poor balance or off center revolving of tools may cause vibration and chattering which could cause the tool to break and be expelled.	*Apply cutting speed within the range of recommended cutting conditions. *Adjust accuracy and balance of spindles and bearings periodically to prevent off center revolving and chattering caused by wear on these parts.
Drilling Tools	⊙Through cutting in cases when the workpiece revolves may produce a disk shaped peice with sharp edges when the cutting tool breaks through.	*Ensure safety guards and goggles are used. Also install a cover on the chuck.
	⊙Drills with an extremely small diameter have a very sharp point which may puncture the skin if not handled carefully. If the drill breaks during cutting, the broken pieces may be expelled.	*Handle with care. Take precautions such as wearing gloves and goggles.
Brazed Tools	⊙Weakening of the braze and breakage of inserts may cause injury.	*Before using them, ensure they are brazed securely. *Do not use them under conditions which produce very high temperature.
Others	⊙Machine and tools may be damaged if they are used for purposes other than the prescribed application.	*Use them strictly for the prescribed application.

INFORMATION

This catalogue completes the basic precautions for safety use of our company's products. For further information, please refer to the guideline, catalogues or contact us. We are not responsible for any accidents causing by modifying tools without our permission.