

INDEX

INDEX FOR TOOL NUMBER

A.....	2
B.....	2
C.....	3
D.....	4
E.....	5
F.....	5
G.....	5
H.....	6
I.....	6
J.....	6
K.....	7
L.....	7
M.....	7
N.....	8
O.....	9
P.....	9
Q.....	9
R.....	9
S.....	9
T.....	11
U.....	12
V.....	12
W.....	13
X.....	14
Z.....	14

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
A					
A000-DCLNR/L12	DOUBLE CLAMP DIMPLE BAR	E014	APX3000R000WA000A	APX3000 type end mill	K030
A000-DDUNR/L15	DOUBLE CLAMP DIMPLE BAR	E014	APX4000-000A00RA	APX4000 type face mill	K038
A000-DSKNR/L12	DOUBLE CLAMP DIMPLE BAR	E015	APX4000R000M00A00	APX4000 type end mill	K038
A000-DTFNR/L16	DOUBLE CLAMP DIMPLE BAR	E015	APX4000R000SA000A	APX4000 type end mill	K037
A000-DVUNR/L16	DOUBLE CLAMP DIMPLE BAR	E016	APX4000R000WA000A	APX4000 type end mill	K036
A000-DWLNRL/L00	DOUBLE CLAMP DIMPLE BAR	E016	APX4K-000A00A000RA	APX4000 type end mill	K042
A000-PCLNR/L00	P type boring bar	E037	APX4KR000000000000A	APX4000 type end mill	K042
A000-PDQNR/L00	P type boring bar	E038	AQXR00000A/N00S/L	AQX type end mill	K054,K055
A000-PDUNR/L00	P type boring bar	E037	AQXR000M00A00	AQX type end mill	K056
A000-PDZNR/L00	P type boring bar	E039	ASS0	Spring (For AJX/BRE/CV type cutter)	C032 K062—K065,K116
A000-PSKNR/L00	P type boring bar	E036	ASX400-000000R	ASX400 type face mill	K026
A000-PTFNR/L00	P type boring bar	E036	ASX400R000M16	ASX400 type end mill	K027
A000-PWLNRL/L00	P type boring bar	E038	ASX400R000S32	ASX400 type end mill	K027
A40T-DVUNR/L16	DOUBLE CLAMP DIMPLE BAR	E016	ASX445-000000R/L	ASX445 type face mill	K010
A50UMWLNRO8	M type boring bar	E040	ASX445R000S32	ASX445 type end mill	K011
AEMW000000ER	Insert (For BAE type end mill)	J021	AXD4000-000000R0	AXD4000 type face mill	K044
AHX640S-000000R	AHX type face milling cutter	K018	AXD4000R000SA000A/B	AXD4000 type end mill	K045
AHX640W-000000R/L	AHX type face milling cutter	K016	AXD7000-000000R0	AXD7000 type face mill	K050
AJS0000T00	Clamp screw	M003	AXD7000R00000A-H63A	AXD7000 type end mill	K051
AJX00-00000000	AJX type face milling cutter	K067	AXD7000R000SA00S0	AXD7000 type end mill	K050
AJX00-0000000R	AJX type face milling cutter	K062	B		
AJX00R0000000	AJX type face milling cutter	K062,K067	BCP000	Shim pin	M013
AJX00R000AM00	AJX type face milling cutter	K063	BF-CCGT0000000002	Insert (Class G tolerance)	B035
AJX00R000SA00S/L/ES/EL	AJX type end mill	K064,K065	BF-CNGG0000000004	Insert (Class G tolerance)	B022
AM2MB	ALIMASTER end mill	I294	BF-CNGM0000000002	Insert (Class G tolerance)	B023
AM2MR	ALIMASTER end mill	I289	BF-DCGT0000000002	Insert (Class G tolerance)	B037
AM2SC	ALIMASTER end mill	I290	BF-DNGG0000000004	Insert (Class G tolerance)	B024
AM2SCRB	ALIMASTER end mill	I295,I296	BF-DNGM0000000002	Insert (Class G tolerance)	B025
AM3MF	ALIMASTER end mill	I292	BM-CNGM0000000TA2	Insert (Class G tolerance)	B023
AM3SS	ALIMASTER end mill	I291	BM-DNGM0000000TA2	Insert (Class G tolerance)	B026
AM3SSRB	ALIMASTER end mill	I298,I299	BM-TNGM0000000003	Insert (Class G tolerance)	B028
AM4MF	ALIMASTER end mill	I293	BOES101	Set bolt	M009
AMMR	ALIMASTER end mill	I302	BPT322	Shim	M010
AMS0	Clamp bridge	M014	BRA0000S00	BRA type drill	L154,L155
AMSR	ALIMASTER end mill	I300	BRM00000S00	BRM type drill	L152
AMSRRB	ALIMASTER end mill	I304	BRP00R000ELS00	BRP type end mill	K076
AOGT000000PEFR-GM	Insert (For APX3000 type cutter)	J020,K033	BRP00R000LS00	BRP type end mill	K076
AOMT000000PEER-M/H	Insert (For APX3000*4000 type cutter)	J020 K033,K039	BRP00R000S00	BRP type end mill	K076
APGT000000PDRF-G2	Insert (For BAP300*400 type cutter)	J021	BRPN-0000000R	BRP type face milling cutter	K075
APMT000000PDER-H0	Insert (For BAP300*400/SRM2 type cutter)	J021,K105	BRPNR000M00	BRP type end mill	K075
APMT000000PDER-M0	Insert (For BAP300*400/SRM2 type cutter)	J021,K105	BRPOP-0000000R	BRP type face milling cutter	K075
APX3000-000A00RA	APX3000 type face mill	K032	BRS000	Clamp screw	M003
APX3000R000000A	APX3000 type end mill	K032	BRS0000S00	BRS type drill	L150
APX3000R000M00A	APX3000 type end mill	K032	BTahr/L0000-50	Small tools holder (External back turning)	D012
APX3000R000SA000A	APX3000 type end mill	K031	BTAT000000R/L-B	Insert for external back turning	D012
			BTAT605000RX	Insert for external back turning	D012
			BTBT000000R/L-B	Insert for external back turning	D013
			BTBT606000R/L	Insert for external back turning	D013

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
BTVHR○○○○○-75○	Small tools holder (External back turning) ...	D014	CCMT○○○○○○○-LP	Insert (Class M tolerance)	A128
BTVT○○○○○○○R-B	Insert for external back turning	D014	CCMT○○○○○○○-MK	Insert (Class M tolerance)	A129
C					
○○○SCLCR○○	S type boring bar (Carbide shank)....	E017,E031	CCMT○○○○○○○-MM	Insert (Class M tolerance)	A129
○○○SDQCR○○	S type boring bar (Carbide shank).....	E032	CCMT○○○○○○○-MP	Insert (Class M tolerance)	A129
○○○SDUCR○○	S type boring bar (Carbide shank).....	E030	CCMT○○○○○○○-MW	Insert (Class M tolerance)	A130
○○○STFCR○○	S type boring bar (Carbide shank).....	E029	CCMT○○○○○○○-SW	Insert (Class M tolerance)	A128
○○○SVQCR○○	S type boring bar (Carbide shank).....	E033	CCMW○○○○○○○	Insert (Class M tolerance)	A131,B051
○○○SWUBR○○	MICRO-DEX boring bar (Carbide shank) ...	E017	CCMX○○○○○○○EN-○	Insert (For DCCC type end mill)	J022
○○FR-BLS	MICRO-MINI boring bar (Solid carbide)	E023,F135	CCPO○	Shim pin.....	M013
○○HR-BLS	MICRO-MINI boring bar (Solid carbide)	E023,F135	CCTC1	Clamp bridge	M014
C07KSTUCR06	MICRO-DEX boring bar (Carbide shank) ...	E018	CESPR○○○S○○	CESP type end mill.....	K106
CA○○○	Clamp bridge	M014	CFSPR○○○S○○	CFSP type end mill.....	K106
CAS○○T	Set screw	M003	CG○○RS-○○○	MICRO-MINI TWIN.....	F131
CB○○RS	MICRO-MINI TWIN.....	E020	CGSPR○○○S○○	CGSP type end mill	K106
CB○○RS-○○	MICRO-MINI TWIN.....	E020	CK○○○	Clamp bridge	M014
CB○○RS-○○B	MICRO-MINI TWIN.....	E020	CKW6	Clamp bridge	M015
CB○○RS-B	MICRO-MINI TWIN.....	E020	CNGA○○○○○○○	Insert (Class G tolerance).....	B023
CBJPR○○○S○○	CBJP type end mill	K108	CNGG○○○○○○○-FJ	Insert (Class G tolerance).....	A092
CBMPR○○○S○○	CBMP type end mill	K108	CNGG○○○○○○○-MJ	Insert (Class G tolerance).....	A093
CBN2XLB	CBN end mill.....	I285	CNGG○○○○○○○-PK	Insert (Class G tolerance).....	A092
CBN2XLRB	CBN end mill.....	I287	CNGN○○○○○○○	Insert (Class G tolerance).....	B032
CBS○	Breaker piece	M016	CNMA○○○○○○○	Insert (Class M tolerance)	A097,B048
CBS○D	Breaker piece	M016	CNMG○○○○○○○	Insert (Class M tolerance)	A095
CBT○	Breaker piece	M016	CNMG○○○○○○○-FH	Insert (Class M tolerance)	A092
CBT○○	Breaker piece	M016	CNMG○○○○○○○-FS	Insert (Class M tolerance)	A092
CBT○○○○	Breaker piece	M016	CNMG○○○○○○○-FY	Insert (Class M tolerance)	A092
CCET○○○○○○○R/L-SN	Insert (Class E tolerance).....	A130,A131	CNMG○○○○○○○-GH	Insert (Class M tolerance)	A096
CCET○○○○○○○R/L-SR	Insert (Class E tolerance).....	A130	CNMG○○○○○○○-GJ	Insert (Class M tolerance)	A097
CCET○○○○○○○R/LW-SN	Insert (Class E tolerance).....	A131	CNMG○○○○○○○-GK	Insert (Class M tolerance)	A096
CCGH○○○○○○○R/L-F	Insert (Class G tolerance).....	A128	CNMG○○○○○○○-GM	Insert (Class M tolerance)	A095
CCGT○○○○○○○-AZ	Insert (Class G tolerance).....	A127	CNMG○○○○○○○-LK	Insert (Class M tolerance)	A093
CCGT○○○○○○○-FJ	Insert (Class G tolerance).....	A127	CNMG○○○○○○○-LM	Insert (Class M tolerance)	A092
CCGT○○○○○○○L-F	Insert (Class G tolerance).....	A128	CNMG○○○○○○○-LP	Insert (Class M tolerance)	A092
CCGT○○○○○○○R/L-SN	Insert (Class G tolerance).....	A131	CNMG○○○○○○○-LS	Insert (Class M tolerance)	A093
CCGT○○○○○○○R/L-SS	Insert (Class G tolerance).....	A129	CNMG○○○○○○○-MA	Insert (Class M tolerance)	A095
CCGT○○○○○○○-SMG	Insert (Class G tolerance).....	A131	CNMG○○○○○○○-MH	Insert (Class M tolerance)	A095
CCGW○○○○○○○	Insert (Class G tolerance).....	A132	CNMG○○○○○○○-MJ	Insert (Class M tolerance)	A093
CCGW○○○○○○○FS	Insert (Class G tolerance).....	B035	CNMG○○○○○○○-MK	Insert (Class M tolerance)	A094
CCK○○	Clamp bridge	M014	CNMG○○○○○○○-MM	Insert (Class M tolerance)	A094
CCMH○○○○○○○-MV	Insert (Class M tolerance)	A130	CNMG○○○○○○○-MP	Insert (Class M tolerance)	A094
CCMH○○○○○○○-SV	Insert (Class M tolerance)	A128	CNMG○○○○○○○-MS	Insert (Class M tolerance)	A094
CCMT○○○○○○○	Insert (Class M tolerance)	A129	CNMG○○○○○○○-MW	Insert (Class M tolerance)	A095
CCMT○○○○○○○-FM	Insert (Class M tolerance)	A127	CNMG○○○○○○○-RK	Insert (Class M tolerance)	A096
CCMT○○○○○○○-FP	Insert (Class M tolerance)	A127	CNMG○○○○○○○-RM	Insert (Class M tolerance)	A096
CCMT○○○○○○○-FV	Insert (Class M tolerance)	A127	CNMG○○○○○○○-RP	Insert (Class M tolerance)	A096
CCMT○○○○○○○-LM	Insert (Class M tolerance)	A128	CNMG○○○○○○○-RS	Insert (Class M tolerance)	A096
			CNMG○○○○○○○-SA	Insert (Class M tolerance)	A093
			CNMG○○○○○○○-SH	Insert (Class M tolerance)	A093
			CNMG○○○○○○○-SW	Insert (Class M tolerance)	A093
			CNMG○○○○○○○-SY	Insert (Class M tolerance)	A093

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
CNMM○○○○○-HV	Insert (Class M tolerance)	A097	CTCHR/L○○○○-200	Small tools holder (External cutting off)	D021
CNMM○○○○○-HX	Insert (Class M tolerance)	A097	CTCT○○○○○○○-B	Insert for cutting off	D021
CNMM○○○○○-HZ	Insert (Class M tolerance)	A097	CTDHR/L1616-○○○	Small tools holder (External cutting off)	D022
CPGT○○○○○	Insert (Class G tolerance)	A133,B051	CTDT○○○○○○○-B	Insert for cutting off	D022
CPGT○○○○○R/L-F	Insert (Class G tolerance)	A133	CTDT○○○○○○○-B○	Insert for cutting off	D022
CPMH○○○○○-FV	Insert (Class M tolerance)	A133	CTE○TN/P○	Shim (For MMTE holder)	G012
CPMH○○○○○-MV	Insert (Class M tolerance)	A133	CTEHR/L1616-○○○	Small tools holder (External cutting off)	D023
CPMH○○○○○R/L-F	Insert (Class M tolerance)	A133	CTET○○○○○○○-B	Insert for cutting off	D023
CPMH○○○○○-SV	Insert (Class M tolerance)	A133	CTET○○○○○○○-B○	Insert for cutting off	D023
CPMT○○○○○ZPEN-M○	Insert (For PMR type end mill)	J022,K114	CTI○TN/P○	Shim (For MMTI holder)	G013
CPMX○○○○○	Insert (Class M tolerance)	A133	CWAHX640WN	Wedge	K016
CPT○	Side lock plate	C017,C018,C023	CWSG20SN	Wedge-S	K021
CR○	Stop ring	G012,G013	CWSG20TR	Wedge-T	K021
CR○RS-○	MICRO-MINI TWIN	E021	D		
CR○RS-○B	MICRO-MINI TWIN	E021	DC○○○T	Clamp screw	M003
CRN2MB	CRN end mill	I258	DCET○○○○○R/L-SN	Insert (Class E tolerance)	A137
CRN2MRB	CRN end mill	I264	DCET○○○○○R/L-SR	Insert (Class E tolerance)	A136
CRN2MS	CRN end mill	I252	DCET○○○○○R/LW-SN	Insert (Class E tolerance)	A137
CRN2XL	CRN end mill	I254,I255	DCGT○○○○○-AZ	Insert (Class G tolerance)	A134
CRN2XLB	CRN end mill	I260-I262	DCGT○○○○○R/L-F	Insert (Class G tolerance)	A134
CRN2XLRB	CRN end mill	I266,I267	DCGT○○○○○R/L-SN	Insert (Class G tolerance)	A137
CRN4JC	CRN end mill	I257	DCGT○○○○○R/L-SS	Insert (Class G tolerance)	A135
CS○	Clamp screw	M003	DCGT○○○○○-SMG	Insert (Class G tolerance)	A137
CS○	Shim	M010	DCGW○○○○○	Insert (Class G tolerance)	A138
CS○○○○○T	Clamp screw	M003	DCGW○○○○○FS	Insert (Class G tolerance)	B038
CS○○○○○TS	Clamp screw	M003	DCK○○○	Clamp bridge	M015
CS○○○T	Clamp screw	M003	DCLNR/L○○○○○○○	DOUBLE CLAMP holder	C008
CSF401260T	Clamp screw	M003	DCLNR/L○○○○○○○-T	DOUBLE CLAMP holder	C008
CSVHR/L○○○○	Small tools holder (For cam tool posts)	D027	DCMT○○○○○	Insert (Class M tolerance)	A136
CSVTB○○○R/L	Insert for external back turning	D028	DCMT○○○○○-FM	Insert (Class M tolerance)	A134
CSVTB○○○R-B	Insert for external back turning	D028	DCMT○○○○○-FP	Insert (Class M tolerance)	A134
CSVTBXL	Insert for external back turning, Copying	D028	DCMT○○○○○-FV	Insert (Class M tolerance)	A134
CSVTC○○○○R/L	Insert for external cutting off	D028	DCMT○○○○○-LM	Insert (Class M tolerance)	A135
CSVTC○○○○R-B	Insert for external cutting off	D028	DCMT○○○○○-LP	Insert (Class M tolerance)	A134
CSVTF○○○R/L	Insert for external front turning	D027	DCMT○○○○○-MK	Insert (Class M tolerance)	A135
CSVTF○○○R/L-B	Insert for external front turning	D027	DCMT○○○○○-MM	Insert (Class M tolerance)	A135
CSVTFXL	Insert for external front turning, Copying	D027	DCMT○○○○○-MP	Insert (Class M tolerance)	A135
CSVTG○○○○R/L	Insert for grooving	D029	DCMT○○○○○-MV	Insert (Class M tolerance)	A136
CSVTT60050RR/L	Insert for threading	D029	DCMT○○○○○-SV	Insert (Class M tolerance)	A135
CT○	Shim	M010	DCMW○○○○○	Insert (Class M tolerance)	A138,B052
CT○RS-M○	MICRO-MINI TWIN	G026	DCS○	Spring	C008,C010,C017,C019-C022 E014-E016
CT32T1	Shim	M011	DCSVN32	Shim	M010
CTAHR/L○○○○-120	Small tools holder (External cutting off)	D018	DDJNR/L○○○○○○○	DOUBLE CLAMP holder	C010
CTAHR1010-120S	Small tools holder (External cutting off)	D018	DDJNR/L○○○○○15-T	DOUBLE CLAMP holder	C010
CTAT○○○○○○○-B	Insert for cutting off	D019	DEGX○○○○○R/L	Insert (For AL holder)	A139
CTAT○○○○○○○-BX	Insert for cutting off	D019	DEGX○○○○○R/L-F	Insert (For AL holder)	A139,B052
CTAT○○○○○○○LL/RR	Insert for cutting off	D019	DF2MB	Diamond(DF) coated end mill	I277
CTBHR/L○○○○-160	Small tools holder (External back turning, External cutting off)	D013,D020	DF2XLB	Diamond(DF) coated end mill	I278,I279
CTBT○○○○○○○-B	Insert for cutting off	D020			

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
DF3XB.....	Diamond(DF) coated end mill.....	I281	DWLNR/L.....	DOUBLE CLAMP holder.....	C022
DF4JC.....	Diamond(DF) coated end mill.....	I274	DWLNR/L.....06-T.....	DOUBLE CLAMP holder.....	C022
DF4XL.....	Diamond(DF) coated end mill.....	I275	E		
DFC4JC.....	Diamond(DFC) coated end mill.....	I272	E.....	Stop ring.....	C019—C021
DFCJRT.....	Diamond(DFC) coated end mill.....	I273	EGS.....	Clamp screw.....	M004
DFPSRB.....	Diamond(DF) coated end mill.....	I283	ESS42.....	Shim.....	M010
DKS.....	Clamp screw.....	M003	EST.....	Shim.....	M010
DLC2MA.....	DLC coated end mill.....	I268	F		
DLC2MB.....	DLC coated end mill.....	I270	FC400890T.....	Clamp screw.....	M004
DNGA.....	Insert (Class G tolerance).....	A103,B048	FCTU.....R/L.....	FCTU type boring bar.....	E027
DNGG.....-FJ.....	Insert (Class G tolerance).....	A098	FSCLC1008R/L-06A.....	DIMPLE BAR.....	E007
DNGG.....-PK.....	Insert (Class G tolerance).....	A098	FSCLC1008R/L-06E.....	DIMPLE BAR (Carbide shank).....	E007
DNGG.....R/L.....	Insert (Class G tolerance).....	A102	FSCLC1008R/L-06E-.....	DIMPLE BAR (Carbide shank).....	E007
DNGM.....-MJ.....	Insert (Class G tolerance).....	A100	FSCLP.....R/L-.....A.....	DIMPLE BAR.....	E007
DNGN.....	Insert (Class G tolerance).....	B032	FSCLP.....R/L-.....E.....	DIMPLE BAR (Carbide shank).....	E007
DNMA.....	Insert (Class M tolerance).....	A103	FSCLP.....R-.....E-.....	DIMPLE BAR (Carbide shank).....	E007
DNMG.....	Insert (Class M tolerance).....	A101	FSDQC.....R/L-.....A.....	DIMPLE BAR.....	E010
DNMG.....-FH.....	Insert (Class M tolerance).....	A098	FSDQC.....R/L-.....E.....	DIMPLE BAR (Carbide shank).....	E010
DNMG.....-FS.....	Insert (Class M tolerance).....	A098	FSDUC.....R/L-.....A.....	DIMPLE BAR.....	E009
DNMG.....-FY.....	Insert (Class M tolerance).....	A098	FSDUC.....R/L-.....E.....	DIMPLE BAR (Carbide shank).....	E009
DNMG.....-GH.....	Insert (Class M tolerance).....	A103	FSL5.....R.....	FSL5 type boring bar.....	F136,G030
DNMG.....-GJ.....	Insert (Class M tolerance).....	A103	FSTU.....R/L.....	FSTU type boring bar.....	E026
DNMG.....-GK.....	Insert (Class M tolerance).....	A102	FSTUP.....R/L-.....A.....	DIMPLE BAR.....	E008
DNMG.....-GM.....	Insert (Class M tolerance).....	A101	FSTUP.....R/L-.....E.....	DIMPLE BAR (Carbide shank).....	E008
DNMG.....-LK.....	Insert (Class M tolerance).....	A099	FSTUP.....R-.....E-.....	DIMPLE BAR (Carbide shank).....	E008
DNMG.....-LM.....	Insert (Class M tolerance).....	A099	FSVJB.....R/L-11S.....	DIMPLE BAR.....	E013
DNMG.....-LP.....	Insert (Class M tolerance).....	A098	FSVJC.....R/L-08S.....	DIMPLE BAR.....	E013
DNMG.....-LS.....	Insert (Class M tolerance).....	A099	FSVPB.....R/L-.....A.....	DIMPLE BAR.....	E012
DNMG.....-MA.....	Insert (Class M tolerance).....	A101	FSVPC1610R/L-08A.....	DIMPLE BAR.....	E012
DNMG.....-MH.....	Insert (Class M tolerance).....	A101	FSVUB.....R/L-.....A.....	DIMPLE BAR.....	E012
DNMG.....-MJ.....	Insert (Class M tolerance).....	A100	FSVUC1612R/L-08A.....	DIMPLE BAR.....	E012
DNMG.....-MK.....	Insert (Class M tolerance).....	A100	FSWL.....R/L.....	FSWL type boring bar.....	E028
DNMG.....-MM.....	Insert (Class M tolerance).....	A100	FSWUB.....R/L-L3A.....	DIMPLE BAR.....	E011
DNMG.....-MP.....	Insert (Class M tolerance).....	A100	FSWUB.....R/L-L3E.....	DIMPLE BAR (Carbide shank).....	E011
DNMG.....-MS.....	Insert (Class M tolerance).....	A101	FSWUB.....R-L3E-.....	DIMPLE BAR (Carbide shank).....	E011
DNMG.....-RK.....	Insert (Class M tolerance).....	A102	FSWUP.....R/L-.....A.....	DIMPLE BAR.....	E011
DNMG.....-RM.....	Insert (Class M tolerance).....	A102	FSWUP.....R/L-.....E.....	DIMPLE BAR (Carbide shank).....	E011
DNMG.....-RP.....	Insert (Class M tolerance).....	A102	FSWUP.....R-.....E-.....	DIMPLE BAR (Carbide shank).....	E011
DNMG.....-RS.....	Insert (Class M tolerance).....	A102	G		
DNMG.....-SA.....	Insert (Class M tolerance).....	A099	GCMT040204-U.....	Insert (For TAF type drill).....	L139,L145
DNMG.....-SH.....	Insert (Class M tolerance).....	A099	GPMT.....U.....	Insert (For TAF type drill).....	L139—L145
DNMG.....-SY.....	Insert (Class M tolerance).....	A099	GT.....HR/L.....	Small tools holder (External grooving).....	D016
DNMM.....-HZ.....	Insert (Class M tolerance).....	A103	GT.....T.....R/L-E.....	Insert for external grooving.....	D017
DNMX.....-MW.....	Insert (Class M tolerance).....	A101	GT.....T.....R/L-U.....	Insert for external grooving.....	D016
DNMX.....-SW.....	Insert (Class M tolerance).....	A099	GT.....T.....R-VT.....	Insert for external grooving.....	D017
DTGNR/L.....16.....	DOUBLE CLAMP holder.....	C017	GT.....TR/L.....	Insert (Blank).....	D017
DTGNR/L.....16-T.....	DOUBLE CLAMP holder.....	C017	GY05016S.....	Clamp screw.....	M004
DVJNR/L.....16.....	DOUBLE CLAMP holder.....	C019			
DVPNR/L.....16.....	DOUBLE CLAMP holder.....	C021			
DVVNN.....16.....	DOUBLE CLAMP holder.....	C020			

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
GY06013M	Clamp screw	M004	H63TH-EV2525R/L-112	HSK external turning tool holder	H019
GY1B	Insert (For GY holder)	F016	H63TH-MGHR/L-DX	HSK MG type holder	H014
GY1G	Insert (For GY holder)	B045,F016	H63TH-MMTENR-H/L16	HSK MMT type holder	H016
GY2B	Insert (For GY holder)	F016	H63TH-MMTER-DX16	HSK MMT type holder	H016
GY2G	Insert (For GY holder)	F015	H63TH-MTHR/L-DX43	HSK MT type holder	H017
GY2M	Insert (For GY holder)	F016	H63TH-PCLNR/L-DX12	HSK PCLN type holder	H006
GY2M	Insert (For GY holder)	F014	H63TH-PCMNN-H/L12	HSK PCMN type holder	H007
GY2M	Insert (For GY holder)	F014	H63TH-PDJNR/L-DX15	HSK PDJN type holder	H009
GY2M	Insert (For GY holder)	F014	H63TH-PDNNN-H/L15	HSK PDNN type holder	H010
GY2M	Insert (For GY holder)	F016	H63TH-PRDCN-H/L12	HSK PRDC type holder	H012
GY2M	Insert (For GY holder)	F015	H63TH-PRGCR/L-DX12	HSK PRGC type holder	H012
GY2M	Insert (For GY holder)	F014	H63TH-SVPBR/L-DX16	HSK SVPB type holder	H013
GYAR/L	GY boring bar	F112	H63TH-SVVBH-H/L16	HSK SVVB type holder	H013
GYAR/L	GY boring bar	F112	HBH	Clamp screw	M002
GYAR/L	GY boring bar	F114	HBHA	Clamp screw	M002
GYAR/L	GY boring bar	F114	HDS	Clamp screw	M009
GYAR/L	GY boring bar	F116	HFF06015	Clamp screw	M004
GYDR/L	GY boring bar	F112—F116	HFF08043H	Clamp screw	M009
GYHR/L	GY holder	F018—F028,F048—F090	HGM-PT	Plug	E036—E040
GYHR/L	GY holder	F038		H007,H010,H012,H013,H016,H019	
GYHR/L	GY holder	F032—F036,F092—F102	HKY	Driver	M002
GYM	Modular blade	F018,F032,F112	HKY	Flag wrench	M002
GYM	Modular blade	F048—F054,F092	HKY	L-wrench	M002
GYM	Modular blade	F020,F032,F112	HKY	L-wrench	M002
GYM	Modular blade	F056—F062,F094	HKY	T-wrench	M002
GYM	Modular blade	F022,F034,F114	HKY	Flag wrench	M002
GYM	Modular blade	F064—F070,F096	HLS	Lever spring	K110
GYM	Modular blade	F024,F034,F114	HP	Clamp pin	E036—E039
GYM	Modular blade	F072—F078,F098	HS	Clamp screw	M004
GYM	Modular blade	F026,F036,F116	HSC	Clamp screw	M002
GYM	Modular blade	F080—F086,F100	HSC	Set bolt	M009
GYM	Modular blade	F028,F036,F116	HSP05008C	Lock screw	M004
GYM	Modular blade	F088,F090,F102	HSS	Clamp screw	M002
GYM	Modular blade	F038	HY	Bush screw	M004
GYPR/L	GY holder	F030	HY-A1	Bush screw	M004
			HY-V1	Bush screw	M004
H			I		
H100TH-B	HSK boring bar holder	H022	IMX	Indexable head end mill	I338
H100TH-EN3232R/L-130	HSK external turning tool holder	H020	IMX	Wrench (For IMX type end mill)	I338
H100TH-EV3232R/L-180	HSK external turning tool holder	H019	IMX	Indexable head end mill	I325,I326,I335,I337
H63TH-A	HSK boring bar holder	H008	IMX	Indexable head end mill	I328,I333
H63TH-B	HSK boring bar holder	H021	IMX	Indexable head end mill	I327,I330,I336
H63TH-DCLNL-L12-3	HSK DCLN type holder	H008	IMX	Indexable head end mill	I329,I331
H63TH-DCLNR/L-DX12	HSK DCLN type holder	H006	IMX	Indexable head end mill	I332
H63TH-DCMNN-H/L12	HSK DCMN type holder	H007	IMX	Indexable head end mill	I334
H63TH-DDJNL-L15-3	HSK DDJN type holder	H011			
H63TH-DDJNR/L-DX15	HSK DDJN type holder	H009	J		
H63TH-DDNNN-H/L15	HSK DDNN type holder	H010	JDMT	Insert (For AJX type cutter)	J022,K066,K116
H63TH-EN2525R/L-115	HSK external turning tool holder	H020	JDMW	Insert (For AJX type cutter)	J022,K066,K116
H63TH-EV2020R/L-105-3	HSK external turning tool holder	H021			

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
JFS○	JUST FIT SLEEVE set number	L147	MCLNR○○○○○19	DOUBLE CLAMP holder	C009
JFS○○○○○	JUST FIT SLEEVE (JFS)	L147	MCS	MCS type drill	L185
JOMT○○○○○ZZSR-JM	Insert (For AJX type cutter)	J022,K066,K116	MES○	Spring	C016—C018,C023,E040,F128 H014,H017
JOMW○○○○○ZZSR-FT	Insert (For AJX type cutter)	J022,K066,K116	MGD○○	Driver	L056
JPMT060204○	Insert (For TAB/CBJP type end mill)	J023,K108	MGHR/L○○○○○○○○	MG holder	F128
JPMX○○○○○	Insert (For SPX type cutter)	J023,K089	MGS○○○○L○○○B	MGS type drill	L055
JSS○	Shim screw	M004	MGS6	Clamp screw	M005
K			MGTR/L○○○○○	Insert (For MG holder)	B046,F129,H015,K111
KGBN○○○	Tool block (For UG holder)	F126	MHK5NR/L	Clamp bridge	M015
KGC1	Clamp bridge	M015	MHS○○○○L○○○B	MHS type drill	L102—L109
KGTON	Insert (For UG holder)	F127	MHS○○○R/L	Shim	M011
KGTR/L	Insert (For UG holder)	F127	MHT1	Clamp screw	M005
KNUX○○○○○R/L-M○	Insert (Class U tolerance)	A124	MK1K	Anti seize lubricant	M017
KS○	Axial screw	M004	MK1KS	Anti seize lubricant	M017
KS○○	Set bolt	M004	MLCP42	Shim	M011
KS○S	Pre-set screw	M004	MLDP42	Shim	M011
KSMGR○○○	KSMG type end mill	K110	MLG○○○○L	Insert (For FSL5 type boring bar)	F137,G031
L			MLSP42	Shim	M011
LK1	Clamp bridge	M015	MLT○○○○L	Insert (For FSL5 type boring bar)	F137,G031
LLCL○○○	Clamp lever	M013	MLTP32	Shim	M011
LLCL○○S	Clamp lever	M013	MMS○○○○S/L-DIN	MMS type drill	L058—L069
LLCS○○○	Clamp screw	M005	MMS○○○○S/L-DIN-C	MMS type drill	L058—L069
LLCS○○○S	Clamp screw	M005	MMS○○○○X○DB	MMS type drill	L058—L069
LLP○○	Shim pin	M013	MMT○○ER○○○○○○○	Insert (For MMTE holder)	G014—G020
LLR○	Radial screw	M004	MMT○○IR○○○○○○○	Insert (For MMTI boring bar)	G015—G021
LLSCN○○	Shim	M010	MMTER○○○○○○○-C	MMTE holder	G012
LLSCP○○	Shim	M010	MMTIR○○○○A○○○-○○○	MMTI boring bar	G013
LLSDN○○	Shim	M010	MNS○○○○-L○○○	MNS type drill	L072—L089
LLSDP42	Shim	M010	MNS○○○○LB/X○○DB	MNS type drill	L072—L089
LLSRN○○○	Shim	M010	MNS○○○○S/L-DIN	MNS type drill DIN6537	(Whistle notch shank type) L072—L092
LLSSN○○	Shim	M010	MNS○○○○S/L-DIN-C	MNS type drill DIN6537	(Cylindrical shank type) L072—L092
LLSSP42	Shim	M010	MP2MB	MS Plus end mill	I136
LLSTE32	Shim	M011	MP2SB	MS Plus end mill	I135
LLSTN○○	Shim	M011	MP2SSB	MS Plus end mill	I134
LLSTP○○	Shim	M011	MP2XLB	MS Plus end mill	I138—I142
LLSWN○○○	Shim	M011	MP6	Shim pin	M013
LLSWP○○	Shim	M011	MPMT○○○○○	Insert (For CBMP/ECMP/TAB type end mill)	J023,K108
LS○	Clamp screw	M005	MPMW○○○○○	Insert (For TSMP type end mill)	J023,K107
LS○○	Clamp screw	M005	MPMX120412-○○	Insert (For SPX type end mill)	J023,K089
LS○○○○T	Clamp screw	M005	MPS○○○○-L○○○	MPS type drill	L035—L047
LS○○T	Clamp screw	M005	MPS○○○○S/L-DIN	MPS type drill DIN6537	(Whistle notch shank type) L035—L049
LS10TS	Clamp screw	M005	MPS○○○○S/L-DIN-C	MPS type drill DIN6537	(Cylindrical shank type) L035—L049
LS24H	Clamp screw	M005	MPS1-○○○○S/L-DIN	MPS1 type drill DIN6537	(Whistle notch shank type) L028—L033
M					
MAE○○○○MB	MAE type drill (External coolant)	L096—L100			
MAS○○○○LB/MB	MAS type drill (Internal coolant)	L096—L100			
MBA○○○○○H	Clamp screw	M009			

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
MPS1-○○○○S/L-DIN-C	MPS1 type drill DIN6537 (Cylindrical shank type)	L028-L033	MTJNR/L○○○○○○○N	WP holder	C016
MS2ES	MSTAR end mill	I068	MTKOR/L	Clamp bridge	M015
MS2JS	MSTAR end mill	I040	MTQNR/L○○○○○○○N	WP holder	C018
MS2LS	MSTAR end mill	I042	MTTR/L○○○○○○○	Insert (For MT holder/D type boring head)	G023,H018
MS2MB	MSTAR end mill	I075	MVX○○○○X○FO○	MVX type drill	L135-L137
MS2MB-E	MSTAR end mill	I127	MWE○○○○MA/SA	MWE type drill	L022-L025
MS2MC-E	MSTAR end mill	I116	MWLNR/L○○○○○○08	WP holder	C023
MS2MRB	MSTAR end mill	I087,I088	MWS○○○○SB/LB/XB	MWS type drill	L012-L015
MS2MS	MSTAR end mill	I037,I038	MWS○○○○X○○DB	MWS type drill	L014-L015
MS2MT	MSTAR end mill	I098-I101	N		
MS2MTB	MSTAR end mill	I114,I115	NNMU200○○ZEN-○○	Insert (For AHX type cutter)	J024,K017,K019
MS2SB	MSTAR end mill	I073,I074	NNMU200712ZER-MM	Insert (For AHX640S type cutter)	J024,K019
MS2SB-E	MSTAR end mill	I126	NP-CCGW○○○○○○○○○	Insert (Class G tolerance)	B035
MS2SS	MSTAR end mill	I036	NP-CCGW○○○○○○○○○2	Insert (Class G tolerance)	B034
MS2XB	MSTAR end mill	I083-I085	NP-CCGW○○○○○○○○W○2	Insert (Class G tolerance)	B035
MS2XL	MSTAR end mill	I044-I046	NP-CCMH○○○○○○○	Insert (Class M tolerance)	B051
MS2XL6	MSTAR end mill	I048,I049	NP-CCMW○○○○○○○	Insert (Class M tolerance)	B051
MS2XLB	MSTAR end mill	I077-I081	NP-CNGA○○○○○○○○○2	Insert (Class G tolerance)	B022,B023
MS2XLRB	MSTAR end mill	I090	NP-CNGA○○○○○○○○○4	Insert (Class G tolerance)	B022
MS3ES	MSTAR end mill	I069	NP-CNGA○○○○○○○○W○2	Insert (Class G tolerance)	B023
MS3MC-E	MSTAR end mill	I118	NP-CNGA○○○○○○○○W○4	Insert (Class G tolerance)	B022
MS4EC	MSTAR end mill	I071	NP-CNMM○○○○○○○R-F	Insert (Class M tolerance)	B048
MS4JC	MSTAR end mill	I062	NP-CPGB○○○○○○○○○2	Insert (Class G tolerance)	B036
MS4JC-E	MSTAR end mill	I122	NP-CPMH○○○○○○○	Insert (Class M tolerance)	B051
MS4LT	MSTAR end mill	I103-I108	NP-DCGW○○○○○○○○○2	Insert (Class G tolerance)	B037
MS4LTB	MSTAR end mill	I110-I112	NP-DCGW○○○○○○○○GS	Insert (Class G tolerance)	B038
MS4MC	MSTAR end mill	I060	NP-DCMT○○○○○○○R/L-F	Insert (Class M tolerance)	B052
MS4MC-E	MSTAR end mill	I120	NP-DNGA○○○○○○○○○2	Insert (Class G tolerance)	B024,B025
MS4MRB	MSTAR end mill	I092,I093	NP-DNGA○○○○○○○○○4	Insert (Class G tolerance)	B024
MS4MRB-E	MSTAR end mill	I129	NP-DNGA○○○○○○○GAWS2JR/L	Insert (Class G tolerance)	B025
MS4SC	MSTAR end mill	I059	NP-DNMM○○○○○○○R-F	Insert (Class M tolerance)	B048
MS4XL	MSTAR end mill	I064-I066	NP-SNGA○○○○○○○○○2	Insert (Class G tolerance)	B027
MS6MH-E/MS8MH-E	MSTAR end mill	I124	NP-SNGA○○○○○○○○○4	Insert (Class G tolerance)	B027
MSBNR○○○○○19	DOUBLE CLAMP holder	C012	NP-SNMM○○○○○○○R-F	Insert (Class M tolerance)	B049
MSCN63	Shim	M011	NP-TCGW○○○○○○○○○3	Insert (Class G tolerance)	B039
MSE○○○○SB	MSE type drill	L008,L009	NP-TCGW○○○○○○○○S	Insert (Class G tolerance)	B039
MSJHD	MSTAR end mill	I055	NP-TNGA○○○○○○○○○3	Insert (Class G tolerance)	B028
MSL○○○○-L○○C	MSL type drill	L050-L052	NP-TNGA○○○○○○○○○6	Insert (Class G tolerance)	B028
MSMHD	MSTAR end mill	I052,I053	NP-TNMM○○○○○○○R-F	Insert (Class M tolerance)	B049
MSMHDRB	MSTAR end mill	I095,I096	NP-TPGB○○○○○○○○○3	Insert (Class G tolerance)	B040
MSMHZD	MSTAR end mill	I057	NP-TPGX○○○○○○○○○3	Insert (Class G tolerance)	B040
MSP0300SB	MSP type starting drill	L011	NP-TPMH○○○○○○○R/L-F	Insert (Class M tolerance)	B054
MSSHD	MSTAR end mill	I051	NP-TPMX○○○○○○○R/L-F	Insert (Class M tolerance)	B054
MSSHV/MSMHV	MSTAR end mill	I131,I132	NP-VBGT○○○○○○○R-F	Insert (Class G tolerance)	B055
MSSN63	Shim	M011	NP-VBGW○○○○○○○○○2	Insert (Class G tolerance)	B041
MSSNR○○○○○19	DOUBLE CLAMP holder	C014	NP-VCGT○○○○○○○R-F	Insert (Class G tolerance)	B055
MT1R/L○○○○○○○	MT1 type holder	G022	NP-VCGW○○○○○○○○○2	Insert (Class G tolerance)	B042
MTENN○○○○○○○○N	WP holder	C017	NP-VNGA○○○○○○○○○2	Insert (Class G tolerance)	B030
MTHR/L○○○○○○○	MT holder	G022			

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
NP-VNGA○○○○○○○○○4Insert (Class G tolerance).....	B030	Q		
NP-VNMM○○○○○○○R-FInsert (Class M tolerance).....	B050	QOGT○○○○○R-G1Insert (For AQX type cutter).....	J025,K057
NP-WCMWL○○○○○FAInsert (Class M tolerance).....	B042	QOMT○○○○○R-M2Insert (For AQX type cutter).....	J025,K057
NP-WFC42ZFER2Wiper insert (For BF407 type cutter).....	J043	R		
NP-WNGA○○○○○○○○○3Insert (Class G tolerance).....	B031	RBH○○○○○NRound type holder (For MICRO-DEX/MICRO-MINI type boring bar)...	E019,E024,F133,G028
NP-WNGA○○○○○○○○○6Insert (Class G tolerance).....	B031	RCGT○○○○○M0-AZInsert (Class G tolerance).....	A140
NP-WNGA○○○○○○○○○GWS3Insert (Class G tolerance).....	B031	RCMT○○○○○M0Insert (Class M tolerance).....	A140
NS○○○Clamp screw.....	M006	RCMX○○○○○M0Insert (Class M tolerance).....	A140
NS○○○WClamp screw.....	M006	RCMX○○○○○M0-RRInsert (Class M tolerance).....	A140
O			RDHX○○○○○M0○Insert (Class H tolerance).....	J025
OCTACUT○○○○○○○OCTACUT type face milling cutter.....	K072	RDMX○○○○○M0○Insert (Class M tolerance).....	J025
OCTACUT○○○S○○○OCTACUT type end mill.....	K073	RDZX○○○○○M0○Insert (Class M tolerance).....	J026
OCTACUT0322SARBOCTACUT type end mill.....	K073	REMX○○○○○EN-JSInsert (For OCTACUT type cutter).....	J026,K073
OEMX○○○○○E○R1Insert (For OCTACUT type cutter).....	J024,K073	REMX○○○○○SNInsert (For OCTACUT type cutter).....	J026,K073
OEMX○○○○○E○R1-JSInsert (For OCTACUT type cutter).....	J024,K073	RGEN2004M0○NInsert (For SG20 type cutter).....	J026,K021
P			RNGN○○○○○Insert (Class G tolerance).....	B032
P○○○AMPin.....	E036—E039	RNMG○○○○○Insert (Class M tolerance).....	A104
P○○○USLock pin.....	M014	RN-S○Clamp screw.....	M006
P○○○WLock pin.....	M014	RN-S○○Clamp screw.....	M006
P○○○WSLock pin.....	M014	RPMM120400GInsert (Class M tolerance).....	J026
P○○SLock pin.....	M014	RPMT○○○○○M0E-JSInsert (For BRP type cutter).....	J026,K077
PCBNR/L○○○○○12LL holder.....	C009	RPMW○○○○○M0○Insert (For BRP type cutter).....	J027,K077
PCLNR/L○○○○○LL holder.....	C008	RRD○○○N-○○○○○RRRD type face mill.....	K080
PDHNR/L○○○○○15LL holder.....	C011	RRD○○○P-○○○○○RRRD type face mill.....	K080
PDJNR/L○○○○○15LL holder.....	C010	RRD○○○R○○○M○○RRD type end mill.....	K079
PMC○○R○○○AM○○○PMC type end mill.....	K116	RRD○○○R○○○S○○○RRD type end mill.....	K078
PMF○○○○○A○○RPMF type end mill.....	K112	RS○○○OTClamp screw.....	M006
PMFA13RCartridge (For PMF type end mill).....	K112	RTG○○AInsert (For TL type holder).....	A161,B043,C036
PMR○○○○○○○RPMR type end mill.....	K114	S		
PMR○○○○○○○A2○RPMR type end mill.....	K114	S○Clamp screw.....	M006
PRDCN○○○○○LL holder.....	C026	S○○○SCLCR/L○○S type boring bar (Steel shank).....	E031
PRGCR/L○○○○○LL holder.....	C026	S○○○SCZCR/L○○S type boring bar (Steel shank).....	E035
PS○○Shim.....	M010	S○○○SDQCR/L○○S type boring bar (Steel shank).....	E032
PSBNR/L○○○○○LL holder.....	C012	S○○○SDUCR/L○○S type boring bar (Steel shank).....	E030
PSDNN○○○○○LL holder.....	C013	S○○○SSKCR/L○○S type boring bar (Steel shank).....	E034
PSKNR/L○○○○○LL holder.....	C015	S○○○STFCR/L○○S type boring bar (Steel shank).....	E029
PSSNR/L○○○○○LL holder.....	C014	S○○○STFER/L○○AL type boring bar (Steel shank).....	E041
PSTNR/L○○○○○LL holder.....	C013	S○○○SVQCR/L○○S type boring bar (Steel shank).....	E033
PT○○Shim.....	M010	S○○○SVUCR/L○○S type boring bar (Steel shank).....	E034
PT○○○RShim.....	M011	SBAHR○○○○Boring holder.....	D030
PTFNR/L○○○○○LL holder.....	C018	SBAT○○○○○LInsert (For SBAHR type holder).....	D030
PTGNR/L○○○○○LL holder.....	C016	SBAT○○○○○L-BInsert (For SBAHR type holder).....	D030
PV○○○Shim.....	M012	SBH○○○○RSquare type holder (For MICRO-DEX/MICRO-MINI type boring bar)...	E025,F134,G029
PVJNR/L○○○○○16MP holder.....	C019			
PVPNR/L○○○○○16MP holder.....	C021			
PVVNN○○○○○16MP holder.....	C020			
PWLNR/L○○○○○06LL holder.....	C022			

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
SC00M00S000S/L	Straight arbor	K118	SNGG000000R/L	Insert (Class G tolerance)	A107
SC00M00S000S/LW	Straight arbor (Carbide shank)	K118	SNGN000000	Insert (Class G tolerance)	A125,B033
SC00M00S00-HSK63A	HSK63 arbor	K119	SNMA000000	Insert (Class M tolerance)	A109
SCACR/L00000000-SM	Small tools holder (External front turning)	D008	SNMF43B2G	Insert (For BN425/DN type cutter)	J029
SCLCR/L00000000	SP holder	C024	SNMG000000	Insert (Class M tolerance)	A107
SCLCR/L00000000-SM	Small tools holder (External front turning)	D008	SNMG000000-FH	Insert (Class M tolerance)	A105
SCMT000000	Insert (Class M tolerance)	A142	SNMG000000-FS	Insert (Class M tolerance)	A105
SCMT000000-FM	Insert (Class M tolerance)	A141	SNMG000000-GH	Insert (Class M tolerance)	A108
SCMT000000-FP	Insert (Class M tolerance)	A141	SNMG000000-GK	Insert (Class M tolerance)	A108
SCMT000000-FV	Insert (Class M tolerance)	A141	SNMG000000-GM	Insert (Class M tolerance)	A107
SCMT000000-LM	Insert (Class M tolerance)	A141	SNMG000000-LK	Insert (Class M tolerance)	A105
SCMT000000-LP	Insert (Class M tolerance)	A141	SNMG000000-LM	Insert (Class M tolerance)	A105
SCMT000000-MK	Insert (Class M tolerance)	A142	SNMG000000-LP	Insert (Class M tolerance)	A105
SCMT000000-MM	Insert (Class M tolerance)	A141	SNMG000000-MA	Insert (Class M tolerance)	A107
SCMT000000-MP	Insert (Class M tolerance)	A141	SNMG000000-MH	Insert (Class M tolerance)	A107
SCMW000000	Insert (Class M tolerance)	A142	SNMG000000-MK	Insert (Class M tolerance)	A106
SD00	Set bolt	M006	SNMG000000-MM	Insert (Class M tolerance)	A106
SDEN1203AEN	Insert (For corner angle 45°type cutter)	J027	SNMG000000-MP	Insert (Class M tolerance)	A106
SDJCR/L00000000	SP holder	C025	SNMG000000-MS	Insert (Class M tolerance)	A106
SDJCR/L00000000-SM	Small tools holder (External front turning)	D009	SNMG000000R/L-1G	Insert (Class M tolerance)	A106
SDJER/L00000015	AL holder	C033	SNMG000000-RK	Insert (Class M tolerance)	A108
SDNCN00000000	SP holder	C025	SNMG000000-RM	Insert (Class M tolerance)	A108
SDNCR/L00000000-SM	Small tools holder (External front turning)	D009	SNMG000000-RP	Insert (Class M tolerance)	A107
SDNEN00000015	AL holder	C033	SNMG000000-RS	Insert (Class M tolerance)	A108
SECN0000AF0N1	Insert (For SE445•545/LSE445 type cutter)	J027	SNMG000000-SA	Insert (Class M tolerance)	A105
SECN0000EF0R/L1	Insert (For SE415•515/QSE415 type cutter)	J028,J042	SNMG000000-SH	Insert (Class M tolerance)	A105
SECN1203AFFR1	Insert (For SE445 type cutter)	J042	SNMG000000-SY	Insert (Class M tolerance)	A106
SEEN0000AF0N0	Insert (For SE445•545 type cutter)	J027	SNMM000000-HV	Insert (Class M tolerance)	A109
SEEN0000EF0R/L0	Insert (For SE415•515/QSE415 type cutter)	J028	SNMM000000-HX	Insert (Class M tolerance)	A109
SEER0000AFEN-JS	Insert (For SE445•545/LSE445 type cutter)	J027,J028	SNMM000000-HXD	Insert (Class M tolerance)	A109
SEER1203EFER-JS	Insert (For SE•QSE415 type cutter)	J028	SNMM000000-HZ	Insert (Class M tolerance)	A108
SEET13T3AGEN-JL	Insert (For ASX445 type cutter)	J029,K012	SNMN000000	Insert (Class M tolerance)	A125,J030
SEEW1204AFTN	Insert (For corner angle 45°type cutter)	J028	SOET12T308PEER-JL	Insert (For ASX400 type cutter)	J030,K028
SEGT13T3AGFN-JP	Insert (For ASX445 type cutter)	J028,K012	SOGT12T308PEFR-JP	Insert (For ASX400 type cutter)	J030,K028
SEM1204AZTN	Insert (For corner angle 45°type cutter)	J028	SOMT12T300PEER/L00	Insert (For ASX400 type cutter)	J030,K028
SEMT13T3AGSN-FT	Insert (For ASX445 type cutter)	J029,K012	SOMX000000-UM	Insert (For MVX type drill)	L135—L137
SEMT13T3AGSN-JH	Insert (For ASX445 type cutter)	J029,K012	SONX1206PER	Insert (For VOX400 type cutter)	J030,K023
SEMT13T3AGSN-JM	Insert (For ASX445 type cutter)	J029,K012	SPEN0000EDR/L	Insert (For corner angle 15°type cutter)	J031
SETK00	Clamp bridge	M015	SPEN0000EEER/L1	Insert (For FBP415/QBP415 type cutter)	J031
SETS00	Clamp screw	M006	SPEN0000A	Insert (For FP490•590•690 type cutter)	J031
SFAN0000ZFFR/L2	Insert (For BF407 type cutter)	J029	SPER1203EEER-JS	Insert (For FBP415/QBP415 type cutter)	J031
SFCN0000ZFFR/L2	Insert (For BF•QBF407 type cutter)	J029,J042	SPGN000000	Insert (Class G tolerance)	A162,B043,B057,J031
SG20000000R	SG20 type face milling cutter	K021	SPGX000000	Insert (Class G tolerance)	A143,B053
SH000-FSDUCL00	SH holder	D026	SPKN1203EDR	Insert (For corner angle 15°type cutter)	J031
SL3200-90	Boring bar sleeve	H022	SPMB1204APT	Insert (For BSP type end mill)	J032
SLCS000	Clamp screw	M006	SPMN000000	Insert (Class M tolerance)	A162,J031
SMGHR00000016	SMG holder	F130,G024	SPMN000000T	Insert (Class M tolerance)	A162,J031
SMGTR000000000	Insert (For SMG holder)	F130,G025	SPMR000000	Insert (Class M tolerance)	A162
SMTTR000000000	Insert (For SMT holder)	F130,G025	SPMR000000-80	Insert (Class M tolerance)	A162
SNGA000000	Insert (Class G tolerance)	A109,B027	SPMT000000	Insert (Class M tolerance)	A143

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
SPMT120408-A	Insert (For TBE1 type end mill)	J032	SVPCR/L00000016	SP holder	C031
SPMW000000	Insert (Class M tolerance)	A143,J032,K106	SVPPR/L0000000-SM	Small tools holder (External front turning)	D011
SPMX120408-00	Insert (For SPX type end mill)	J032,K089	SVVBR/L0000000-SM	Small tools holder (External front turning)	D011
SPNN1203EDR	Insert (For corner angle 15° type cutter)	J032	SVVCN00000016	SP holder	C030
SPNN1203EEER/L1	Insert (For FBP-QBP415 type cutter)	J031	SXZCR/L00000015	Profile holder	C032
SPS0	Locator screw	M006	T		
SPSG20R	Locator (For SG20 type cutter)	K021	TAFL/M/S00000F00	TAF type drill	L139—L143
SPSVN32	Shim	M012	TAFL/M/S00000F00-E	TAF type drill	L144
SPX4-000A24A058RA	SPX type end mill	K088	TAWN00000S00	TAW type drill (General use)	L124—L128
SPX4R00000BT50N0	SPX type end mill	K087	TAWKH00000TG	Insert (For TAW type drill)	L124—L128,L131,L132
SPX4R00000SK50N0	SPX type end mill	K087	TAWNH00000T	Insert (For TAW type drill)	L124—L130
SPX4R05000MT5N0	SPX type end mill	K087	TBGN000000	Insert (Class G tolerance)	B044
SPX4R05000WN0	SPX type end mill	K087	TCGT000000-AZ	Insert (Class G tolerance)	A144
SRBT00	Insert (For SRB type)	J033,K094	TCGT000000R/L-F	Insert (Class G tolerance)	A144
SRDCN00000000	SP holder	C027	TCGW000000	Insert (Class G tolerance)	B053
SRFH000AM0000	SRF type end mill	K093,K097	TCGW000000FS	Insert (Class G tolerance)	B039
SRFH000S0000	SRF type end mill	K092,K093,K096,K097	TCMT000000	Insert (Class M tolerance)	A145
SRFT00	Insert (For SRF type end mill)	J033,K094	TCMT000000-FM	Insert (Class M tolerance)	A144
SRG00C	Insert (For SRM2 type end mill)	J033,K105	TCMT000000-FP	Insert (Class M tolerance)	A144
SRG00E	Insert (For SRM2 type end mill)	J033,K105	TCMT000000-FV	Insert (Class M tolerance)	A144
SRGCR/L00000000	SP holder	C027	TCMT000000-LM	Insert (Class M tolerance)	A145
SRK1R	Clamp bridge	M015	TCMT000000-LP	Insert (Class M tolerance)	A144
SRM00C-M	Insert (For SRM2 type end mill)	J034,K105	TCMT000000-MK	Insert (Class M tolerance)	A145
SRM00E-M	Insert (For SRM2 type end mill)	J034,K105	TCMT000000-MM	Insert (Class M tolerance)	A145
SRM2000AM000S/L00	SRM2 type end mill	K101	TCMT000000-MP	Insert (Class M tolerance)	A145
SRM20000L00NLM/S	SRM2 type end mill	K104	TCMW000000	Insert (Class M tolerance)	A145,B053
SRM20000M00L	SRM2 type end mill	K101	TECN00000PE0R1	Insert (For NSE300•400 type cutter)	J035,J042
SRM20000MNLM/S	SRM2 type end mill	K104	TECN1603PE0R1W	Insert (For NSE300/SE300 type cutter)	J035
SRM20000S00	SRM2 type end mill	K100,K101	TEEN00000PE0R/L0	Insert (For NSE300•400 type cutter)	J035
SRM20000SNLM/S	SRM2 type end mill	K104	TEER00000PEER-JS	Insert (For NSE300•400 type cutter)	J035
SRM20000WNLL/M/S/X	SRM2 type end mill	K104	TEGX000000	Insert (For AL holder)	B053
SRS5	Clamp screw	M006	TEGX000000R/L	Insert (For AL holder)	A146,B053
SSSCR/L00000000	SP holder	C028	TEKN00000PE0R	Insert (For NSE400 type cutter)	J035
STASX0000N	Shim	M012	TEKN00000PE0R/L1	Insert (For NSE400 type cutter)	J035
STAWN00000S00	STAW type drill	L115—L117	TIP15T	Wrench	K011
STAW0S00000S00	STAW type drill	L115—L117	TKY00D	Driver	M002
STAWK00000TG	Insert (For STAW type drill)	L120,L121	TKY00F	Flag wrench	M002
STAWN00000T	Insert (For STAW type drill)	L119	TKY00L	Long wrench	M002
STAWN00000TH	Insert (For STAW type drill)	L118,L119	TKY00R	L-wrench	M002
STBS500N	Shim	M012	TKY00T	T-wrench	M002
STFER/L00000016	AL holder	C034	TKY00W	Flag wrench	M002
STGCR/L00000000	SP holder	C029	TLHR000000	TL holder	C036
STGER/L00000016	AL holder	C034	TNGA000000	Insert (Class G tolerance)	A115,B029,B049
STPMR0N	Shim (For PMR type end mill)	K114	TNGG000000-PK	Insert (Class G tolerance)	A110
STS1	Shim screw	M006	TNGG000000R/L	Insert (Class G tolerance)	A114
SUFT00R00	Insert (For SUF type end mill)	J034,K098	TNGG000000R/L-F	Insert (Class G tolerance)	A110
SVJBR/L00000000-SM	Small tools holder (External front turning)	D010	TNGG000000R/L-FS	Insert (Class G tolerance)	A110
SVJCR/L00000000	SP holder	C030	TNGG000000R/L-K	Insert (Class G tolerance)	A112
SVJDR/L00000016	AL holder	C035	TNGN000000	Insert (Class G tolerance)	A126,B033
SVLPR/L00000000-SM	Small tools holder (External front turning)	D010			

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
TNMA○○○○○○○	Insert (Class M tolerance)	A115	TPNX1605N	Insert (For VIPER type end mill)	J036
TNMG○○○○○○○	Insert (Class M tolerance)	A113	TPS○	Clamp screw	M007
TNMG○○○○○○○-FH	Insert (Class M tolerance)	A110	TPS○○	Clamp screw	M007
TNMG○○○○○○○-FS	Insert (Class M tolerance)	A110	TPS○○○	Clamp screw	M007
TNMG○○○○○○○-FY	Insert (Class M tolerance)	A110	TS○	Clamp screw	M007
TNMG○○○○○○○-GH	Insert (Class M tolerance)	A115	TS○○	Clamp screw	M007
TNMG○○○○○○○-GK	Insert (Class M tolerance)	A115	TS○○○	Clamp screw	M007
TNMG○○○○○○○-GM	Insert (Class M tolerance)	A112	TS○○○○	Clamp screw	M007
TNMG○○○○○○○-LK	Insert (Class M tolerance)	A111	TSMPR○○○S○○	TSMP type end mill	K107
TNMG○○○○○○○-LM	Insert (Class M tolerance)	A111	TSR○○○○○S	Clamp screw	M007
TNMG○○○○○○○-LP	Insert (Class M tolerance)	A110	TSS○○○○○	Radial screw	M008
TNMG○○○○○○○-LS	Insert (Class M tolerance)	A111	TTAHR/L○○○○	Small tools holder (External threading)	D024
TNMG○○○○○○○-MA	Insert (Class M tolerance)	A113	TTAT○○○○○○○○○-B	Insert for external threading	D024
TNMG○○○○○○○-MH	Insert (Class M tolerance)	A113	U		
TNMG○○○○○○○-MJ	Insert (Class M tolerance)	A112	UCR	Clamp bridge	M015
TNMG○○○○○○○-MK	Insert (Class M tolerance)	A112	UGHN○○○	UG holder	F126
TNMG○○○○○○○-MM	Insert (Class M tolerance)	A112	UGHR/L○○○○○○○	UG holder	F127
TNMG○○○○○○○-MP	Insert (Class M tolerance)	A112	UGS○	Wrench (For UG holder)	F126,F127
TNMG○○○○○○○-MS	Insert (Class M tolerance)	A112	V		
TNMG○○○○○○○R/L-1G	Insert (Class M tolerance)	A111	VA2MS	VIOLET end mill	I307
TNMG○○○○○○○R/L-2G	Insert (Class M tolerance)	A114	VA2SS	VIOLET end mill	I306
TNMG○○○○○○○R/L-ES	Insert (Class M tolerance)	A113	VA4MC	VIOLET end mill	I309
TNMG○○○○○○○-RK	Insert (Class M tolerance)	A115	VAJR	VIOLET end mill	I317
TNMG○○○○○○○-RM	Insert (Class M tolerance)	A114	VALR	VIOLET end mill	I319
TNMG○○○○○○○-RP	Insert (Class M tolerance)	A114	VAMFPR	VIOLET end mill	I313
TNMG○○○○○○○-RS	Insert (Class M tolerance)	A115	VAMH	VIOLET end mill	I321
TNMG○○○○○○○-SA	Insert (Class M tolerance)	A111	VAMR	VIOLET end mill	I315
TNMG○○○○○○○-SH	Insert (Class M tolerance)	A111	VAPDM	VIOLET drill	L163—L165
TNMG○○○○○○○-SY	Insert (Class M tolerance)	A111	VAPDMSUS	VIOLET drill	L173—L178
TNMM○○○○○○○-HZ	Insert (Class M tolerance)	A115	VAPDS	VIOLET drill	L158—L161
TNMN○○○○○○○	Insert (Class M tolerance)	A126	VAPDSCB	VIOLET drill	L182,L183
TNMX○○○○○○○-MW	Insert (Class M tolerance)	A113	VAPDSSUS	VIOLET drill	L167—L172
TNMX○○○○○○○-SW	Insert (Class M tolerance)	A111	VASFPR	VIOLET end mill	I311
TPEN○○○○○P○○	Insert (For corner angle 0° type cutter)	J036	VBET○○○○○○○R/L-SN	Insert (Class E tolerance)	A151
TPEW1303ZP○R2	Insert (For PMF type end mill)	J036,J042,K112	VBET○○○○○○○R/L-SR	Insert (Class E tolerance)	A151
TPGH○○○○○○○R/L-FS	Insert (Class G tolerance)	A147	VBET○○○○○○○R/LW-SN	Insert (Class E tolerance)	A152
TPGN○○○○○○○	Insert (Class G tolerance)	A164,B044,B058	VBGT○○○○○○○R/L-F	Insert (Class G tolerance)	A150
TPGR○○○○○○○R/L	Insert (Class G tolerance)	A163	VBMT○○○○○○○	Insert (Class M tolerance)	A151
TPGX○○○○○○○	Insert (Class G tolerance)	A149,B054	VBMT○○○○○○○-FM	Insert (Class M tolerance)	A150
TPGX○○○○○○○R/L	Insert (Class G tolerance)	A147,A148	VBMT○○○○○○○-FP	Insert (Class M tolerance)	A150
TPMH○○○○○○○-FV	Insert (Class M tolerance)	A147	VBMT○○○○○○○-FV	Insert (Class M tolerance)	A150
TPMH○○○○○○○-MV	Insert (Class M tolerance)	A148	VBMT○○○○○○○-LM	Insert (Class M tolerance)	A150
TPMH○○○○○○○-SV	Insert (Class M tolerance)	A148	VBMT○○○○○○○-LP	Insert (Class M tolerance)	A150
TPMN○○○○○○○	Insert (Class M tolerance)	A163,J036	VBMT○○○○○○○-MM	Insert (Class M tolerance)	A151
TPMN○○○○○○○T	Insert (Class M tolerance)	A163,J036	VBMT○○○○○○○-MP	Insert (Class M tolerance)	A151
TPMR○○○○○○○	Insert (Class M tolerance)	A163	VBMT○○○○○○○-MV	Insert (Class M tolerance)	A151
TPMR○○○○○○○-80	Insert (Class M tolerance)	A163	VBMT○○○○○○○-SV	Insert (Class M tolerance)	A151
TPMX○○○○○○○	Insert (Class M tolerance)	A148	VC2PSB	MIRACLE end mill	I241
TPMX○○○○○○○L	Insert (Class M tolerance)	A148			
TPNN2204PDR	Insert (For corner angle 0° type cutter)	J036			

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
VC2PSBP	MIRACLE end mill	I242	VFSDRB	IMPACT MIRACLE end mill	I208
VC4SRB	MIRACLE end mill	I250	VFSFPR	IMPACT MIRACLE end mill	I163
VCGT	Insert (Class G tolerance)	A153	VFSFPRCH	IMPACT MIRACLE end mill	I165
VCGT	Insert (Class G tolerance)	A153	VFX5	VFX5 type end mill	K082
VCHSM	VCHSM type drill	L113	VFX6	VFX6 type end mill	K085
VCMT	Insert (Class M tolerance)	A154	VNGA	Insert (Class G tolerance)	A118,B050
VCMT	Insert (Class M tolerance)	A153	VNGG	Insert (Class G tolerance)	A116
VCMT	Insert (Class M tolerance)	A153	VNGG	Insert (Class G tolerance)	A118
VCMT	Insert (Class M tolerance)	A153	VNGG	Insert (Class G tolerance)	A116
VCMT	Insert (Class M tolerance)	A153	VNGM	Insert (Class G tolerance)	A117
VCMT	Insert (Class M tolerance)	A153	VNMG	Insert (Class M tolerance)	A118
VCMT	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A116
VCMT	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A116
VCMT	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A118
VCMT	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A117
VCMT	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A116
VCMT	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A116
VCMW	Insert (Class M tolerance)	A154	VNMG	Insert (Class M tolerance)	A116
VCPSRB	MIRACLE end mill	I244—I246,I248	VNMG	Insert (Class M tolerance)	A117
VDGX	Insert (Class G tolerance)	A155	VNMG	Insert (Class M tolerance)	A118
VDGX	Insert (Class G tolerance)	B055	VNMG	Insert (Class M tolerance)	A118
VF2MV	IMPACT MIRACLE end mill	I149	VNMG	Insert (Class M tolerance)	A117
VF2SB	IMPACT MIRACLE end mill	I170,I171	VNMG	Insert (Class M tolerance)	A117
VF2SDB	IMPACT MIRACLE end mill	I172	VNMG	Insert (Class M tolerance)	A117
VF2SDBL	IMPACT MIRACLE end mill	I173	VNMG	Insert (Class M tolerance)	A117
VF2SSB	IMPACT MIRACLE end mill	I169	VNMG	Insert (Class M tolerance)	A117
VF2WB	IMPACT MIRACLE end mill	I168	VNMG	Insert (Class M tolerance)	A117
VF2XL	IMPACT MIRACLE end mill	I146,I147	VNMG	Insert (Class M tolerance)	A117
VF2XLB	IMPACT MIRACLE end mill	I176—I180	VOX400	VOX400 type face mill	K022
VF2XLBS	IMPACT MIRACLE end mill	I175	VPET	Insert (Class E tolerance)	A156
VF3XB	IMPACT MIRACLE end mill	I182—I184	VPGT	Insert (Class G tolerance)	A156
VF4MB	IMPACT MIRACLE end mill	I187	VQ4SVB	VQ end mill	I232
VF4MV	IMPACT MIRACLE end mill	I151	VQJHV	VQ end mill	I224
VF4SVB	IMPACT MIRACLE end mill	I189	VQMHV	VQ end mill	I220
VF6MHV	IMPACT MIRACLE end mill	I157	VQMHVRB	VQ end mill	I234,I235
VF6MHVCH	IMPACT MIRACLE end mill	I158	VQMHVRBF	VQ end mill	I239
VF6MHVRB	IMPACT MIRACLE end mill	I204	VQMHZV	VQ end mill	I211,I212
VF6MHVRBCH	IMPACT MIRACLE end mill	I206	VQMHZVOH	VQ end mill	I217
VF6SVRCH	IMPACT MIRACLE end mill	I166	VQSVR	VQ end mill	I229
VF8MHVCH	IMPACT MIRACLE end mill	I159	VQXL	VQ end mill	I226
VF8MHVRBCH	IMPACT MIRACLE end mill	I207	VSD	VIOLET drill, Straight shank	L180,L181
VFHVRB	IMPACT MIRACLE end mill	I191,I192,I197,I198	W		
VFJHV	IMPACT MIRACLE end mill	I155	WBG	Insert (Class G tolerance)	A157
VFMD	IMPACT MIRACLE end mill	I161	WBMT	Insert (Class M tolerance)	A157
VFMDB	IMPACT MIRACLE end mill	I209	WCGT	Insert (Class G tolerance)	A158
VFMFPR	IMPACT MIRACLE end mill	I167	WCMT	Insert (Class M tolerance)	A158
VFMHV	IMPACT MIRACLE end mill	I152	WCMW	Insert (Class M tolerance)	B056
VFMHVCH	IMPACT MIRACLE end mill	I154	WCS	Shim screw	M008
VFMHVRB	IMPACT MIRACLE end mill	I201	WEC	Wiper insert	
VFMHVRBCH	IMPACT MIRACLE end mill	I203		(For SE445•545/LSE445 type cutter)	J040
VFSD	IMPACT MIRACLE end mill	I160			

INDEX FOR TOOL NUMBER

Order Number	PRODUCT NAME	Page	Order Number	PRODUCT NAME	Page
WEC00EF0R/L5C	Wiper insert (For SE415•515 type cutter)...	J040	XDGT1550PDER-G00	Insert (For BXD4000 type cutter).....	J037
WEEW13T3AG0R3C	Wiper insert (For ASX445 type cutter) ...	J043,K012	XDGT1550PDFR-G00	Insert (For BXD4000•7000 type cutter)	J037
WEEW13T3AG0R8C	Wiper insert (For ASX445 type cutter) ...	J040,K012	XDGT1550PDFR-GL00	Insert (For BXD4000•7000 type cutter)	J037
WFC42ZFER/L2	Wiper insert (For BF407/QBF407 type cutter) ...	J043	XDGX0000000PDER-GM	Insert (For AXD4000 type cutter).....	J037,K046
WNEU2000ZEN7C00	Wiper insert (For AHX type cutter)	J040	XDGX0000000PDFR-GL	Insert (For AXD4000•7000 type cutter)	J037
		K017,K019			J038,K046,K051
WNMA0000000	Insert (Class M tolerance)	A123	XDGX0000000PDFR-GM	Insert (For AXD4000 type cutter).....	J038,K046
WNMG0000000	Insert (Class M tolerance)	A122	XNMU0000000R0S	Insert (For VFX5•VFX6 type cutter)....	J038,K083
WNMG0000000-FH	Insert (Class M tolerance)	A119			K086
WNMG0000000-FS	Insert (Class M tolerance)	A119	Z		
WNMG0000000-FY	Insert (Class M tolerance)	A119	ZCMX0000000ER0	Insert (For DCCC type end mill).....	J039
WNMG0000000-GH	Insert (Class M tolerance)	A123			
WNMG0000000-GJ	Insert (Class M tolerance)	A123			
WNMG0000000-GK	Insert (Class M tolerance)	A123			
WNMG0000000-GM	Insert (Class M tolerance)	A121			
WNMG0000000-LK	Insert (Class M tolerance)	A119			
WNMG0000000-LM	Insert (Class M tolerance)	A119			
WNMG0000000-LP	Insert (Class M tolerance)	A119			
WNMG0000000-LS	Insert (Class M tolerance)	A120			
WNMG0000000-MA	Insert (Class M tolerance)	A121			
WNMG0000000-MH	Insert (Class M tolerance)	A122			
WNMG0000000-MJ	Insert (Class M tolerance)	A120			
WNMG0000000-MK	Insert (Class M tolerance)	A121			
WNMG0000000-MM	Insert (Class M tolerance)	A121			
WNMG0000000-MP	Insert (Class M tolerance)	A121			
WNMG0000000-MS	Insert (Class M tolerance)	A121			
WNMG0000000-MW	Insert (Class M tolerance)	A122			
WNMG0000000-RK	Insert (Class M tolerance)	A122			
WNMG0000000-RM	Insert (Class M tolerance)	A122			
WNMG0000000-RP	Insert (Class M tolerance)	A122			
WNMG0000000-RS	Insert (Class M tolerance)	A122			
WNMG0000000-SA	Insert (Class M tolerance)	A120			
WNMG0000000-SH	Insert (Class M tolerance)	A120			
WNMG0000000-SW	Insert (Class M tolerance)	A120			
WNMG0000000-SY	Insert (Class M tolerance)	A120			
WOEW12T308PE0R8C	Wiper insert (For ASX400 type cutter) ...	J041,K028			
WOEX1206PER5C	Insert (For VOX400 type cutter)	J041,K023			
WPC42EE0R/L10C	Wiper insert (For FBP415/QBP415 type cutter) ...	J041			
WPGT0000000	Insert (Class G tolerance).....	B056			
WPGT0000000R/L-FS	Insert (Class G tolerance).....	A159			
WPMT0000000-MV	Insert (Class M tolerance)	A159			
WPSTN00	Shim	M012			
WPSWC43	Shim	M012			
WPSWN43	Shim	M012			
WPT4405	Plate (For TAW drill).....	L124—L128			
WS0000000T	Clamp screw	M008			
WS1	Wedge screw	M008			
X					
XCMT0000000-SVX	Insert (Class M tolerance)	A160			