

INDEX

INDEX FOR TOOL NUMBER

A II
B II
C III
D IV
E V
F V
G V
H V
I VI
J VI
K VI
L VI
M VII
N VIII
O VIII
P VIII
Q VIII
R VIII
S IX
T XI
V XII
W XIII
X XIII
Z XIII

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
A					
AEMW00000000R	Insert (For BAE type end mill)	J020	ARPOPR0000AM0000	ARP type screw-in end mill (Metric type)	K180
AEMW00000000R	Insert (For BAE type end mill)	J020	ARX00R0000M00A00	ARX type screw-in end mill (Metric type)	K187
AHX0000S000000R	AHX640S type face mill	K030,K037,K043	ARX00R0000SA00LW	ARX type end mill (Metric type)	K187,K188
AHX0000SR000000	AHX640S type face mill	K029,K037,K042	ARX00R0000SA00S	ARX type end mill (Metric type)	K186,K188
AHX0000SUR000000	AHX640S type face mill (Metric type)	K028,K036,K040,K041	ASX400000000R	ASX400 type face mill (Metric type)	K073
AHX640W0000000R/L	AHX640W type face mill	K051	ASX400R000000	ASX400 type face mill (Metric type)	K070
AHX640WR/L000000	AHX640W type face mill	K048,K049	ASX400R0000C/D/E/F/K	ASX400 type face mill	K072
AHX640WR/L000000	AHX640W type face mill (Metric type)	K050	ASX400R0000C/E/M	ASX400 type face mill	K072
AJS0000T000000	Clamp screw (For AJX type cutter)	M003	ASX400R0000AM1600	ASX400 type screw-in end mill (Metric type)	K072
AJX000000A/B00R	AJX type face mill (Metric type)	K163	ASX400R0000S32	ASX400 type end mill (Metric type)	K073
AJX00R00000000	AJX type face mill (Metric type)	K162,K173	ASX400R0000W20	ASX400 type end mill	K071
AJX00R0000AM0000	AJX type screw-in end mill (Metric type)	K165	ASX445000000R	ASX445 type face mill (Metric type)	K024
AJX00R0000SA00S/SS/L/EL	AJX type end mill (Metric type)	K160,K161	ASX445R00000000	ASX445 type face mill	K022,K023
AJX14RA000000E/F	AJX type cutter	K159	ASX445R0000C/E/M	ASX445 type face mill	K022
AJXU00R00000000	AJX type cutter	K159,K173	ASX445R0000S32	ASX445 type end mill	K023
AJXU00R0000AM0000	AJX type cutter	K164	AXD400000000A00R0	AXD4000 type face mill (Metric type)	K112
AJXU00R0000C/E	AJX type cutter	K159	AXD4000R000000A/B	AXD4000 type face mill (Metric type)	K111
AJXU00R0000FA/SA/WA00S/ML	AJX type end mill	K158	AXD4000R0000SA0000	AXD4000 type end mill (Metric type)	K110
AMS00000000000	Clamp bridge (For AJX/BRE type cutter)	M015	AXD4000UR000000A/B	AXD4000 type face mill	K109
AOGT123600PEFR-GM	Insert (For APX3000 type cutter)	J015,K091	AXD4000UR0000SA0000A/B	AXD4000 type end mill	K108
AOMT123600PEER-H/M	Insert (For APX3000 type cutter)	J015,J016,K091	AXD700000000A/B00R0	AXD7000 type face mill (Metric type)	K120
AOMT184800PEER-H/M	Insert (For APX4000 type cutter)	J016,K100	AXD7000R00000000	AXD7000 type face mill (Metric type)	K119
AOX445-063A04R	AOX445 type face mill (Metric type)	K061	AXD7000R000000A-H63A	AXD7000 type HSK shank end mill (Metric type)	K120
AOX445R00000000	AOX445 type face mill (Metric type)	K061	AXD7000R0000SA00S0	AXD7000 type end mill (Metric type)	K119
AOX445R0000S32	AOX445 type end mill (Metric type)	K061	AXD7000UR00000000	AXD7000 type face mill	K118
APGT0000PDFR-G0	Insert (For BAP300/400 type cutter)	J020,J021	AXD7000UR0000SA00S0	AXD7000 type end mill	K118
APMT0000PDER-H0	Insert (For BAP300/400/SRM2 type cutter)	J020,J021,K222,K223,K228	B		
APMT0000PDER-M0	Insert (For BAP300/400/SRM2 type cutter)	J021,K222,K223,K228	BC500000000000	Clamp set (For F type boring bar)	M003
APX30000000A00RA	APX3000 type face mill (Metric type)	K088	BGP1410000000000	Shim pin	M014
APX3000R000000CA/DA	APX3000 type face mill (Metric type)	K089	BF-CCGT00000002	Insert (Class G tolerance)	B043
APX3000R000000A/B	APX3000 type face mill	K086	BF-CCGW000000TS2	Insert (Class G tolerance)	B043
APX3000R0000M00A00	APX3000 type screw-in end mill (Metric type)	K090	BF-CNGG000000TA4	Insert (Class G tolerance)	B026
APX3000UR0000AM00A00	APX3000 type screw-in end mill (Inch type)	K090	BF-CNGM00000002	Insert (Class G tolerance)	B028
APX3000R0000SA000A	APX3000 type end mill (Metric type)	K087	BF-DCGT00000002	Insert (Class G tolerance)	B047
APX3000UR0000SA/FA0000	APX3000 type end mill	K084,K085	BF-DCGW000000TS2	Insert (Class G tolerance)	B047
APX40000000A00RA	APX4000 type face mill (Metric type)	K098	BF-DNGG000000TA4	Insert (Class G tolerance)	B030
APX4000R00000000A	APX4000 type face mill (Metric type)	K097	BF-DNGM00000002	Insert (Class G tolerance)	B032
APX4000R0000M00A00	APX4000 type screw-in end mill (Metric type)	K099	BLS000000000000	Clamp screw	M003
APX4000R0000SA000A	APX4000 type end mill (Metric type)	K096	BM-CCGT000000TA2	Insert (Class G tolerance)	B044
APX4000UR00000000	APX4000 type face mill	K095	BM-CNGM000000TA2	Insert (Class G tolerance)	B028
APX4000UR0000AM00A00	APX4000 type screw-in end mill (Inch type)	K099	BM-DCGT000000TA2	Insert (Class G tolerance)	B047
APX4000UR0000SA/FA0000	APX4000 type end mill	K094	BM-DNGM000000TA2	Insert (Class G tolerance)	B032
APX4K000000A00000RA	APX4000 type end mill (Metric type)	K105	BM-TNGM000000TA3	Insert (Class G tolerance)	B035
APX4KR000000A00000A	APX4000 type end mill (Metric type)	K105	BOE4R0000000000	BOE type face mill	K195
APX4KR06316CA056A	APX4000 type end mill (Metric type)	K105	BOE4R000000C/X	BOE type face mill	K195
APX4KUR000000WA00000A	APX4000 type end mill	K104	BOE4R000000W20	BOE type end mill	K194
APX4KUR0209A16A	APX4000 type end mill	K104	BOE4S06U00000000	Clamp screw	M008
APX4KUR2516CA22A	APX4000 type end mill	K104	BOER000000A/C/E/F	BOE type face mill	K195
AQXR0000M00A00	AQX type screw-in end mill (Metric type)	K151	BOER000000W20	BOE type end mill	K194
AQXR0000SA/SN00S/L	AQX type end mill (Metric type)	K149,K150	BRP0000R000000ELS00	BRP type end mill	K190
AQXUR0000SA/WA00S/L	AQX type end mill	K148	BRP0000R000000ELW00	BRP type end mill	K190
ARPO0PR0000000A	ARP type face mill	K174,K176	BRP0000R000000LW00	BRP type end mill	K190
ARPO0PR000000FA00M	ARP type end mill (Inch type)	K175	BRP0000R000000W00	BRP type end mill	K190
ARPO0PR000000SA00M/L	ARP type end mill	K175,K178	BRPOUPR0000000000	BRP type face mill	K191
ARPO0P000000A000AR	ARP type face mill (Metric type)	K177	BRPOUPR000000C/E/X	BRP type face mill	K191
ARPO0UPR000000AM0000	ARP type screw-in end mill (Inch type)	K179	BRS10500000000000	Clamp screw (For BRE type end mill)	M003
			BTAHR/L0000000000	External back turning holder	D016
			BTAHR/L00000000-50	External back turning holder	D019
			BTAT0000000000R/L-B	External back turning insert	D016,D019
			BTAT6050000RX	External back turning insert	D016,D019

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
BTBT000000R/L-B	External back turning insert.....	D017,D020	CCMT0000LM	Insert (Class M tolerance).....	A147
BTBT606000R/L	External back turning insert.....	D017,D020	CCMT0000LP	Insert (Class M tolerance).....	A147
BTVHR0000	External back turning holder.....	D018	CCMT0000LS	Insert (Class M tolerance).....	A147
BTVHR0000-75	External back turning holder.....	D021	CCMT0000MK	Insert (Class M tolerance).....	A149
BTVHR0000-75F	External back turning holder.....	D021	CCMT0000MM	Insert (Class M tolerance).....	A149
BTVT000000R-B	External back turning insert.....	D018,D021	CCMT0000MP	Insert (Class M tolerance).....	A149
BXD4000-000A/B000RA/RB	BXD4000 type face mill (Metric type).....	K130	CCMT0000MS	Insert (Class M tolerance).....	A149
BXD4000R00000	BXD4000 type face mill.....	K129	CCMT0000MW	Insert (Class M tolerance).....	A150
BXD4000R00000000	BXD4000 type face mill (Metric type).....	K130	CCMT0000SW	Insert (Class M tolerance).....	A147
BXD4000R00000B	BXD4000 type face mill.....	K129	CCMW0000	Insert (Class M tolerance).....	A152,B063
BXD4000R0000SA00000	BXD4000 type end mill (Metric type).....	K131	CCMX000000ENA/B	Insert (For LER type end mill).....	J024,K146
BXD4000R0000SA00S/SB	BXD4000 type end mill.....	K128	CE4SRB	Ceramic end mill (Metric type).....	I295
C			CE6SRB	Ceramic end mill (Metric type).....	I296
C000CR-BLS	MICRO-MINI boring bar.....	E031	CFC/FM000000	Clamp screw.....	M002
C0000SCLCR00	MICRO-DEX holder (Carbide shank).....	E029	CFSPR0000W00	CFSP type end mill.....	K199
C0000SWUBR00	MICRO-DEX holder (Carbide shank).....	E029	CG00RS-00	MICRO-MINI TWIN boring bar.....	F215
C0-GYHR/L090-M25R/L	GY type holder (External 90° type)....	F176-F185	CG0000RS-00	MICRO-MINI TWIN boring bar.....	F215
C0-GYHR/L0X00-M00R/L	GY type holder (External 00° type)....	F166-F175	CG00RS-00B	MICRO-MINI TWIN boring bar.....	F215
C07KSTUCR06	MICRO-DEX holder (Carbide shank).....	E030	CG0000RS-00B	MICRO-MINI TWIN boring bar.....	F215
C2MHA	Carbide end mill (Metric type).....	I297	CL0	Clamp bridge.....	M015
C3-GYHR/LCX90-M20R/L	GY type holder (External 90° type)....	F176-F185	CL00	Clamp bridge.....	M015
C4LATB	Carbide end mill (Metric type).....	I299	CNG000	Insert (Class G tolerance).....	B039
C6-GYHR/LF00-M25R/L	GY type holder (External 00° type)....	F166-F175	CNGA000	CBN insert (Class G tolerance).....	B028
CAS51T	Clamp screw (For BF407 type face mill) ..	M003	CNGG0000FJ	Insert (Class G tolerance).....	A102
CB00RS	MICRO-MINI TWIN boring bar.....	E032	CNGG0000FJ-P	Insert (Class G tolerance).....	A102
CB00RS-B	MICRO-MINI TWIN boring bar.....	E032	CNGG0000MJ	Insert (Class G tolerance).....	A104
CBC4	Chipbreaker.....	M016	CNGG0000PK	Insert (Class G tolerance).....	A103
CBH000000	Clamp screw.....	M002	CNMA0000	Insert (Class M tolerance).....	A109,B028,B059
CBN2XLB	CBN end mill (Metric type).....	I291	CNMG0000	Insert (Class M tolerance).....	A106
CBN2XLRB	CBN end mill (Metric type).....	I293	CNMG0000C	Insert (Class M tolerance).....	A104
CBR4	Chipbreaker.....	M016	CNMG0000FP	Insert (Class M tolerance).....	A102
CBS0	Chipbreaker.....	M016	CNMG0000FH	Insert (Class M tolerance).....	A102
CBS0D	Chipbreaker.....	M016	CNMG0000FS	Insert (Class M tolerance).....	A102
CBT3	Chipbreaker.....	M016	CNMG0000FY	Insert (Class M tolerance).....	A102
CCET0000R/LSN	Insert (Class E tolerance).....	A150,A151	CNMG0000GH	Insert (Class M tolerance).....	A108
CCET0000R/LSR	Insert (Class E tolerance).....	A150	CNMG0000GJ	Insert (Class M tolerance).....	A108
CCET0000R/LWSN	Insert (Class E tolerance).....	A151	CNMG0000GK	Insert (Class M tolerance).....	A105
CCGH0000R/LF	Insert (Class G tolerance).....	A147	CNMG0000GM	Insert (Class M tolerance).....	A105
CCGT000000L-F	Insert (Class G tolerance).....	A146	CNMG0000LK	Insert (Class M tolerance).....	A103
CCGT0000AZ	Insert (Class G tolerance).....	A146	CNMG0000LM	Insert (Class M tolerance).....	A103
CCGT0000FJ	Insert (Class G tolerance).....	A145	CNMG0000LP	Insert (Class M tolerance).....	A103
CCGT0000FJ-P	Insert (Class G tolerance).....	A146	CNMG0000LS	Insert (Class M tolerance).....	A103
CCGT0000MJ	Insert (Class G tolerance).....	A148	CNMG0000MA	Insert (Class M tolerance).....	A105
CCGT0000MJ-P	Insert (Class G tolerance).....	A148	CNMG0000MH	Insert (Class M tolerance).....	A106
CCGT0000MFS	Insert (Class G tolerance).....	A145	CNMG0000MJ	Insert (Class M tolerance).....	A104
CCGT0000MFS-P	Insert (Class G tolerance).....	A145	CNMG0000MK	Insert (Class M tolerance).....	A105
CCGT0000MLS	Insert (Class G tolerance).....	A148	CNMG0000MM	Insert (Class M tolerance).....	A105
CCGT0000MRS0	Insert (Class G tolerance).....	A147,A151	CNMG0000MP	Insert (Class M tolerance).....	A104
CCGT0000MSMG	Insert (Class G tolerance).....	A151	CNMG0000MS	Insert (Class M tolerance).....	A106,A107
CCGT0000R/LSN	Insert (Class G tolerance).....	A151	CNMG0000MW	Insert (Class M tolerance).....	A106
CCGT0000R/LSS	Insert (Class G tolerance).....	A147,A148	CNMG0000RK	Insert (Class M tolerance).....	A107
CCGW0000	Insert (Class G tolerance).....	B044	CNMG0000RM	Insert (Class M tolerance).....	A107
CCGW0000V0	Insert (Class G tolerance).....	A152	CNMG0000RP	Insert (Class M tolerance).....	A107
CCGW0000FS	Insert (Class G tolerance).....	B044	CNMG0000RS	Insert (Class M tolerance).....	A107
CCMH0000MV	Insert (Class M tolerance).....	A149	CNMG0000SA	Insert (Class M tolerance).....	A103
CCMH0000SV	Insert (Class M tolerance).....	A147	CNMG0000SH	Insert (Class M tolerance).....	A103
CCMT0000	Insert (Class M tolerance).....	A149	CNMG0000SW	Insert (Class M tolerance).....	A103
CCMT0000FM	Insert (Class M tolerance).....	A145	CNMG0000SY	Insert (Class M tolerance).....	A104
CCMT0000FP	Insert (Class M tolerance).....	A145	CNMM0000HL	Insert (Class M tolerance).....	A109
CCMT0000FV	Insert (Class M tolerance).....	A145	CNMM0000HM	Insert (Class M tolerance).....	A109
			CNMM0000HR	Insert (Class M tolerance).....	A109
			CNMM0000HV	Insert (Class M tolerance).....	A109

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
CNMM000HX	Insert (Class M tolerance)	A108	CTET00000000-B	External cutting off insert	D034
CNMM000HZ	Insert (Class M tolerance)	A108	CTI00T000	Shim	G013,M013
CNMN000	Insert (Class M tolerance)	A142	D		
CNMP000	Insert (Class M tolerance)	A107	DC2SB	Diamond coated end mill (Metric type)	I287
CPGT000	Insert (Class G tolerance)	A153,B061	DC2XLB	Diamond coated end mill (Metric type)	I289
CPGT000R/LF	Insert (Class G tolerance)	A153	DC0000T	Clamp screw	M003
CPM00000	Clamp screw	M002	DCET000R/LSN	Insert (Class E tolerance)	A159,A160
CPMH000FV	Insert (Class M tolerance)	A153	DCET000R/LSR	Insert (Class E tolerance)	A159
CPMH000MV	Insert (Class M tolerance)	A154	DCET000R/LWSN	Insert (Class E tolerance)	A161
CPMH000R/LF	Insert (Class M tolerance)	A153	DCGT000AZ	Insert (Class G tolerance)	A156
CPMH000SV	Insert (Class M tolerance)	A153	DCGT000FJ	Insert (Class G tolerance)	A155
CPMT000MQ	Insert (Class M tolerance)	A154	DCGT000FJ-P	Insert (Class G tolerance)	A155
CPMT000SQ	Insert (Class M tolerance)	A153	DCGT000MFS	Insert (Class G tolerance)	A156
CPMT1205ZPEN-M	Insert (For PMR type end mill)	J026,K232	DCGT000MJ	Insert (Class G tolerance)	A158
CPMX000	Insert (Class M tolerance)	A154	DCGT000MJ-P	Insert (Class G tolerance)	A158
CR0	Stop ring (For SRE type end mill)	M014	DCGT000MLS	Insert (Class G tolerance)	A157
CR00RS-00	MICRO-MINI TWIN boring bar	E033	DCGT000MRS0	Insert (Class G tolerance)	A157,A160
CR00RS-00B	MICRO-MINI TWIN boring bar	E033	DCGT000MSMG	Insert (Class G tolerance)	A161
CS000000T	Clamp screw	M003	DCGT000R/LF	Insert (Class G tolerance)	A156
CS000000TS	Clamp screw	M003	DCGT000R/LSN	Insert (Class G tolerance)	A160
CSC/SD/SP/SR/SS000000	Clamp screw	M002	DCGT000R/LSS	Insert (Class G tolerance)	A157
C-SCLCR/L-000	Screw clamp type boring bar (Carbide shank)	E013	DCGW000	Insert (Class G tolerance)	A161,B047
C-SDQCR/L-000	Screw clamp type boring bar (Carbide shank)	E014	DCGW000FS	Insert (Class G tolerance)	B047
C-STUCR/L-000	Screw clamp type boring bar (Carbide shank)	E016	DCK0000	Clamp bridge	M015
CSVHR/L-000	External turning holder	D041	DCLNR/L-000	Double clamp type holder	C006
CSVHR/L0000	External turning holder	D044	DCMT000	Insert (Class M tolerance)	A159
CSVTB000R/L	External back turning insert	D042,D045	DCMT000FM	Insert (Class M tolerance)	A155
CSVTB000R-B	External back turning insert	D042,D045	DCMT000FP	Insert (Class M tolerance)	A155
CSVTBXL	External back turning copying insert	D042,D045	DCMT000FV	Insert (Class M tolerance)	A155
CSVTC0000R/L	External cutting off insert	D042,D045	DCMT000LM	Insert (Class M tolerance)	A157
CSVTC0000R-B	External cutting off insert	D042,D045	DCMT000LP	Insert (Class M tolerance)	A156
CSVTF000R/L	External front turning insert	D041,D044	DCMT000LS	Insert (Class M tolerance)	A157
CSVTF000R/L-B	External front turning insert	D041,D044	DCMT000MS	Insert (Class M tolerance)	A158
CSVTFXL	External front turning copying insert	D041,D044	DCMT000MK	Insert (Class M tolerance)	A159
CSVTG000000R/L	External grooving insert	D043,D046	DCMT000MM	Insert (Class M tolerance)	A158
CSVTT60050RR/L	External threading insert	D043,D046	DCMT000MP	Insert (Class M tolerance)	A158
C-SWLOR/L-000	Screw clamp type boring bar (Carbide shank)	E019	DCMT000MV	Insert (Class M tolerance)	A159
C-SWL0502R/LS	Screw clamp type boring bar (Carbide shank)	E017	DCMT000SV	Insert (Class M tolerance)	A157
C-SWL0504R/L	Screw clamp type boring bar (Carbide shank)	E017	DCMW000	Insert (Class M tolerance)	A161,B064
C-SWL05S3R/LM	Screw clamp type boring bar (Carbide shank)	E017	DCRNR/L-000	Double clamp type holder	C008
CT00RS-M0	MICRO-MINI TWIN boring bar	G039	DCS0	Spring	C006-C027,M014
CT00RS-M00	MICRO-MINI TWIN boring bar	G039	DCSVN32	Shim	M010
CT00RS-M00B	MICRO-MINI TWIN boring bar	G039	DDJNR/L-000	Double clamp type holder	C010
CT00RS-M0B	MICRO-MINI TWIN boring bar	G039	DDPNN-164	Double clamp type holder	C011
CTAHR/L-000	External cutting off holder	D026	DDQNR/L-164	Double clamp type holder	C012
CTAHR/L0000-120	External cutting off holder	D028	DEGX000R/L	Insert (Class G tolerance)	A162
CTAHR1010-120S	External cutting off holder	D028	DEGX000R/LF	Insert (Class G tolerance)	A162,B070
CTAHR-000S	External cutting off holder	D026	DF2MB	Diamond coated end mill (Metric type)	I276
CTAT0000000R/L0	External cutting off insert	D027,D029	DF2XLB	Diamond coated end mill (Metric type)	I278
CTAT0000000R/L0-B	External cutting off insert	D027,D029	DF3XB	Diamond coated end mill (Metric type)	I282
CTAT0000000R0-BX	External cutting off insert	D027,D029	DF4JC	Diamond coated end mill (Metric type)	I272
CTBHR/L-000	External back turning, cutting off holder	D017,D030	DF4XL	Diamond coated end mill (Metric type)	I273
CTBHR/L0000-160	External back turning, cutting off holder	D020,D031	DFC4JC	DFC end mill (Metric type)	I270
CTBT0000000R/L0-B	External cutting off insert	D030,D031	DFCJRT	DFC end mill (Metric type)	I271
CTCHR/L0000-200	External cutting off holder	D032	DFPSRB	Diamond coated end mill (Metric type)	I284
CTCT00000000-B	External cutting off insert	D032	DNG000	Insert (Class G tolerance)	B039
CTDHR/L0000-000	External cutting off holder	D033	DNGA000	Insert (Class G tolerance)	A116,B059
CTDT00000000-B	External cutting off insert	D033	DNGG000FJ	Insert (Class G tolerance)	A110
CTDT00000000-BS	External cutting off insert	D033	DNGG000PK	Insert (Class G tolerance)	A110
CTE00T000	Shim	G012,M013	DNGG000R/L	Insert (Class G tolerance)	A115
CTEHR/L0000-000	External cutting off holder	D034			
CTET00000000-B	External cutting off insert	D034			

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
DNMG000MJInsert (Class G tolerance).....	A112	FSWL100RScrew clamp boring bar.....	E018
DNMA000Insert (Class M tolerance).....	A116	FSWL200RScrew clamp boring bar.....	E018
DNMG000Insert (Class M tolerance).....	A114	G		
DNMG000CInsert (Class M tolerance).....	A112	GOER0000PXFR2Insert (For FMAX type cutter).....	K064
DNMG000FPInsert (Class M tolerance).....	A110	GTBHR/L000External grooving holder.....	D022
DNMG000FHInsert (Class M tolerance).....	A110	GT0HR/L000000External grooving holder.....	D024
DNMG000FSInsert (Class M tolerance).....	A110	GT0HR/L000000SExternal grooving holder.....	D024
DNMG000FYInsert (Class M tolerance).....	A110	GT0T0000000R-VTExternal grooving insert.....	D023,D025
DNMG000GHInsert (Class M tolerance).....	A115	GT0T0000000R/L-EExternal grooving insert.....	D023,D025
DNMG000GJInsert (Class M tolerance).....	A115	GT0T0000000R/L-UExternal grooving insert.....	D022,D024
DNMG000GKInsert (Class M tolerance).....	A113	GTS0Clamp screw.....	M004
DNMG000GMInsert (Class M tolerance).....	A113	GY00000S/MClamp screw.....	M004
DNMG000LKInsert (Class M tolerance).....	A111	GY0B0000000NInsert (For GY holder).....	F016
DNMG000LMInsert (Class M tolerance).....	A111	GY1G00000000N-GFGSCBN Insert (For GY holder).....	F014,B057
DNMG000LPInsert (Class M tolerance).....	A111	GY2G00000000N-MFInsert (For GY holder).....	F015
DNMG000LSInsert (Class M tolerance).....	A111	GY0M00000000N-00Insert (For GY holder).....	F013-F016
DNMG000MAInsert (Class M tolerance).....	A113	GY0M00000000R/L05-GMInsert (For GY holder).....	F014
DNMG000MHInsert (Class M tolerance).....	A114	GYAR/L000900-000GY type holder (Internal 90° type)....	F158-F165
DNMG000MJInsert (Class M tolerance).....	A112	GYAR/LUS000900-000GY type holder (Internal 90° type)....	F150-F157
DNMG000MKInsert (Class M tolerance).....	A113	GYDR/L000900-M00R/LGY type holder (Internal 90° type)....	F158-F165
DNMG000MMInsert (Class M tolerance).....	A113	GYDR/LUS000900-M00R/LGY type holder (Internal 90° type)....	F150-F157
DNMG000MPInsert (Class M tolerance).....	A113	GYHR/L00000000-M00R/LGY type holder (External 00° type).....	F044-F055,F108-F139
DNMG000MSInsert (Class M tolerance).....	A114	GYHR/L0000000050-M00R/LGY type holder (External 50° type).....	F064
DNMG000RKInsert (Class M tolerance).....	A115	GYHR/L0000000090-M00R/LGY type holder (External 90° type).....	F058-F063,F140-F149
DNMG000RMInsert (Class M tolerance).....	A115	GYHR/LUS00000000-M00R/LGY type holder (External 00° type).....	F020-F031,F066-F097
DNMG000RPInsert (Class M tolerance).....	A115	GYHR/LUS0000000050-M00R/LGY type holder (External 50° type).....	F040
DNMG000RSInsert (Class M tolerance).....	A115	GYHR/LUS0000000090-M00R/LGY type holder (External 90° type).....	F034-F039,F098-F107
DNMG000SAInsert (Class M tolerance).....	A111	GYM00R/L0-000Modular Blade (For GY holder).....	F020-F185
DNMG000SHInsert (Class M tolerance).....	A111	GYPR/L000000000K-K25GY type holder (External 00° type).....	F056
DNMG000SYInsert (Class M tolerance).....	A112	GYPR/LUS000000000K-K25GY type holder (External 00° type).....	F032
DNMM000HLInsert (Class M tolerance).....	A116	GYQR/L0000000000-000GY type holder (External 00° type)....	F044,F048-F055
DNMM000HZInsert (Class M tolerance).....	A116	GYQR/LUS0000000000-000GY type holder (External 00° type)....	F020-F031
DNMX000MWInsert (Class M tolerance).....	A114	GYSR/L00000000JX00-000GY type holder (External 00° type).....	F042
DNMX000SWInsert (Class M tolerance).....	A112	GYSR/LUS00000000B00-000GY type holder (External 00° type).....	F018
DRGNR/L000Double clamp type holder.....	C013	H		
DSDNN-000Double clamp type holder.....	C016	H100TH-B000000HSK boring bar holder.....	H022
DSKNR/L000Double clamp type holder.....	C017	H100TH-EN3232R/L-130HSK external turning tool holder.....	H020
DSRNR/L000Double clamp type holder.....	C014	H100TH-EV3232R/L-180HSK external turning tool holder.....	H019
DSSNR/L000Double clamp type holder.....	C015	H63TH-A000DCLNR/L12HSK DCLN type holder.....	H008
DTCNN-000Double clamp type holder.....	C022	H63TH-B000-00HSK boring bar holder.....	H021
DTFNR/L000Double clamp type holder.....	C022	H63TH-DCLNL-L12-3HSK DCLN type holder.....	H008
DTGNR/L000Double clamp type holder.....	C018	H63TH-DCLNR/L-DX12HSK DCLN type holder.....	H006
DVJNR/L000Double clamp type holder.....	C024	H63TH-DCMNN-H/L12HSK DCMN type holder.....	H007
DVPNR/L000Double clamp type holder.....	C025	H63TH-DDJNL-L15-3HSK DDJN type holder.....	H011
DVVNN-000Double clamp type holder.....	C025	H63TH-DDJNR/L-DX15HSK DDJN type holder.....	H009
DWLNR/L000Double clamp type holder.....	C027	H63TH-DDNNN-H/L15HSK DDNN type holder.....	H010
E			H63TH-EN2525R/L-115HSK external turning tool holder.....	H020
ECMPR000W00ECMP type end mill.....	K198	H63TH-EV2020R/L-105-3HSK external turning tool holder.....	H021
F			H63TH-EV2525R/L-112HSK external turning tool holder.....	H019
FC400890TClamp screw (For AL type boring bar).....	M003	H63TH-MGHR/L0000000HSK MG type holder.....	H014
FMAXUR00000FMAX type face mill (Inch type).....	K062	H63TH-MMTENR-H/L16HSK MMT type holder.....	H016
FMAX000A00RFMAX type face mill (Metric type).....	K062	H63TH-MMTER-DX16HSK MMT type holder.....	H016
FMAXR0000000FMAX type face mill (Metric type).....	K062	H63TH-MTHR/L-DX43HSK MT type holder.....	H017
FMAXUR00FMAX type face mill (Inch type).....	K063	H63TH-PCLNR/L-DX12HSK PCLN type holder.....	H006
FMAX-000FMAX type face mill (Metric type).....	K063			
FSL5000RGrooving and threading boring bar....	F212,G036			
FSWL000RS/RMScrew clamp boring bar.....	E018			
FSWL000R/LMScrew clamp boring bar.....	E018			

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
H63TH-PCMNN-H/L12HSK PCMN type holder.....	H007	IMX-C4FD-CExchangeable head end mill (Head) (Inch type)... I323	
H63TH-PDJNR/L-DX15HSK PDJN type holder.....	H009	IMX-C4FD-CExchangeable head end mill (Head) (Metric type) ... I324	
H63TH-PDNNN-H/L15HSK PDNN type holder.....	H010	IMX-C4FVExchangeable head end mill (Head) (Inch type)... I325	
H63TH-PRDCN-H/L12HSK PRDC type holder.....	H012	IMX-C4FVExchangeable head end mill (Head) (Metric type) ... I326	
H63TH-PRGCR/L-DX12HSK PRGC type holder.....	H012	IMX-CH3LExchangeable head end mill (Head) (Inch type)... I338	
H63TH-SVPBR/L-DX16HSK SVPB type holder.....	H013	IMX-CH3LExchangeable head end mill (Head) (Metric type) ... I338	
H63TH-SVVBH-H/L16HSK SVVB type holder.....	H013	IMX-CH6VExchangeable head end mill (Head) (Inch type)... I339	
HBHClamp screw.....	M002,M008	IMX-CH6VExchangeable head end mill (Head) (Metric type) ... I339	
HDS10031Clamp screw.....	M008	IMX-R4FExchangeable head end mill (Head) (Inch type)... I329	
HDSU37513Clamp screw.....	M008	IMX-R4FExchangeable head end mill (Head) (Metric type) ... I330	
HFCShim screw.....	M002,M013	IRSNShim.....	M010
HFF08043HClamp screw.....	M008	ISSNShim.....	M010
HGM-PTPlug.....	H007-H019,M009	ITSNShim.....	M010
HKYDriver wrench.....	M002	IVSNShim.....	M010
HKYFlag wrench.....	M002	IWSNShim.....	M011
HKYLong L-wrench.....	M002			
HKYL-wrench.....	M002	J		
HKYT-wrench.....	M002	JDMTInsert (For AJX type cutter).....	J015,K166
HKYFlag wrench.....	M002	JDMTInsert (For AJX type cutter).....	J015,K166,K230
HNMX1206EN06-RInsert (For BMR type cutter).....	K235,J027	JDMWInsert (For AJX type cutter).....	J015,K166,K230
HNMX1206ER12-RInsert (For BMR type cutter).....	K235,J027	JFSJUST FIT SLEEVE (JFS).....	L182
HSCClamp screw.....	M002,M009	JOMTInsert (For AJX type cutter).....	J015,K166
HSCClamp screw.....	M009	JOMTInsert (For AJX type cutter).....	J015,K166,K230
HSCUClamp screw (For cutter).....	M009	JOMWInsert (For AJX type cutter).....	J015,K166,K230
HSCUCClamp screw (For cutter).....	M009	JPMT060204-EInsert (For milling).....	J035
HSCUFClamp screw (For cutter).....	M009	JPMXInsert (For SPX type end mill).....	J029,K134
HSCXClamp screw (For cutter).....	M009	JPMXInsert (For SPX type end mill).....	J029,K134
HSCXUClamp screw (For cutter).....	M009	JSSShim screw.....	M004
HSCXUClamp screw (For cutter).....	M009			
HSSClamp screw.....	M002,M008	K		
HSSClamp screw.....	M008	KGC1Clamp bridge (For UG tool block).....	M015
HSD/SP/SRClamp screw.....	M002	KNUXInsert (Class U tolerance).....	A141
HPM/FMClamp screw.....	M002			
			L		
I			LERLER type end mill.....	K146
ICSNShim.....	M010	LLCLOClamp lever.....	M014
IDSNShim.....	M010	LLCLOClamp lever.....	M014
IMXExchangeable head end mill (Holder) (Inch type) ... I340		LLCSClamp screw.....	M004
IMXExchangeable head end mill (Holder) (Metric type) ... I341		LLPShim pin.....	M014
IMXExchangeable head end mill (Holder) (Inch type) ... I342		LLSCNShim.....	M011
IMXExchangeable head end mill (Holder) (Metric type) ... I343		LLSCPShim.....	M011
IMXExchangeable head end mill (Holder) (Inch type) ... I342		LLSDNShim.....	M011
IMXExchangeable head end mill (Holder) (Metric type) ... I343		LLSDPShim.....	M011
IMXExchangeable head end mill (Head) (Inch type) ... I306,I308,I331,I335		LLSRN123Shim.....	M011
IMXExchangeable head end mill (Head) (Metric type) ... I307,I309,I332,I336		LLSSN42Shim.....	M011
IMXExchangeable head end mill (Holder) (Metric type) ... I341		LLSSP42Shim.....	M011
IMXExchangeable head end mill (Head) (Inch type) ... I312,I327		LLSTNShim.....	M011
IMXExchangeable head end mill (Head) (Metric type) ... I313,I328		LLSTP32Shim.....	M011
IMXExchangeable head end mill (Head) (Inch type) ... I310,I318,I333		LLSWNShim.....	M011
IMXExchangeable head end mill (Head) (Metric type) ... I311,I319,I334		LLSWP42Shim.....	M011
IMX-B3FVExchangeable head end mill (Head) (Metric type) ... I337		LNGU1308Insert (For VAS400/VAS500 type side cutter).....	J036,K077,K080
IMX-CExchangeable head end mill (Head) (Inch type) ... I314,I321		LNGU1710Insert (For VAS500 type side cutter) ... J036,K080	
IMX-CExchangeable head end mill (Head) (Metric type) ... I315,I321		LSClamp screw.....	M004
IMX-CExchangeable head end mill (Head) (Metric type) ... I322		LSClamp screw.....	M004
			LSClamp screw.....	M004
			LSClamp screw.....	M004
			LS0622TClamp screw.....	M004

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
M					
M AE	MAE type drill (Metric type)	L140—L144	MP4MC	MSPLUS end mill (Inch type)	I100
M AS	MAS type drill (Inch type)	L138	MP2SB	MSPLUS end mill (Metric type)	I107
M AS	MAS type drill (Metric type)	L140—L144	MP4JC	MSPLUS end mill (Inch type)	I102
M BA	Clamp screw	M009	MP4MRB	MSPLUS end mill (Inch type)	I104
M BAU100016H	Clamp screw (For AJX type cutter)	M009	MP2MB	MSPLUS end mill (Metric type)	I108
M BAU75016H	Clamp screw (For AJX type cutter)	M009	MP2MB	MSPLUS end mill (Inch type)	I111
M BD	Insert (For MBD type end mill)	J025,K213	MP2SDB	MSPLUS end mill (Metric type)	I113
M BD	MBD type end mill	K213	MP2XLB	MSPLUS end mill (Metric type)	I115
M BF	Insert (For MBD type end mill)	J025,K213	MPMM	Insert (For ECMP type end mill)	J023,K198
M BN	Insert (For MBD type end mill)	J025,K212	MPMX120412-JM	Insert (For SPX type end mill)	J029,K134
M BN	MBN type end mill	K212	MPMX120412-WH	Insert (For SPX type end mill)	J029,K134
M BN	MBN type end mill	K212	MRGNR/L	Multiple clamp type holder	C013
M CFNR/L	Multiple clamp holder	C009	MRGNR/L	Multiple clamp type holder	C013
M CFNR/L	Multiple clamp holder	C009	MS2ES	MSTAR end mill (Metric type)	I072
M CGNR/L	Multiple clamp holder	C008	MS2JS	MSTAR end mill (Metric type)	I038
M CGNR/L	Multiple clamp holder	C008	MS2LS	MSTAR end mill (Metric type)	I040
M CLNR/L	Multiple clamp holder	C007	MS2MB	MSTAR end mill (Metric type)	I079
M CLNR/L	Multiple clamp holder	C007	MS2MD	MSTAR end mill (Metric type)	I036
M CRNR/L	Multiple clamp holder	C009	MS2MRB	MSTAR end mill (Metric type)	I089
M DJNR/L	Multiple clamp holder	C010	MS2MS	MSTAR end mill (Metric type)	I033
M DJNR/L	Multiple clamp holder	C010	MS2SB	MSTAR end mill (Metric type)	I077
M DPNN	Multiple clamp holder	C011	MS2SS	MSTAR end mill (Metric type)	I032
M ES3	Spring	M014	MS2XL	MSTAR end mill (Inch type)	I049
M FE	MFE type drill	L156—L159	MS2XL6	MSTAR end mill (Metric type)	I046
M -FSCLCR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E006	MS2XLB	MSTAR end mill (Metric type)	I081
M -FSCLPRL	Screw clamp DIMPLE BAR (Heavy metal shank)	E006	MS2XLB	MSTAR end mill (Inch type)	I087
M -FSDQCR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E008	MS3ES	MSTAR end mill (Metric type)	I073
M -FSDUCR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E008	MS4EC	MSTAR end mill (Metric type)	I075
M -FSTUPRL	Screw clamp DIMPLE BAR (Heavy metal shank)	E007	MS4JC	MSTAR end mill (Metric type)	I064
M -FSVJBR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E010	MS4MC	MSTAR end mill (Metric type)	I062
M -FSVJCR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E010	MS4MRB	MSTAR end mill (Metric type)	I092
M -FSVPBR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E010	MS4SC	MSTAR end mill (Metric type)	I061
M -FSVPCR/L	Screw clamp DIMPLE BAR (Heavy metal shank)	E010	MS4XL	MSTAR end mill (Metric type)	I066
M -FSVUBRL	Screw clamp DIMPLE BAR (Heavy metal shank)	E009	MS4XL	MSTAR end mill (Inch type)	I070
M -FSVUCRL	Screw clamp DIMPLE BAR (Heavy metal shank)	E009	M -SCLCR	Screw clamp type boring bar (Heavy metal shank)	E012
M -FSWUBRL	Screw clamp DIMPLE BAR (Heavy metal shank)	E009	MSDNN	Multiple clamp type holder	C016
M -FSWUPRL	Screw clamp DIMPLE BAR (Heavy metal shank)	E009	MSDNN	Multiple clamp type holder	C016
M GD	Driver (For MICRO-MGS type drill)	L153	MSE	MSE type drill (Metric type)	L146,L147,L150
M GS	MICRO-MGS type drill (Metric type)	L152	MSJHD	MSTAR end mill (Metric type)	I055
M GTR/L43	Insert (For grooving)	H015	MSKNR/L	Multiple clamp type holder	C017
M HS	MHS type drill (Metric type)	L108—L123	MSKNR/L	Multiple clamp type holder	C017
M K1KS	Anti seize lubricant	M017	MSMHD	MSTAR end mill (Metric type)	I052
M LG	Insert (For FSL5 type boring bar)	F214,G038	MSMHDRB	MSTAR end mill (Metric type)	I095
M LG	Insert (For FSL5 type boring bar)	F214,G038	MSMHZD	MSTAR end mill (Metric type)	I057
M MLT	Insert (For FSL5 type boring bar)	F214,G038	MSMHZD	MSTAR end mill (Inch type)	I059
M MS	MMS type drill	L096—L105	MSP0300SB	MSP starter drill (Metric type)	L149
M MS	MMS type drill	L096—L105	MSRNR/L	Multiple clamp type holder	C014
M MT	Insert (For external threading)	G016,G018,G020	MSRNR/L	Multiple clamp type holder	C014
M MT	Insert (For external threading)	G014	MSRNR/L	Multiple clamp type holder	C014
M MT	Insert (For internal threading)	G017,G019,G021	MSSH	MSTAR end mill (Metric type)	I051
M MT	Insert (For internal threading)	G015	MSSNR/L	Multiple clamp type holder	C015
M MTER	Threading holder	G012	MSSNR/L	Multiple clamp type holder	C015
M MTER	Threading holder	D038,G012	M-SWLOR/L	Screw clamp type boring bar (Heavy metal shank)	E020
M MTIR	Threading holder	G013	M-SWLOR/L	Screw clamp type boring bar (Heavy metal shank)	E020
M -MWLNR/L	Multiple clamp type boring bar (Heavy metal shank)	E027	MTANR/L	Multiple clamp type holder	C020
M NS	MNS type drill (Metric type)	L128—L132	MTANR/L	Multiple clamp type holder	C020
M NS	MNS type drill (Metric type)	L128—L132	MTCNN	Multiple clamp type holder	C021
MP2SSB	MSPLUS end mill (Metric type)	I106	MTCNN	Multiple clamp type holder	C021
MP3MC	MSPLUS end mill (Inch type)	I098	MTCNN	Multiple clamp type holder	C021
			MTENN	Multiple clamp type holder	C021

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
MTENN-000X	Multiple clamp type holder	C021	NP-DCMT000R/LF	CBN insert (Class M tolerance)	B064
MTFNR/L-00	Multiple clamp type holder	C023	NP-DNGA000-002	CBN insert (Class G tolerance)	B030,B031
MTFNR/L-0000	Multiple clamp type holder	C023	NP-DNGA000-004	CBN insert (Class G tolerance)	B029,B030
MTFNR/L-0000X	Multiple clamp type holder	C023	NP-DNGA000-GAWS2JR/L	CBN insert (Class G tolerance)	B031
MTGNR/L-0000	Multiple clamp type holder	C019	NP-DNMM000RF	CBN insert (Class M tolerance)	B059
MTGNR/L-0000X	Multiple clamp type holder	C019	NP-GDCN2004PDSR3	Insert (For NF10000 type cutter)	J037
MTJNR/L-000	Multiple clamp type holder	C018	NP-SNGA000-002	CBN insert (Class G tolerance)	B033
MTJNR/L-000X	Multiple clamp type holder	C018	NP-SNGA000-GA4	CBN insert (Class G tolerance)	B033
MTK1R/L	Clamp bridge	M015	NP-SNMM000RF	CBN insert (Class M tolerance)	B060
MTRNR/L-123X	Multiple clamp type holder	C020	NP-TCGW000-003	CBN insert (Class G tolerance)	B048
MTRNR/L-164	Multiple clamp type holder	C020	NP-TNGA000-003	CBN insert (Class G tolerance)	B034,B035
MTTR/L430000	Insert (For threading)	H018	NP-TNGA000-006	CBN insert (Class G tolerance)	B034
MTVOR/L-00-00	Grooving and threading holder	F210,G034	NP-TNGA000-03	CBN insert (Class G tolerance)	B035
MVE0000X00S000	MVE type drill	L011-L070	NP-TNMM000RF	CBN insert (Class M tolerance)	B060
MVJNR/L-0000	Multiple clamp type holder	C024	NP-TPGB000-003	CBN insert (Class G tolerance)	B049,B050
MVLNR/L-0000	Multiple clamp type holder	C026	NP-TPGX0000	CBN insert (Class G tolerance)	B050
MVS0000X00S000	MVS type drill	L004-L070	NP-TPGX000-003	CBN insert (Class G tolerance)	B050
MVS0000X00S000PL	MVS type drill	L011-L061	NP-TPMH000R/LF	CBN insert (Class M tolerance)	B066
MVX0000XC000	MVX type drill (Inch type)	L166-L168	NP-TPMX000R/LF	CBN insert (Class M tolerance)	B066
MVX0000XF00	MVX type drill (Metric type)	L171-L177	NP-VBGT000RF	CBN insert (Class G tolerance)	B068
MWLNR/L-0000	Multiple clamp type holder	C027	NP-VBGW000-002	CBN insert (Class G tolerance)	B051
MWS0000LB/SB/XB	MWS type drill	L080-L090	NP-VCGT000RF	CBN insert (Class G tolerance)	B068
MWS0000LB/SB/XB	MWS type drill	L080-L090	NP-VCGW000-002	CBN insert (Class G tolerance)	B052
MWS0000X00DB	MWS type drill	L085-L090	NP-VNGA000-002	CBN insert (Class G tolerance)	B036,B037
N			NP-VNGA000-004	CBN insert (Class G tolerance)	B036,B037
NKY00D	Driver wrench	M002	NP-VNMA0000	CBN insert (Class M tolerance)	B037
NKY00F	Flag wrench	M002	NP-VNMM000RF	CBN insert (Class M tolerance)	B061
NKY00L	Long L-wrench	M002	NP-WCGW000-003	CBN insert (Class G tolerance)	B053
NKY00R	L-wrench	M002	NP-WEEW13T3AG0R3C	Wiper CBN insert (For ASX445 type cutter)	J038,K025
NKY00T	T-wrench	M002	NP-WFC42ZFER0	Wiper CBN insert (For BF407 type cutter)	J038
NKY00W	Flag wrench	M002	NP-WNGA432-003	CBN insert (Class G tolerance)	B038
NL00	Pin	M014	NP-WNGA432-GoWS3	CBN insert (Class G tolerance)	B038
NL00L	Pin	M014	NP-WNGA432-006	CBN insert (Class G tolerance)	B038
NNMU000000ZER-L	Insert (For AHX440S/AHX640S type face mill) ...	J014,K031,K044	NS000	Clamp screw (For small tools holder)	M004
NNMU000000ZEN-M	Insert (For AHX440S/AHX475S/AHX640S type face mill) ...	J014,K031,K038,K044	NS000W	Clamp screw (For small tools holder) ...	M004,M005
NNMU130532ZEN-R	Insert (For AHX440S/AHX475S type face mill) ...	J014,K031,K038	O		
NNMU200608ZEN-HK	Insert (For AHX640W type face mill) ...	J014,K044,K052	OEMX0000EER1-JS	Insert (For BOE type cutter)	J022,K194
NNMU200608ZEN-MK	Insert (For AHX640W type face mill) ...	J014,K044,K052	OEMX0000ESR1	Insert (For BOE type cutter)	J022,K194
NNMU200708ZEN-MP	Insert (For AHX640S type face mill) ...	J014,K044	OEMX0000ETR0	Insert (For BOE type cutter)	J022,J037,K194
NNMU200712ZER-MM	Insert (For AHX640S type face mill) ...	J014,K044	OEMX0000ETR1-JS	Insert (For BOE type cutter)	J022,K194
NP-CCGB21.51-GA2	CBN insert (Class G tolerance)	B042	P		
NP-CCGW000-002	CBN insert (Class G tolerance)	B042,B043	PMC00R000AM0000	PMC type end mill	K230
NP-CCGW000-002GS	CBN insert (Class G tolerance)	B044	PMF00000A00R	PMF type end mill	K233
NP-CCGW000-G0WS2	CBN insert (Class G tolerance)	B043	PMFA13R	Cartridge (For PMF type cutter)	K233
NP-CCMH000	CBN insert (Class M tolerance)	B063	PMR000000R	PMR type end mill	K232
NP-CCMW0000000	CBN insert (Class M tolerance)	B063	PMR000000A00R	PMR type end mill	K232
NP-CNGA000-002	CBN insert (Class G tolerance)	B027	Q		
NP-CNGA000-004	CBN insert (Class G tolerance)	B026	QOGT0000R-G1	Insert (For AQX type end mill)	J016,K152
NP-CNGA000-00WS2	CBN insert (Class G tolerance)	B027	QOMT0000R-M2	Insert (For AQX type end mill)	J016,J017,K152
NP-CNGA000-02	CBN insert (Class G tolerance)	B027	R		
NP-CNGA000-00WS4	CBN insert (Class G tolerance)	B026	RBH00000A	Holder (For MICRO-DEX/MICRO-MINI)	E034,E035,F216,G040
NP-CNMM000RF	CBN insert (Class M tolerance)	B059			
NP-CPGB000-002	CBN insert (Class G tolerance)	B045			
NP-CPMH000	CBN insert (Class M tolerance)	B063			
NP-DCGW000-002	CBN insert (Class G tolerance)	B046,B047			

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
RBH○○○○N	Holder (For MICRO-DEX/MICRO-MINI) E034—E036,E038,F216,F217,G040,G041		SDNCR/L-○○○SM	External front turning holder	D009
RCGT○○○○M0-AZ	Insert (Class G tolerance)	A163	S-DSKNR/L-○○○C	DOUBLE CLAMP DIMPLE BAR	E022
RCMT○○○○M0	Insert (Class M tolerance)	A163	S-DTFNR/L-○○○C	DOUBLE CLAMP DIMPLE BAR	E022
RCMX○○○○M0	Insert (Class M tolerance)	A163	S-DVUNR/L-○○○C	DOUBLE CLAMP DIMPLE BAR	E023
RCMW○○○○M0-RR	Insert (Class M tolerance)	A163	S-DWLNRL/L-○○○C	DOUBLE CLAMP DIMPLE BAR	E023
RDMW○○○○M0E	Insert (For ARX type end mill)	J017,K188	SDXCR/L-○○○	Screw clamp type holder	C032
REMX○○○○○N	Insert (For BOE type cutter)	J022,K194	SECN○○AFON1	Insert (For SE445/545 type face mill)	J027
REMX○○○○○N-JS	Insert (For BOE type cutter)	J022,K194	SECN42AFFR1	Insert (For SE445 type face mill)	J037
RGEN2004○N	Insert (For milling)	J028	SEEN○○AFON○	Insert (For SE445/545 type face mill)	J027,J028
RNG○○○	Insert (Class G tolerance)	B040	SEEN42EFOR1	Insert (For SE415 type face mill)	J027
RNMG○○○	Insert (Class M tolerance)	A117	SEEN53EFER1	Insert (For SE515 type face mill)	J028
RPHT○○○○M0E4-○	Insert (For ARP type face mill)	J017,K181	SEER53AFEN-JS	Insert (For SE445/545 type cutter)	J028
RPMT○○○○M0E4-○	Insert (For ARP type face mill)	J017,K181	SEER42EFER-JS	Insert (For SE415 type cutter)	J027
RPMW○○○○○E-JS	Insert (For BRP type cutter)	J022,K191	SEER○○AFEN-JS	Insert (For milling)	J028,J034
RPMW○○○○○E	Insert (For BRP type cutter)	J022,K191	SEET13T3AGEN-JL	Insert (For ASX445 type face mill)	J018,K025
RS○○○○T/TS	Clamp screw	M005	SEGT13T3AGFN-JP	Insert (For ASX445 type face mill)	J019,K025
RTG○○○A	Insert (Class G tolerance)	A187,B054	SEKN42AFTN	Insert (For SE445/545 type cutter)	J027
S			SEKN○○AFON1	Insert (For SE445/545 type cutter)	J027,J028
SO	Clamp screw	M005	SEKN42AGTN	Insert (For milling)	J034
SO○	Clamp screw	M005	SEKN42EFTR	Insert (For SE415 type face mill)	J027
SO○-STHOR/L-○	Grooving and threading boring bar	F211,G035	SEKN42EFOR1	Insert (For SE415 type face mill)	J027
SO○-STHNR/L-○	Grooving and threading boring bar	F211,G035	SEMT13T3AGSN-FT	Insert (For ASX445 type face mill)	J018,K025
SBAHR○○○○○	Boring holder	D047	SEMT13T3AGSN-JH	Insert (For ASX445 type face mill)	J018,K025
SBAT○○○○○○L	Insert (For BAHR type holder)	D047	SEMT13T3AGSN-JM	Insert (For ASX445 type face mill)	J018,K025
SBAT○○○○○○L-B	Insert (For BAHR type holder)	D047	SETK○○○	Clamp bridge	M015
SBH○○○○○	Clamp screw	M002	SETS○1	Clamp screw	M005
SBH○○○○R	Holder (For MICRO-DEX/MICRO-MINI) E037,E038,F217,G041		SFAN42ZFFR/L2	Insert (For BF407 type face mill)	J022
SC○○M○○S○○○S/L	Straight shank arbor (For Screw-in)	K236	SFC/FM○○○○○	Clamp screw	M002
SC○○M○○S○○○SW/LW	Straight shank arbor (For Screw-in)	K237	SFCN42ZFFR2	Insert (For BF407 type face mill)	J022,J037
SC○○M○○S○○-HSK63A	HSK shank arbor (For Screw-in)	K238	S-FSCLPR/L-○○○C	Screw clamp DIMPLE BAR	E006
SC○○M○○S10-BT○○	BT shank arbor (For Screw-in)	K238	S-FSTUPR/L-○○○C	Screw clamp DIMPLE BAR	E007
SCACR/L○○○○○○○-SM	External front turning holder	D012	SH○○○-FSDUCL○○	DIMPLE SLEEVE holder	D039,D040
SCACR/L-○○○SM	External front turning holder	D008	SL○○○○-90	HSK boring bar sleeve	H022
SCLCR/L-○○○	Screw clamp type holder	C030	SLCS105	Clamp screw	M005
SCLCR/L○○○○○○○-SM	External front turning holder	D012	SL-ONEN120404ASN	Insert (For AOX445 type cutter)	J037,K061
SCLCR/L-○○○SM	External front turning holder	D008	S-MCLNR/L-○○○	Multiple clamp type holder	E024
SCMT○○○	Insert (Class M tolerance)	A165	S-MDUNR/L-○○○	Multiple clamp type holder	E024
SCMT○○○FM	Insert (Class M tolerance)	A164	S-MSKNR/L-○○○	Multiple clamp type holder	E025
SCMT○○○FP	Insert (Class M tolerance)	A164	S-MTFNR/L-○○○	Multiple clamp type holder	E025
SCMT○○○FV	Insert (Class M tolerance)	A164	S-MTFNR/L-○○○X	Multiple clamp type holder	E025
SCMT○○○LM	Insert (Class M tolerance)	A164	S-MVUNR/L-○○○	Multiple clamp type holder	E026
SCMT○○○LP	Insert (Class M tolerance)	A164	S-MWLNRL/L-○○○	Multiple clamp type holder	E026
SCMT○○○MK	Insert (Class M tolerance)	A165	SNG○○○	Insert (Class G tolerance)	A143,B040,B062
SCMT○○○MM	Insert (Class M tolerance)	A165	SNGA○○○	Insert (Class G tolerance)	A123,B033,B060
SCMT○○○MP	Insert (Class M tolerance)	A164	SNGG○○○R/L	Insert (Class G tolerance)	A121
SCMW○○○	Insert (Class M tolerance)	A165	SNGU140812AN○○○	Insert (For WSX445 type cutter)	J033,K017
SCU○○M○○S○○○S/L	Straight shank arbor (For Screw-in)	K236	SNMA○○○	Insert (Class M tolerance)	A123
SCU○○M○○S○○○SW/LW	Straight shank arbor (For Screw-in)	K237	SNMG○○○	Insert (Class M tolerance)	A121
S-DCLNR/L-○○○C	DOUBLE CLAMP DIMPLE BAR	E021	SNMG○○○C	Insert (Class M tolerance)	A119
S-DDUNR/L-○○○C	DOUBLE CLAMP DIMPLE BAR	E021	SNMG○○○FH	Insert (Class M tolerance)	A118
SDEN42AEN	Insert (For milling)	J034	SNMG○○○FP	Insert (Class M tolerance)	A118
SDJCR/L-○○○	Screw clamp type holder	C031	SNMG○○○FS	Insert (Class M tolerance)	A118
SDJCR/L○○○○○○○-SM	External front turning holder	D013	SNMG○○○GH	Insert (Class M tolerance)	A122
SDJCR/L-○○○SM	External front turning holder	D009	SNMG○○○GK	Insert (Class M tolerance)	A120
SDJER/L-○○○	Screw clamp type holder	C041	SNMG○○○GM	Insert (Class M tolerance)	A120
SDKN○○AE○	Insert (For milling)	J034	SNMG○○○LK	Insert (Class M tolerance)	A118
SDNCN-○○○	Screw clamp type holder	C031	SNMG○○○LM	Insert (Class M tolerance)	A118
SDNCR/L○○○○○○○-SM	External front turning holder	D013	SNMG○○○LP	Insert (Class M tolerance)	A118
			SNMG○○○MA	Insert (Class M tolerance)	A120
			SNMG○○○MH	Insert (Class M tolerance)	A120
			SNMG○○○MK	Insert (Class M tolerance)	A120
			SNMG○○○MM	Insert (Class M tolerance)	A119

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
SNMG○○○○MP	Insert (Class M tolerance)	A119	SRFH○○S○○○	SRF type end mill (Metric type)	K202,K203
SNMG○○○○MS	Insert (Class M tolerance)	A121	SRFH○○S○○L○○○	SRF type end mill (Metric type)	K202
SNMG○○○○R/L1G	Insert (Class M tolerance)	A119	SRFH○○S○○E○○○	SRF type end mill (Metric type)	K203
SNMG○○○○RK	Insert (Class M tolerance)	A122	SRFH○○S○○LW/MW/EW	SRF type end mill (Metric type)	K204
SNMG○○○○RM	Insert (Class M tolerance)	A121	SRFT○○	Insert (For SRF type end mill)	J030,K206,K208
SNMG○○○○RP	Insert (Class M tolerance)	A121	SRFT○○○○	Insert (For SRF type end mill)	J030,K205,K208
SNMG○○○○RS	Insert (Class M tolerance)	A122	SUFT○○R○○	Insert (For SUF type end mill)	J030,K208
SNMG○○○○SA	Insert (Class M tolerance)	A119	SRFU○○S○○L/M	SRF type end mill	K200
SNMG○○○○SH	Insert (Class M tolerance)	A119	SRFU○○S○○LW/MW	SRF type end mill	K201
SNMG○○○○SY	Insert (Class M tolerance)	A119	SRG○○C/E	SRM2 type end mill	J031,J032,K223,K228
SNMM○○○○HL	Insert (Class M tolerance)	A123	SRGCR/L-○○○○M	Screw clamp type holder	C033
SNMM○○○○HM	Insert (Class M tolerance)	A123	SRK1R	Clamp bridge	M015
SNMM○○○○HR	Insert (Class M tolerance)	A123	SRM○○○C/E	Insert (For SRM2 type end mill)	J031,K222
SNMM○○○○HV	Insert (Class M tolerance)	A123	SRM○○○C/E-M	Insert (For SRM2 type end mill)	J031,K222,K223
SNMM○○○○HX	Insert (Class M tolerance)	A123	SRM○○○C/E-M	Insert (For SRM2 type end mill)	J031,J032,K223
SNMM○○○○HZ	Insert (Class M tolerance)	A122	SRM2○○○AM○○S/L○○	SRM2 type screw-in end mill	K220,K221
SNMN○○○	Insert (Class M tolerance)	A143,J035	SRM2○○SAS2/M2/L2/L4	SRM2 type end mill	K217
SNMU140812ANE○○○	Insert (For WSX445 type cutter)	J033,K017	SRM○○○○S○M/L/F/LF/LL	SRM2 type end mill	K218,K219
SO○○X○○	Insert (For MVX type drill)	L166—L168,L171—L177	SRM2○○○SNLS/M	SRM2 type end mill	K228
SOET12T308PEER-JL	Insert (For ASX400 type face mill)	J017,K071	SRM2○○○WNLS/M/L/X	SRM2 type end mill	K228
SOGT12T308PEFR-JP	Insert (For ASX400 type face mill)	J018,K071	SRM2500MNSL/M	SRM2 type end mill	K228
SOGX○○○○○○-UN	Insert (For MVX type drill)	L170,L179	SRS5	Clamp screw (For SRE type cutter)	M005
SOMT12T308PEER/L-JM	Insert (For ASX400 type face mill)	J017,K071	SRSGN-○○○○M	Screw clamp type holder	C044
SOMT12T308PEER-JH	Insert (For ASX400 type face mill)	J017,K071	SRSGR/L-○○○○M	Screw clamp type holder	C044
SOMT12T320PEER-FT	Insert (For ASX400 type face mill)	J018,K071	SSBCR/L-○○○	Screw clamp type holder	C034
SOMX○○○○○○-UM	Insert (For MVX type drill)	L170,L179	S-SCLCR/L-○○○	Screw clamp type boring bar	E012
SOMX○○○○○○-US	Insert (For MVX type drill)	L170,L179	S-SDQCR/L-○○○	Screw clamp type boring bar	E013
SOMX○○○○○○-UH	Insert (For MVX type drill)	L170,L179	S-SDUCR/L-○○○	Screw clamp type boring bar	E014
SONX1206PER/L	Insert (For VOX400 type face mill)	J033,K065	S-SL5NR○○	Grooving and threading boring bar	F213,G037
SPEN42EEER/L1	Insert (For FBP415 type face mill)	J024	SSC/SD/SP/SR/SS○○○○○	Clamp screw	M002
SPEN42EETR1	Insert (For FBP415 type face mill)	J037	SSSCR/L-○○○	Screw clamp type holder	C034
SPER42EEER-JS	Insert (For FBP415 type cutter)	J024	S-SSKCR/L-○○○	Screw clamp type boring bar	E015
SPG○○○	Insert (Class G tolerance)	A188,B055,B072	S-STFER/L-○○○	AL type boring bar	E028
SPGR321R	Insert (Class G tolerance)	A188	S-STUCR/L-○○○	Screw clamp type boring bar	E015
SPGX○○○	Insert (Class G tolerance)	A166,B064	S-SVQCR/L-○○○	Screw clamp type boring bar	E016
SPKN○○EDR	Insert (For milling)	J034	S-SVUCR/L-○○○	Screw clamp type boring bar	E017
SPM○○○○○	Clamp screw	M002	S-SWUCR/L-○○○	Screw clamp type boring bar	E019
SPMB1204APT	Insert (For BSP type end mill)	J023	STASX○○○N	Shim (For ASX445/400 type face mill)	M012
SPMM432A	Insert (For TBE2 type end mill)	J032	STAW○○○○○	STAW type drill (Inch type)	L184—L187
SPMN○○○	Insert (Class M tolerance)	A188,J035	STAW○○○○○S○○○	STAW type drill (Metric type)	L188—L190
SPMN○○○T	Insert (For TBE2 type end mill)	J035	STAWK○○○○TG	Insert (For STAW type drill)	L193—L197
SPMR○○○	Insert (Class M tolerance)	A188	STAWN○○○○T	Insert (For STAW type drill)	L192,L195
SPMT○○○	Insert (Class M tolerance)	A166	STAWN○○○○TH	Insert (For STAW type drill)	L192—L195
SPMW○○○	Insert (For CFSP type end mill)	A166,J023,K199	STFCR/L-○○○	Screw clamp type holder	C035
SPMX120408-JM	Insert (For SPX type end mill)	J029,K134	STFER/L-○○○	AL type holder	C042
SPMX120408-WH	Insert (For SPX type end mill)	J029,K134	STGCR/L-○○○	Screw clamp type holder	C035
SPNN42EEER/L1	Insert (For FBP415 type face mill)	J024	STGER/L-○○○	AL type holder	C042
SPSCN42	Shim	M011	SUFT○○R○○	Insert (For SRF type end mill)	K207
SPSDN32	Shim	M012	SUFT○○R○○○	Insert (For SRF type end mill)	J030,K208
SPSSN42	Shim	M012	SVHBR/L-○○○	Screw clamp type holder	C029
SPSTN32	Shim	M012	SVJBR/L-○○○	Screw clamp type holder	C028
SPSVN32	Shim	M012	SVJBR/L○○○○○○○-SM	External front turning holder	D014
SPX4-○○○A24A058RA	SPX type end mill (Metric type)	K133	SVJBR/L-○○○SM	External front turning holder	D010
SPX4R○○○○○○A058A	SPX type end mill (Metric type)	K133	SVJCR/L-○○○	Screw clamp type holder	C036
SPX4R050○○WN○	SPX type end mill	K132	SVJCR/L-○○○B-SM	External front turning holder	D048
SPX4R32○○CAT50N○	SPX type end mill	K132	SVJCR/L○○○○JX○○-SM	External front turning holder	D049
SPX4UR○○○○○○A22A	SPX type end mill	K132	SVJDR/L-○○○	AL type holder	C043
SRDCN-○○○○M	Screw clamp type holder	C033	SVLPR/L○○○○○○○-SM	External front turning holder	D014
SRDPN-1612	Screw clamp type holder	C040	SVLPR/L-○○○SM	External front turning holder	D010
SRDPR/L-1612	Screw clamp type holder	C040	SVPCL/L-○○○	Screw clamp type holder	C036
SRFHU○○AM○○○○	SRF type end mill (Metric type)	K205	SVPDR/L-○○○	Screw clamp type holder	C043
			SVPPR/L○○○○○○○-SM	External front turning holder	D015

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
SVVBN-000	Screw clamp type holder	C028	TNMG000C	Insert (Class M tolerance)	A126
SVVBR/L0000000-SM	External front turning holder	D015	TNMG000FH	Insert (Class M tolerance)	A124
SVVBR/L-000SM	External front turning holder	D011	TNMG000FP	Insert (Class M tolerance)	A124
SWLCR/L-000	Screw clamp type holder	C037	TNMG000FS	Insert (Class M tolerance)	A124
SXZCR/L-000	Double clamp type holder	C038	TNMG000FY	Insert (Class M tolerance)	A124
SXZCR/L0000015	Double clamp type holder (Inch type)	C038	TNMG000GH	Insert (Class M tolerance)	A130
T			TNMG000GK	Insert (Class M tolerance)	A127
TAWKH0000TG	Insert (For TAW type drill)	L211	TNMG000GM	Insert (Class M tolerance)	A127
TAWLN/MN/SN0000	TAW type drill (Inch type)	L200-L205	TNMG000LK	Insert (Class M tolerance)	A125
TAWLN/MN/SN0000S00	TAW type drill (Metric type)	L206,L207	TNMG000LM	Insert (Class M tolerance)	A125
TAWNH0000T	Insert (For TAW type drill)	L209,L210	TNMG000LP	Insert (Class M tolerance)	A125
TBG000	Insert (Class G tolerance)	B056	TNMG000LS	Insert (Class M tolerance)	A125
TCG000	Insert (Class G tolerance)	A189	TNMG000MA	Insert (Class M tolerance)	A127
TCGT000AZ	Insert (Class G tolerance)	A167	TNMG000MH	Insert (Class M tolerance)	A127
TCGT000FJ-P	Insert (Class G tolerance)	A167	TNMG000MJ	Insert (Class M tolerance)	A126
TCGT000MJ	Insert (Class G tolerance)	A168	TNMG000MK	Insert (Class M tolerance)	A127
TCGT000MJ-P	Insert (Class G tolerance)	A168	TNMG000MM	Insert (Class M tolerance)	A127
TCGT000R/LF	Insert (Class G tolerance)	A168	TNMG000MP	Insert (Class M tolerance)	A126
TCGW000	Insert (Class G tolerance)	A169,B048,B065	TNMG000MS	Insert (Class M tolerance)	A128
TCMT000	Insert (Class M tolerance)	A169	TNMG000R/L1G	Insert (Class M tolerance)	A126
TCMT000FM	Insert (Class M tolerance)	A167	TNMG000R/L2G	Insert (Class M tolerance)	A128
TCMT000FP	Insert (Class M tolerance)	A167	TNMG000R/LES	Insert (Class M tolerance)	A128
TCMT000FV	Insert (Class M tolerance)	A167	TNMG000RK	Insert (Class M tolerance)	A129
TCMT000LM	Insert (Class M tolerance)	A168	TNMG000RM	Insert (Class M tolerance)	A129
TCMT000LP	Insert (Class M tolerance)	A168	TNMG000RP	Insert (Class M tolerance)	A129
TCMT000MK	Insert (Class M tolerance)	A169	TNMG000RS	Insert (Class M tolerance)	A129
TCMT000MM	Insert (Class M tolerance)	A169	TNMG000SA	Insert (Class M tolerance)	A125
TCMT000MP	Insert (Class M tolerance)	A169	TNMG000SH	Insert (Class M tolerance)	A125
TCMW000	Insert (Class M tolerance)	A169,B065	TNMG000SY	Insert (Class M tolerance)	A126
TECN32PE0R1W	Insert (For NSE300 type face mill)	J025	TNMM000HL	Insert (Class M tolerance)	A131
TECN43PE0R1	Insert (For NSE400 type face mill)	J026	TNMM000HZ	Insert (Class M tolerance)	A130,A131
TEEN00PE0R1	Insert (For NSE300/400 type face mill)	J026	TNMN000	Insert (Class M tolerance)	A144
TEER00PEER-JS	Insert (For NSE300/400 type face mill)	J026	TNMX000MW	Insert (Class M tolerance)	A128
TEGX000	Insert (Class G tolerance)	B070	TNMX000SW	Insert (Class M tolerance)	A125
TEGX000R/L	Insert (Class G tolerance)	A170,B070	TPEW1303ZP0R2	Insert (For PMF type end mill) ...	J026,J037,K233
TEKN43PETR	Insert (For NSE400 type face mill)	J026	TPG000	Insert (Class G tolerance)	A191,B058,B072
TEKN43PE0R1	Insert (For NSE400 type face mill)	J026	TPGH000R/LFS	Insert (Class G tolerance)	A171
TIP00D	Torx plus Wrench	M002	TPGR000R/L	Insert (Class G tolerance)	A190
TIP00F	Torx plus Wrench	M002	TPGT000R/LF	Insert (Class G tolerance)	B066
TIP00L	Torx plus Wrench	M002	TPGV000R/LF	Insert (Class G tolerance)	B067
TIP00R	Torx plus Wrench	M002	TPGX000	Insert (Class G tolerance)	A173,B050,B067
TIP00T	Torx plus Wrench	M002	TPGX000R/L	Insert (Class G tolerance)	A172
TIP00W	Torx plus Wrench	M002	TPKN000POR	Insert (For milling)	J034
TKY00D	Driver wrench	M002	TPMH000FV	Insert (Class M tolerance)	A171
TKY00F	Flag wrench	M002	TPMH000MV	Insert (Class M tolerance)	A173
TKY00L	Long L-wrench	M002	TPMH000SV	Insert (Class M tolerance)	A172
TKY00R	L-wrench	M002	TPMN000	Insert (Class M tolerance)	A190,J035
TKY00T	T-wrench	M002	TPMR000	Insert (Class M tolerance)	A190
TKY00W	Flag wrench	M002	TPMT000MQ	Insert (Class M tolerance)	A173
TNG000	Insert (Class G tolerance)	A144,B041	TPMT000SQ	Insert (Class M tolerance)	A171
TNGA000	Insert (Class G tolerance)	A130,B035,B060	TPMX000	Insert (Class M tolerance)	A173
TNGG000PK	Insert (Class G tolerance)	A124	TPMX000L	Insert (Class M tolerance)	A172
TNGG000R/L	Insert (Class G tolerance)	A129	TPS000	Clamp screw	M005
TNGG000R/LF	Insert (Class G tolerance)	A125	TPS000	Clamp screw	M005
TNGG000R/LFS	Insert (Class G tolerance)	A124	TS000	Clamp screw	M006
TNGG000R/LK	Insert (Class G tolerance)	A126	TS000	Clamp screw	M006
TNMA000	Insert (Class M tolerance)	A130	TSS04005	Radial screw	M006
TNMC00NGR/L000	Grooving insert	F210,F211,G034,G035	TSS04505S	Radial screw	M006
TNMG00NV	Threading insert	F210,F211,G034,G035	TTAHR/L-000	External threading holder	D035
TNMG000	Insert (Class M tolerance)	A127,A128	TTAHR/L0000	External threading holder	D036
			TTAT000000R/L0-B	Threading insert	D035,D036

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
V					
VAS400UA000000R/L0000	VAS400 type side cutter (Inch type)	K076	VF2XL	IMPACT MIRACLE end mill (Metric type)	I197
VAS400UA000000N00000	VAS400 type side cutter (Inch type)	K077	VF2XLB	IMPACT MIRACLE end mill (Metric type)	I229
VBET000R/LSN	Insert (Class E tolerance)	A177	VF2XLB	IMPACT MIRACLE end mill (Inch type)	I235
VBET000R/LSR	Insert (Class E tolerance)	A177	VF2XLBS	IMPACT MIRACLE end mill (Metric type)	I228
VBET000R/LWSN	Insert (Class G tolerance)	A177	VF3XB	IMPACT MIRACLE end mill (Metric type)	I237
VBGT000FJ	Insert (Class G tolerance)	A174	VF4MB	IMPACT MIRACLE end mill (Metric type)	I242
VBGT000FJ-P	Insert (Class G tolerance)	A174	VF4MV	IMPACT MIRACLE end mill (Metric type)	I202
VBGT000MJ	Insert (Class G tolerance)	A175	VF6MHV	IMPACT MIRACLE end mill (Metric type)	I203
VBGT000MJ-P	Insert (Class G tolerance)	A175	VF6MHVCH	IMPACT MIRACLE end mill (Metric type)	I204
VBGT000R/LF	Insert (Class G tolerance)	A175	VF6MHVRB	IMPACT MIRACLE end mill (Metric type)	I261
VBMT000	Insert (Class M tolerance)	A176	VF6MHVRBCH	IMPACT MIRACLE end mill (Metric type)	I263
VBMT000FM	Insert (Class M tolerance)	A174	VF6SVRCH	IMPACT MIRACLE end mill (Metric type)	I214
VBMT000FP	Insert (Class M tolerance)	A174	VF8MHVCH	IMPACT MIRACLE end mill (Metric type)	I205
VBMT000FV	Insert (Class M tolerance)	A174	VF8MHVRBCH	IMPACT MIRACLE end mill (Metric type)	I265
VBMT000LM	Insert (Class M tolerance)	A175	VFFDRB	IMPACT MIRACLE end mill (Metric type)	I244
VBMT000LP	Insert (Class M tolerance)	A175	VFHVRB	IMPACT MIRACLE end mill (Metric type)	I245
VBMT000LS	Insert (Class M tolerance)	A175	VFHVRB	IMPACT MIRACLE end mill (Inch type)	I251
VBMT000MK	Insert (Class M tolerance)	A176	VFMD	IMPACT MIRACLE end mill (Metric type)	I207
VBMT000MM	Insert (Class M tolerance)	A176	VFMD	IMPACT MIRACLE end mill (Inch type)	I209
VBMT000MP	Insert (Class M tolerance)	A175	VFMDRB	IMPACT MIRACLE end mill (Metric type)	I258
VBMT000MS	Insert (Class M tolerance)	A176	VFMFPR	IMPACT MIRACLE end mill (Metric type)	I215
VBMT000MV	Insert (Class M tolerance)	A176	VFMHVRBCH	IMPACT MIRACLE end mill (Metric type)	I260
VBMT000SV	Insert (Class M tolerance)	A175	VFR2SB	IMPACT MIRACLE REVOLUTION end mill (Metric type)	I266
VBMW000	Insert (Class M tolerance)	A177	VFR2SBF	IMPACT MIRACLE REVOLUTION end mill (Metric type)	I268
VC2C	MIRACLE end mill (Metric type)	I146	VFSD	IMPACT MIRACLE end mill (Metric type)	I206
VC2PSB	MIRACLE end mill (Metric type)	I125	VFSDRB	IMPACT MIRACLE end mill (Metric type)	I257
VC2PSBP	MIRACLE end mill (Metric type)	I126	VFSFPR	IMPACT MIRACLE end mill (Metric type)	I211
VC4JRB	MIRACLE end mill (Metric type)	I139	VFSFPRCH	IMPACT MIRACLE end mill (Metric type)	I213
VC4MB	MIRACLE end mill (Metric type)	I131	VFX5-000000A000R	VFX5 type end mill (Metric type)	K139
VCGT000AZ	Insert (Class G tolerance)	A179	VFX5UR000000A00	VFX5 type end mill (Inch type)	K138
VCGT000R/LF	Insert (Class G tolerance)	A179	VFX6-000A00A000R	VFX6 type end mill (Metric type)	K143
VCGT000MLS	Insert (Class G tolerance)	A178	VFX6UR000000A00	VFX6 type end mill (Inch type)	K142
VCHFRB	MIRACLE end mill (Metric type)	I141	VNGA000	Insert (Class G tolerance)	A135,B037,B061
VCHFRB	MIRACLE end mill (Inch type)	I144	VNGG000FJ	Insert (Class G tolerance)	A132
VCLD	MIRACLE end mill (Metric type)	I124	VNGG000R/L	Insert (Class G tolerance)	A135
VCMT000	Insert (Class M tolerance)	A180	VNGG000R/LF	Insert (Class G tolerance)	A132
VCMT000FM	Insert (Class M tolerance)	A178	VNGM000MJ	Insert (Class G tolerance)	A133
VCMT000FP	Insert (Class M tolerance)	A178	VNMA000	Insert (Class M tolerance)	A135
VCMT000FV	Insert (Class M tolerance)	A178	VNMG000	Insert (Class M tolerance)	A135
VCMT000LM	Insert (Class M tolerance)	A179	VNMG000FH	Insert (Class M tolerance)	A132
VCMT000LP	Insert (Class M tolerance)	A179	VNMG000FP	Insert (Class M tolerance)	A132
VCMT000LS	Insert (Class M tolerance)	A179	VNMG000FS	Insert (Class M tolerance)	A132
VCMT000MK	Insert (Class M tolerance)	A180	VNMG000GK	Insert (Class M tolerance)	A134
VCMT000MM	Insert (Class M tolerance)	A179	VNMG000GM	Insert (Class M tolerance)	A134
VCMT000MP	Insert (Class M tolerance)	A179	VNMG000LK	Insert (Class M tolerance)	A133
VCMT000MS	Insert (Class M tolerance)	A180	VNMG000LM	Insert (Class M tolerance)	A133
VCMT000MV	Insert (Class M tolerance)	A180	VNMG000LP	Insert (Class M tolerance)	A132
VCMT000SV	Insert (Class M tolerance)	A179	VNMG000LS	Insert (Class M tolerance)	A133
VCMW000	Insert (Class M tolerance)	A180	VNMG000MA	Insert (Class M tolerance)	A134
VCPSRB	MIRACLE end mill (Metric type)	I133	VNMG000MH	Insert (Class M tolerance)	A134
VCXB	MIRACLE end mill (Metric type)	I128	VNMG000MJ	Insert (Class M tolerance)	A133
VDGX000R/L	Insert (Class G tolerance)	A181	VNMG000MK	Insert (Class M tolerance)	A134
VDGX000R/LF	Insert (Class G tolerance)	B071	VNMG000MM	Insert (Class M tolerance)	A134
VF2MV	IMPACT MIRACLE end mill (Metric type)	I200	VNMG000MP	Insert (Class M tolerance)	A133
VF2SB	IMPACT MIRACLE end mill (Metric type)	I219	VNMG000MS	Insert (Class M tolerance)	A135
VF2SB	IMPACT MIRACLE end mill (Inch type)	I222	VNMG000SA	Insert (Class M tolerance)	A133
VF2SDB	IMPACT MIRACLE end mill (Metric type)	I224	VNMG000SH	Insert (Class M tolerance)	A133
VF2SDBL	IMPACT MIRACLE end mill (Metric type)	I225	VOX400-000A00R	VOX400 type face mill (Metric type)	K067
VF2SSB	IMPACT MIRACLE end mill (Metric type)	I218	VOX400R000000	VOX400 type face mill (Metric type)	K066
VF2WB	IMPACT MIRACLE end mill (Metric type)	I217	VOX400UR000000	VOX400 type face mill (Inch type)	K065
			VPET000R/LSRF	Insert (Class E tolerance)	A182
			VPGT000MSMG	Insert (Class G tolerance)	A182

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
VQ4SVB	SMART MIRACLE end mill (Metric type).....	I180	WNMG000RM	Insert (Class M tolerance)	A140
VQ4SVB	SMART MIRACLE end mill (Inch type).....	I182	WNMG000RP	Insert (Class M tolerance)	A139
VQJHV	SMART MIRACLE end mill (Metric type).....	I170	WNMG000RS	Insert (Class M tolerance)	A140
VQJHV	SMART MIRACLE end mill (Inch type).....	I172	WNMG000SA	Insert (Class M tolerance)	A137
VQMHV	SMART MIRACLE end mill (Metric type).....	I163	WNMG000SH	Insert (Class M tolerance)	A137
VQMHV	SMART MIRACLE end mill (Inch type).....	I167	WNMG000SW	Insert (Class M tolerance)	A137
VQMHVRB	SMART MIRACLE end mill (Metric type).....	I184	WNMG000SY	Insert (Class M tolerance)	A137
VQMHVRB	SMART MIRACLE end mill (Inch type).....	I189	WOWE12T308PEOR8C	Wiper insert (For ASX400 type face mill) ...	J018,K071
VQMHVRBF	SMART MIRACLE end mill (Metric type).....	I192	WOEX1206PER5C	Wiper insert (For ASX400 type face mill) ...	J033,K065
VQMHVRBF	SMART MIRACLE end mill (Inch type).....	I194	WPC42EER/L10C	Wiper insert (For FBP415 type face mill).....	J024
VQMHZV	SMART MIRACLE end mill (Metric type).....	I147	WPC42EETR10C	Wiper insert (For FBP415 type face mill).....	J038
VQMHZV	SMART MIRACLE end mill (Inch type).....	I153	WPGT000	Insert (Class G tolerance).....	B069
VQMHZVOH	SMART MIRACLE end mill (Metric type).....	I157	WPGT000R/LFS	Insert (Class G tolerance).....	A185
VQMHZVOH	SMART MIRACLE end mill (Inch type).....	I160	WPMT000MV	Insert (Class M tolerance)	A185
VQSVR	SMART MIRACLE end mill (Metric type).....	I177	WS000000T	Clamp screw (For TAW type drill).....	M007
VQXL	SMART MIRACLE end mill (Inch type).....	I174	WS000000TPS	Internal screw (For STAW type drill) ...	L198,M007
W			X		
WBG000R/LF	Insert (Class G tolerance).....	A183	XCMT000SVX	Insert (Class M tolerance)	A186
WBMT000R/LMV	Insert (Class M tolerance)	A183	XDGT1550PDR-G00	Insert (For BXD4000 type cutter).....	J023,K128
WCGT000FJ-P	Insert (Class G tolerance).....	A184	XDGT1550PDR-GL00	Insert (For BXD4000 type cutter).....	J023,K128
WCGT000MJ	Insert (Class G tolerance).....	A184	XDGX1750PDR-GM	Insert (For AXD4000 type cutter).....	J019,K113
WCGT000MJ-P	Insert (Class G tolerance).....	A184	XDGX1750PDR-GL	Insert (For AXD4000 type cutter).....	J019,K113
WCGT000R/L	Insert (Class G tolerance).....	A184	XDGX2270PDR-GLA	Insert (For AXD7000 type cutter).....	J020,K121
WCMT000	Insert (Class M tolerance)	A184	XDGX2270PDR-GL	Insert (For AXD7000 type cutter).....	J020,K121
WCMW000	Insert (Class M tolerance)	B069	XNMU16000R-OS	Insert (For VFX5 type end mill).....	J032,K140
WCS503507H	Shim screw	M007	XNMU19000R-OS	Insert (For VFX6 type end mill).....	J033,K144
WEC00AFOR5C	Wiper insert (For SE445/545 type face mill) ...	J028,J038	XNS00	Clamp screw.....	M007
WEC42EFOR5C	Wiper insert (For SE415 type face mill).....	J027	XNS000	Clamp screw.....	M007
WEEW13T3AGOR8C	Wiper insert (For ASX445 type face mill) ...	J019,K025	XPGT13T3PDR-G0	Insert (For BAP3500 type cutter).....	J021
WFC42ZFER2	Wiper insert (For BF407 type face mill).....	J038	XPMT13T3PDR-M0	Insert (For BAP3500 type cutter).....	J021
WNEU1305ZEN4C-M	Wiper insert (For AHX440S type face mill) ...	J014,K031	Z		
WNEU2007ZEN7C-M	Wiper insert (For AHX640S type face mill) ...	K044	ZCMX000000ER0	Insert (For LER type end mill).....	J024,J025,K146
WNEU2006ZEN7C-WK	Wiper insert (For AHX640S/AHX640W type face mill) ...	J015,K044,K052			
WNEU2007ZEN7C-WP	Wiper insert (For AHX640S type face mill) ...	J014,K044			
WNGU1406ANEN8C-M	Wiper insert (For WSX445 type cutter) ...	J034,K017			
WNMA000	Insert (Class M tolerance)	A140			
WNMG000	Insert (Class M tolerance)	A139			
WNMG000C	Insert (Class M tolerance)	A137			
WNMG000FH	Insert (Class M tolerance)	A136			
WNMG000FP	Insert (Class M tolerance)	A136			
WNMG000FS	Insert (Class M tolerance)	A136			
WNMG000FY	Insert (Class M tolerance)	A136			
WNMG000GH	Insert (Class M tolerance)	A140			
WNMG000GJ	Insert (Class M tolerance)	A140			
WNMG000GK	Insert (Class M tolerance)	A138			
WNMG000GM	Insert (Class M tolerance)	A138			
WNMG000LK	Insert (Class M tolerance)	A137			
WNMG000LM	Insert (Class M tolerance)	A136			
WNMG000LP	Insert (Class M tolerance)	A136			
WNMG000LS	Insert (Class M tolerance)	A137			
WNMG000MA	Insert (Class M tolerance)	A139			
WNMG000MH	Insert (Class M tolerance)	A139			
WNMG000MJ	Insert (Class M tolerance)	A137			
WNMG000MK	Insert (Class M tolerance)	A138			
WNMG000MM	Insert (Class M tolerance)	A138			
WNMG000MP	Insert (Class M tolerance)	A138			
WNMG000MS	Insert (Class M tolerance)	A139			
WNMG000MW	Insert (Class M tolerance)	A139			
WNMG000RK	Insert (Class M tolerance)	A140			