



## Clamping points of cutter

Quick change system for this tool. Please refer to the procedure below for the correct usage.


- ① Insert the 4 bolts into the machines spindle.



- ② Then place the cutter into position.



- ③ Rotate the cutter until it locks in the key way.



- ④ Tighten up the bolts, assembly is completed.

